


Service Manual

- Sec. 1** *General Description*
- Sec. 2** *Adjustment Procedures*
- Sec. 3** *Block / Schematic / Circuit
 Board Diagrams*
- Sec. 4** *Exploded Views &
 Replacement Parts Lists*

Panasonic ^{Mini} **DV DV** _{PAL}

Digital Cassette Video Recorder

AG-DV2700 ^E_B



Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

Panasonic

© 1998 Matsushita Electric Industrial Co., Ltd. All rights reserved.
Unauthorized copying and distribution is a violation of law.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

AG-DV2700E

Power Source:	220-240 V AC 50/60 Hz
Power Consumption:	36 watts
Power Consumption When in Standby Mode:	Approx. 10 watts

Video Recording System:	2 rotary heads, Digital Component
Audio Recording System:	PCM Digital Recording; 16 bit (48 kHz/2ch), 12 bit (32 kHz/4ch)
Video Heads:	2 heads
Tape Speed:	SP; 18.831mm/sec. LP; 12.568 mm/sec.
Tape Format:	DV/ Mini DV tape
Record/Playback Time:	SP; 120 min. LP; 180 min. with DV120 SP; 60 min. LP; 90 min. with DVM60
FF/REW Time:	approx. 70 sec. with DV120 approx. 50 sec. with DVM60

VIDEO

Television System:	CCIR; 625 lines, 50 fields, PAL colour signal		
Modulation System:	Digital Component recording		
Input Level:	AV1/AV2;	1.0 Vp-p,	75 ohm, terminated
	VIDEO IN (AV3) (PHONO);	1.0 Vp-p,	75 ohm, terminated
	S-VIDEO IN (AV3);	1.0 Vp-p,	75 ohm, terminated
Output Level:	AV1/AV2;	1.0 Vp-p,	75 ohm, terminated
	VIDEO OUT (AV3) (PHONO);	1.0 Vp-p,	75 ohm, terminated
	S-VIDEO OUT (AV3);	1.0 Vp-p,	75 ohm, terminated
	RF Modulated;	UHF channel (21-69),	75 ohm

AUDIO

Input Level:	AV1/AV2;	-6 dBV,	more than 10 kohm
	AUDIO IN (AV3) (PHONO);	-6 dBV,	more than 10 kohm
	MIC(M3);	-70 dBV,	
Output Level:	AV1/AV2;	-6 dBV,	less than 1 kohm
	AUDIO OUT (PHONO);	-6 dBV,	less than 1 kohm
	HEAD PHONES;	-30 dBV,	8ohm
Audio Track:	16 bit (48 kHz/2ch);	1 track, 2 channels	
	12 bit (32 kHz/4ch);	2 tracks, 4 channels	

Digital Still Picture:	Digital Still Picture Output, Control Signal Input/Output (Transfer rate; max. 115 kbps)		
Digital Interface:	DV Terminal (i.LINK, 4-pin)		
Video Horizontal Resolution:	Colour; more than 500 lines		
Audio Frequency Response:	20 Hz-20 kHz (16 bit) 20 Hz-14.5 kHz (12 bit)		
Operating Temperature:	5°C-40°C		
Operating Humidity:	35%-80%		
Weight:	7 kg		
Dimensions:	445 (W)×123 (H)×373.5 (D) mm		
Standard Accessories:	1 pc. RF Coaxial Cable 1 pc. Remote Controller 4 pcs. "R6" size batteries 3 pcs. AC Mains Leads 1 pc. DV Cable 1 pc. Edit Cable 1 pc. S-Video Cable 1 pc. AV Cables 1 pc. Editing Controller Cable 1 pc. Digital Video Head Cleaner 2 pcs. 21-pin Phono Transformer Adaptors (Input/Output) 1 pc. Modular Cap		
Attached Parts:			

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

AG-DV2700B

Power Source:	220-240 V AC 50/60 Hz
Power Consumption:	36 watts
Power Consumption When in Standby Mode:	Approx. 10 watts

Video Recording System:	2 rotary heads, Digital Component
Audio Recording System:	PCM Digital Recording; 16 bit (48 kHz/2ch), 12 bit (32 kHz/4ch)
Video Heads:	2 heads
Tape Speed:	SP; 18.831mm/sec. LP; 12.568 mm/sec.
Tape Format:	DV/ Mini DV tape
Record/Playback Time:	SP; 120 min. LP; 180 min. with DV120 SP; 60 min. LP; 90 min. with DVM60
FF/REW Time:	approx. 70 sec. with DV120 approx. 50 sec. with DVM60

VIDEO

Television System:	CCIR; 625 lines, 50 fields, PAL colour signal		
Modulation System:	Digital Component recording		
Input Level:	AV1/AV2;	1.0 Vp-p,	75 ohm, terminated
	VIDEO IN (AV3) (PHONO);	1.0 Vp-p,	75 ohm, terminated
	S-VIDEO IN (AV3);	1.0 Vp-p,	75 ohm, terminated
Output Level:	AV1/AV2;	1.0 Vp-p,	75 ohm, terminated
	VIDEO OUT (AV3) (PHONO);	1.0 Vp-p,	75 ohm, terminated
	S-VIDEO OUT (AV3);	1.0 Vp-p,	75 ohm, terminated
	RF Modulated;	UHF channel (21-68),	75 ohm

AUDIO

Input Level:	AV1/AV2;	-6 dBV,	more than 10 kohm
	AUDIO IN (AV3) (PHONO);	-6 dBV,	more than 10 kohm
	MIC(M3);	-70 dBV,	
Output Level:	AV1/AV2;	-6 dBV,	less than 1 kohm
	AUDIO OUT (PHONO);	-6 dBV,	less than 1 kohm
	HEAD PHONES;	-30 dBV,	8ohm
Audio Track:	16 bit (48 kHz/2ch);	1 track, 2 channels	
	12 bit (32 kHz/4ch);	2 tracks, 4 channels	

Digital Still Picture:	Digital Still Picture Output, Control Signal Input/Output (Transfer rate; max. 115 kbps)		
Digital Interface:	DV Terminal (i.LINK, 4-pin)		
Video Horizontal Resolution:	Colour; more than 500 lines		
Audio Frequency Response:	20 Hz-20 kHz (16 bit) 20 Hz-14.5 kHz (12 bit)		
Operating Temperature:	5°C-40°C		
Operating Humidity:	35%-80%		
Weight:	7 kg		
Dimensions:	445 (W)×123 (H)×373.5 (D) mm		
Standard Accessories:	1 pc. RF Coaxial Cable 1 pc. Remote Controller 4 pcs. "R6" size batteries 1 pc. AC Mains Lead 1 pc. DV Cable 1 pc. Edit Cable 1 pc. S-Video Cable 1 pc. AV Cables 1 pc. Editing Controller Cable 1 pc. Digital Video Head Cleaner 2 pcs. 21-pin Phono Transformer Adaptors (Input/Output) 1 pc. Clamp Filter 1 pc. Modular Cap		
Attached Parts:			

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

INTRODUCTION

This Service Manual contains technical information such as General Description, Adjustment Procedures, Block Diagrams / Schematic Diagrams / C.B.A. Layout and Exploded Views / Parts Lists which service personnel to understand and service the Panasonic Digital Video Cassette Recorder model AG-DV2700E/B.

Panasonic

Note : Some parts of this service manual have been made based on NV-DV10000.
The portion or section mentioned NV-DV10000B is equivalent to AG-DV2700B and
NV-DV10000EC is AG-DV2700E.

CONTENTS

SECTION1 GENERAL DESCRIPTION	1-1
1.SERVICE INFORMATION	1-1
1-1.CHANNEL MEMORY INITIALIZATION	1-1
2.SERVICE POSITION	1-2
2-1.EXTENTION CABLES	1-2
2-2.SERVICE POSITION	1-2
2-3.PREPARATION FOR ELECTRICAL ADJUSTMENT	1-3
3.SERVICE INFORMATION DISPLAY	1-9
3-1.SET SERVICE MODE	1-9
3-2.SELF-TEST MODE	1-11
4.REMOVAL OF THE CASSETTE TAPE	1-12
4-1.BATTERY OPERATION	1-12
4-2.HAND OPERATION	1-12
5.OPERATING INSTRUCTIONS	1-14
SECTION2 ADJUSTMENT PROCEDURES	2-1
1.DISASSEMBLY/ASSEMBLY PROCEDURES FOR CABINET PARTS, C.B.A. AND MECHANISM UNIT	2-1
1-1.DISASSEMBLE FLOW CHART FOR CABINET PARTS, C.B.A. AND MECHANISM UNIT	2-1
1-2.DISASSEMBLY/ASSEMBLY PROCEDURES(FOR CABINET PARTS, C.B.A. AND MECHANISM UNIT)	2-2
2.DISASSEMBLY/ASSEMBLY PROCEDURES FOR MECHANISM	2-4
2-1.DISASSEMBLY FLOW CHART FOR MECHANISM	2-4
2-2.DISASSEMBLY/ASSEMBLY PROCEDURES(FOR MECHANICAL PARTS)	2-5
1.MECHANISM CONNECTION C.B.A.	2-5
2. TRAY UNIT	2-6
3.MECHANICAL PARTS	2-8
4.MECHANICAL ADJUSTMENT	2-18
4-1.NAME OF TAPE TRANSPORTATION	2-18
4-2.CLEANING PROCEDURES	2-18
4-3.REEL OFFSET AND TENTION ARM ADJUSTMENT	2-18
4-4.T4,S4 AND S5 POSTHEIGHT PRE-ADJUSTMENT	2-19
4-5.TAPE PASS ADJUSTMENT PROCEDURES	2-19
5.ELECTRICAL ADJUSTMENT	2-23
1.SERVO CIRCUIT	2-23
1-1.T AND S REEL OFFSET ADJUSTMENT	2-23
1-2.TENTION ARM OFFSET ADJUSTMENT	2-23
1-3.TENTION ARM NEUTRAL ADJUSTMENT	2-23
1-4.TENTION ARM PLAY VOLTAGE ADJUSTMENT	2-24
1-5.CONFIRMATION OF REV POSITION OF THE TENTION ARM	2-24
1-6.TENTION REGULATOR SPRING ADJUSTMENT	2-24
1-7.CONFIRMATION OF REV TENTION	2-24
1-8.SUPPLY AND TAKE-UP PHOTO SENSOR SENSITIVITY ADJUSTMENT	2-25
2.VIDEO CIRCUIT	2-26
2-1.PHASE DIFFERENCE OF Y/C SEPA. V BLANKING PULSE ADJUSTMENT	2-26
2-2.PHASE DIFFERENCE OF Y/C SEPA. H BLANKING PULSE ADJUSTMENT	2-26
2-3.PAL ENCODER FREE RUN FREQUENCY ADJUSTMENT	2-26
2-4.EDIT OSD COLOUR BURST CLOCK FREQUENCY ADJUSTMENT	2-26
2-5.EDIT OSD DOT CLOCK FREQUENCY ADJUSTMENT	2-26
2-6.PHASE DIFFERENCE OF COLOUR CTL BURST GATE PULSE ADJUSTMENT	2-26
2-7.E-E Y LEVEL ADJUSTMENT	2-26

3.AUDIO CIRCUIT	2-26
3-1.LEVEL METER ADJUSTMENT	2-26
6.SPECIAL FIXTURES & TOOLS	2-27
SECTION3 BLOCK/SCHEMATIC/CIRCUIT BOARD DIAGRAMS	3-1
3-1.ABBREVIATIONS	3-1
3-2.OVERALL BLOCK DIAGRAM	3-7
3-3.SYSTEM CONTROL & SERVO BLOCK DIAGRAM	3-9
3-4.AUDIO BLOCK DIAGRAM	3-14
3-5.INPUT / OUTPUT BLOCK DIAGRAM	3-17
3-6.VIDEO BLOCK DIAGRAM	3-19
3-7.SOLENOID BLOCK DIAGRAM	3-21
3-8 POWER SUPPLY SCHEMATIC DIAGRAM	3-23
3-9.LOADING SECTION IN MECHANISM DRIVE SCHEMATIC DIAGRAM	3-25
3-10.MOTOR DRIVE SCHEMATIC DIAGRAM	3-28
3-11.DRIVE SECTION IN MECHANISM DRIVE SCHEMATIC DIAGRAM	3-29
3-12.SOLENOID SECTION INMECHANISM DRIVE SCHEMATIC DIAGRAM	3-33
3-13.POWER SECTION IN MAIN SCHEMATIC DIAGRAM	3-35
3-14.EDIT/SYSTEM CONTROL & SERVO SECTION IN MAIN, 5P JACK SCHEMATIC DIAGRAMS	3-37
3-15.AUDIO SECTION IN MAIN SCHEMATIC DIAGRAM	3-47
3-16.RF SECTION IN MAIN SCHEMATIC DIAGRAM	3-51
3-17.ANALOG Y/C SCHEMATIC DIAGRAM	3-53
3-18.HEAD AMP SCHEMATIC DIAGRAM	3-60
3-19.FRONT (L) SCHEMATIC DIAGRAM	3-61
3-20.FRONT (R) SCHEMATIC DIAGRAM	3-62
3-21.LSI/SYSTEM CONTROL & SERVO SECTION IN DIGITAL SCHEMATIC DIAGRM	3-63
3-22.VIDEO 1 SECTION IN DIGITAL SCHEMATIC DIAGRAM	3-75
3-23.VIDEO 2 SECTION IN DIGITAL SCHEMATIC DIAGRAM	3-79
3-24.EDITING CONTROLLER SCHEMATIC DIAGRAM	3-85
3-25.IR, FRONT LED SCHEMATIC DIAGRAMS	3-86
3-26.TIMER, MODULAR SCHEMATIC DIAGRAMS	3-87
3-27.AUDIO SCHEMATIC DIAGRAM	3-89
3-28.NICAM DECODER SCHEMATIC DIAGRAM	3-92
3-29.INPUT/OUTPUT, REAR JACK SCHEMATIC DIAGRAMS	3-93
3-30.TV DEMODULATOR SCHEMATIC DIAGRAM	3-96
3-31.POWER SUPPLY C.B.A.	3-97
3-32.REAR JACK C.B.A.	3-97
3-33.DV JACK C.B.A.	3-98
3-34.MAIN C.B.A.	3-99
3-35.FRONT (L) C.B.A.	3-101
3-36.FRONT (R) C.B.A.	3-101
3-37.HEAD AMP C.B.A.	3-102
3-38.ANALOG Y/C C.B.A.	3-103
3-39.DIGITAL C.B.A.	3-107
3-40.MOTOR DRIVE C.B.A.	3-111
3-41.MODULAR C.B.A.	3-112
3-42.IR C.B.A.	3-112
3-43.FRONT LED C.B.A.	3-112
3-44.5P JACK C.B.A.	3-112
3-45.EDITING CONTROLLER C.B.A.	3-113
3-46.TIMER C.B.A.	3-113
3-47.MECHANISM DRIVE C.B.A.	3-115
3-48.AUDIO C.B.A.	3-119
3-49.INPUT / OUTPUT C.B.A.	3-121
3-50.NICAM DECODER C.B.A.	3-122
3-51.TV DEMODULATOR PACK C.B.A.	3-122
SECTION4 EXPLODED VIEWS & REPLACEMENT PARTS LISTS	4-1
4-1.EXPLODED VIEW & MECHANICAL REPLACEMENT PARTS LIST	4-1
1.CASING PARTS SECTION	4-1
2.CHASSIS PARTS SECTION (1)	4-3
3.CHASSIS PARTS SECTION (2)	4-4
4.SUB CHASSIS PARTS SECTION	4-6
5.CASSETTE TRAY PARTS SECTION	4-7
6.PACKING PARTS SSECTION	4-8
4-2.ELECTRICAL REPLACEMENT PARTS LIST	4-10

Caution for AC Mains Lead (AG-DV2700B)

IMPORTANT

Your attention is drawn to the fact that the recording of pre-recorded tapes or discs or other published or broadcast material may infringe copyright laws.

WARNING

TO REDUCE THE RISK OF FIRE OF SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

As this equipment gets hot during use, operate it in well ventilated place; do not install this equipment in a confined space such as a book case or similar unit.

FOR YOUR SAFETY

■ DO NOT REMOVE OUTER COVER.

To prevent electric shock, do not remove cover. There are no user serviceable parts inside. Refer all servicing to qualified service personnel.

For your safety please read the following text carefully

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 5 amp fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5 amps and that it is approved by ASTA or BSI to BS 1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13 AMP SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:


Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstance should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol .


How to replace the Fuse

- There are two types of the AC Mains Lead assembly: A and B as shown below.


1 Open the fuse compartment with a screwdriver.

2 Replace the fuse and fuse cover.

TYPE A



TYPE B



This VCR has an On Screen Display (OSD) function which allows for timer recording and various other settings. The main operation buttons used in the function are listed below. These buttons are on the remote controller.

MENU: To make the On Screen Display Main menu appear on the TV screen.

To return to the previous screen.

EXIT: To exit the menu completely.

OK: To confirm the selection, or to store.

▲▼◀▶: To make selections from the On Screen Display.

These buttons can also be used for the playback, stop, rewind and fast forward mode.

SECTION 1 GENERAL DESCRIPTIONS

1. SERVICE INFORMATION

1-1. Channel Memory IC Initialization

Memory IC30012 has to be initialized due to the setting value changes when replacing it.

Note:









a) When replacing the memory IC30012, the OSD microprocessor IC30013 should be replaced together.

b) It has to be performed before tuning.

c) Meaning of "MEMORY IC INITIALIZATION" is to make dependency in different models and to distinguish between different features.

d) It does not need to perform when replacing the System Control IC6001.

CHANNEL MEMORY IC INITIALIZATION

PROCEDURES	FIP Display	Monitor Screen
Simultaneously press the FF and EJECT buttons for 3 seconds.		None
Keep to press the FF button and press the Eject button twice.		None
Press the EJECT key for 3 seconds. (Eject operation is performed at this time.)		None
Press the CH UP key twice. (The 3rd digit changes 0→1→2 by pressing the CH up key.)		None
Press the POWER key.	 (Colon starts flashing)	Service Screen (See Fig. S1)
Press the REC key on the Remote Controller Unit.		Service Screen (See Fig. S1)
Set the Model Code and Option Code by pressing ► ◀ ▲ ▼ keys on the Remote Controller Unit. (See Fig. S2)		Service Screen (See Fig. S1)
To release Service Mode, press POWER key and then press the FF then press the EJECT button more than 6 times until the normal indication on the FIP.		None

Service		
	Version	
OSD	VCCZ1.35	0
MAIN	V1CJ0.34	0
Pos for time ref.	NONE	
Last error code:	00	
Model Code	104 (68h)	
Option Code	160 (A0h)	
Clock adjust	+ 0	
VPS/PDC default	AUTO (depend)	

Fig. S1 Service Screen

"+" by pressing ▲ ▼ keys on the Remote Controller Unit.
If changing the "VPS/PDC default" accidentally, set the code mentioned "(default)" by pressing ▲ ▼ keys on the Remote Controller Unit.

Model	Model Code	Option Code
AG-DV2700E	164	136
AG-DV2700B	168	160

Fig. S2 Model Code & Option Code

Caution:

Since the "Clock adjust" and "VPS/PDC default" are future expansion, do not change the initial setting.

If changing the "Clock adjust" accidentally, set the code

2. Service Position

2-1. Extension Cables

Use the following Extension Cables when checking individual circuit boards.

No.	Part No.	Part Name	Connection	Q'ty	Remarks
1	VFK1405	Audio Connection C.B.A.	Main C.B.A. - Audio C.B.A.	1	
2	VFK1406	Digital Connection C.B.A.	Main C.B.A. - AV Digital C.B.A.	1	
3	VFK1407P	Y/C Connection C.B.A.	Main C.B.A. - Analog Y/C C.B.A.	1	
4	VFK1408	Motor Connection C.B.A.	Main C.B.A. - Motor Drive C.B.A.	1	
5	VFK0849	20P Flat Cable	Digital FP3201 - Head Amp FP5002	1	
6	VFK1445	26P Flat Cable	Main P6703 - Mech. P6504	1	
7	VFK1446	32P Flat Cable	Main P6701 - Mech. P6505	1	
8	VFK1436	14P Extension Cable	Motor Power P2502 - Mech. P2705	2	
9	VFK1448	12P Extension Cable	Main P6707 - Power P1102	1	

Fig. 2-1 Extension Cable

2-2. Service Position

a. Service Position for AV Digital, Analog Y/C, Audio or Motor Power C.B.A.




Fig. 2-2 Service Position for AV Digital, Analog Y/C, Audio and Motor Drive C.B.A.

b. Service Position for Mechanism Drive C.B.A.

When checking the Mechanism Drive C.B.A., remove the Mechanism unit with Mechanism Drive C.B.A. from the frame. Then, connect the extension cables as shown in Fig. 2-3 and turn over the Mechanism unit.

c. Service Position for Main C.B.A.

When checking the Main C.B.A., take out the Mechanism unit with Mechanism Drive C.B.A. and Main C.B.A. from the frame. Then, connect extension cables as shown in Fig. 2-4 and turn over the Main C.B.A..




Fig. 2-3 Service Position for Mechanism Drive C.B.A.




Fig. 2-4 Service Position for Main C.B.A.

2-3. Electrical Adjustment

1. PREPARATION

To perform electrical adjustments completely, the following measuring equipment and system should be prepared.

1-1. Measuring Equipment

Equipment	Specification	
Dual-Trace Oscilloscope	Voltage Range	0.001 to 50V/Div.
	Frequency Range	DC to 100MHz
	Probes	10:1, 1:1
DVM (Digital Volt Meter)	Voltage Range	0.001 to 50V
Frequency Counter	Frequency Range	0 to 150MHz

Fig. 2-5

1-2. Special Fixtures and Tools

Please refer to the special jigs and tools list at the end of the electrical adjustment procedure section.

1-3. PC EVR System

The table in figure 2-6 shows the all electrical adjustments, some of the adjustments need the PC EVR System.

Menu	Adjustment	Nasality of PC EVR System	Menu	Adjustment	Nasality of PC EVR System
SERVO ADJUSTMENT MENU	1. Reel Offset Adjustment	No	VIDEO ADJUSTMENT MENU	4. Video Y-in level adjustment	Necessary
	2. Tension Arm Offset Adjustment	No		5. Video-in C level adjustment	Necessary
	3. Tension Arm neutral Adjustment	No		6. Play Y level adjustment	Necessary
	4. Tension Arm Play Level Adjustment	No		7. Play C level adjustment	Necessary
	5. Tension Arm Rev Position Confirmation	No		8. Centering adjustment	Necessary
	6. Tension Arm Spring Adjustment	No		9. Write product ID	Necessary
	7. Reverse Tension Confirmation	No	SEE MANUAL	10. Phase of Y sepa. V blanking pulse adj.	No
	8. PG Shifter Adjustment (Automatic)	Necessary		11. Phase of Y sepa. H blanking pulse adj.	No
	9. Sensitivity adjustment of tape sensors	No		12. PAL encoder free run adjustment	No
SEE MANUAL	1. E-E Y level adjustment	No		13. Edit OSD colour burst clock frequency adj.	No
VIDEO ADJUSTMENT MENU	2. Video VCO adjustment	Necessary		14. Edit OSD dot clock adjustment	No
	3. RF / BITERBI adjustment	Necessary	AUDIO ADJUSTMENT MENU	1. Level meter adjustment	No

Fig. 2-6

Figure 2-7 shows the overall system connection of the PC EVR System.




Fig. 2-7

2. PC EVR System Hook up Procedures

1. Connect the 2 pcs of 30 pin flat cables between the Measuring Board and EVR Connection Board as shown below.
Make sure that the contact surface of 2 pcs. of 30 pin Flat Cables are inner side and direction of the EVR Connection Board is as shown in figure 2-8.




Fig. 2-8

2. Set the Connector Board with the 30 pin Cables to the unit as shown in Figure below.
Make sure that the direction of the Connection Board is correctly fit.




Fig. 2-9

3. Connect a 9pin RS-232C cable between the Measuring Board and RS-232C connector on the Personal Computer as shown in figure 2-7.
4. Connect the 4pin 6V/DC Power cable between AC adaptor or DC power supply unit..

3. PC EVR SOFTWARE


3-1. BOOT UP THE SOFTWARE

1. Power ON the Personal Computer.
Windows 95 is set up (AUTO).
2. Restart the PC in Dos mode.
3. Insert the EVR software floppy disk into the FD drive of the PC.
4. Boot up the EVR program as the following steps.


- 1) Input "a:" and then press the "ENTER" key.




- 2) Input "cd \" and then press the "ENTER" key.



- 3) Input the "cd" and press the "ENTER" key.



- 4) input the "dv2700" and then press the "ENTER" key.



- 5) Wait for a few seconds so that the EVR adjustment program is started.
- 6) For the adjustments, follow the program display.

3-2. How to Use the Main Menu

Select a Sub Menu to check, adjust the unit and etc. by pressing ↑ ↓ (UP/DOWN) Key in Main Menu. Then, press "ENTER" Key. The Sub Menu will be displayed.

Note: Menu (pages) 3 through 5 are needed for adjustment.

With using keys, also the menu can be changed.




Fig. 2-10

3-3. Introduction of the Sub Menu




Fig. 2-11




Fig. 2-14




Fig. 2-12




Fig. 2-15




Fig. 2-13

3-4. Restoration of Connecting Error

This program checks connecting condition with the deck all the time.

When the deck power is off or reset, or cable is disconnected during servicing, restart the program by pressing "CTRL" key and "BREAK" key together.

4. EEPROM

Some of adjustment data have been stored in the EEPROM in the Digital C.B.A.

Be sure to save the EEPROM data into the personal computer before performing service and adjustment, in order to avoid any accidental data loss.

4-1. How to Save the EEPROM Data

- 1) Select "1. VIDEO CHECK" in the Main menu, and then press the "Enter" key.
- 2) Select "3. Read (Save) / Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
- 3) Select "2. Save all EEPROM data" in Read (Save) / Write All EEPROM data menu, and then press the "Enter" key.
- 4) Input the File name, and then press "Enter" key.
The data of EEPROM will be stored in the personal computer.

4-2. How to REWRITE Saved data

When it becomes impossible to adjust during service and adjustment, rewrite the saved data which stored in the personal computer and readjust.

- 1) Select "1. VIDEO CHECK" in the Main menu, and then press the "Enter" key.
- 2) Select "3. Read (Save) / Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
- 3) Select "3. Writing from stored data file" in Read (Save) / Write All EEPROM data menu, and then press the "Enter" key.
- 4) Input the saved file name, and then press the "Enter" key.
- 5) The stored data is written in the EEPROM.

4-3. Digital C.B.A. Replacement

In case that the Digital C.B.A. is replaced, be sure to write the data to EEPROM on the Digital C.B.A. as follows.

1. Select "1. VIDEO CHECK" In the Main menu, and then press the "Enter" key.
2. Select "3. Read (Save) / Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
4. Select "3. Writing from stored data files." In Read (Save) / Write All EEPROM data menu, and then press the "Enter" key. Input the saved file name, and then press the "Enter" key.

OR;

Select "4. Writing of fixed / average values," and then press the "Enter" key. And press the "Enter" key once again.

Then, input ID Number as follows.

4-4. How to input ID Number

When writing ID Number from the saved data which is stored in 4-1.

1. Select "2. Check [Video]." In the Main menu, and then press the "Enter" key.
2. Select "3. Read (Save) / Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
4. Select "5. Writing ID from the stored file." In Read [Save]/Write All EEPROM data menu, and then press the "Enter" key. Input the saved file name, and then press the "Enter" key.

The ID Number will be written automatically.

When the original ID information can not be read because of the destruction of EEPROM etc.:

1. Select "1. VIDEO ADJUSTMENT" in Main menu, and then press "Enter" key.
2. Select "9. Write products ID" in the Video adjustment menu, and then press the "Enter" key.
5. ID Number will be written automatically.
(If the deck has no ID, it may cause problem on the IEEE1394 communication and etc.

3. Service Information Display

In the Service Information Display, there are four digits divided into 3 functions, Service Mode, Service Data Number and Service Information Number.

This information aids trouble shooting by indicating the source of the malfunction. The service mode number and service data number are used by the technician during repair while the service information can be used by the consumer to diagnose malfunctions allowing the technical to provide a more accurate repair cost estimate and reduce repair time.




Fig. 2-16 Service Information Display

3-1. Set Service Mode

Press the FF and Eject buttons simultaneously.

The display will change "0.** : **"

Pressing the FF and Eject button simultaneously will change the Service Mode Number as follows. (Refer to Fig. 2)

Mode 1 : Check tape protection circuit

Mode 2 : Check tape transport mechanism

Mode 3 : Check mode switching operation

Mode 4 : Check tray in /out operation

Mode 5 : Check control buttons

Mode 6 : Check mode switching and solenoid operations

Mode 7 : Check loading / unloading operation

The first digit indicates which of the above 7 service modes that the unit is currently in.

The second and third digits are service data that indicate the condition of the circuit or mechanism being checked.

The forth digit is the service information display. It is to be used by the consumer to help determine the source of a malfunction. The service information display operates independently of the service modes and stores the fault indication in memory for as long as AC power is not supplied.

Service Mode Number	Service Data Numbers	Indication	Remarks																				
1 Tape Beginning/ End detect	00	Light detected at both sensors.																					
	01	Tape Beginning. Light to Supply Photo Sensor is blocked.																					
	02	Tape End. Light to Take-up Photo Sensor is blocked.																					
	03	No light detected at either sensor.																					
2 Mechanism position detect	03	Cassette Down																					
	05	H/L Position																					
	07	Middle Position																					
	09	Stop Position																					
	33	Tray Open Position																					
3 Process mode detect	0*, 2*, 3*	Tray In → Stop																					
	6*	Stop → Play																					
	8*	Play → Cue																					
	9*	Play → Rev																					
	n*	Stop → FF/Rew																					
	2*	Loading																					
	L*	Unloading																					
4 Tray process mode detect	1*	Tray In condition																					
	*2 → *3 → *4 → 00	Tray Out condition																					
5 Mode detect	00	Stop																					
	02	Rew																					
	03	FF																					
	04	Rev																					
	05	Cue																					
	08	Play																					
	0U	Rec																					
6 Mechanism position detect	1U	<table><tr><td>Solenoid condition</td><td>Pinch</td><td>S Reel</td><td>T Reel</td></tr><tr><td>Stop</td><td>On</td><td>Off</td><td>Off</td></tr><tr><td>FF/REW</td><td>Off</td><td>Off</td><td>Off</td></tr><tr><td>Tray In/Out</td><td>Off</td><td>On</td><td>On</td></tr><tr><td>Loading</td><td>Off</td><td>Off</td><td>On</td></tr></table>	Solenoid condition	Pinch	S Reel	T Reel	Stop	On	Off	Off	FF/REW	Off	Off	Off	Tray In/Out	Off	On	On	Loading	Off	Off	On	
	Solenoid condition	Pinch	S Reel	T Reel																			
	Stop	On	Off	Off																			
	FF/REW	Off	Off	Off																			
	Tray In/Out	Off	On	On																			
Loading	Off	Off	On																				
16																							
2U																							
29																							
7 Checks loading/unloading operation	_____	<p>The Loading Motor rotates for loading operation when the "Play" button is pressed.</p> <p>The Loading Motor rotates for unloading operation when the "Stop" button is pressed.</p>	Tape not required.																				

Fig. 3-2 Service Mode Number

3-2. Self-Test Mode

This VTR has a self-diagnosis and display function. If the VTR detects trouble during installation or during use, one of the following Fault Indication Codes will automatically appear in the VTR display. Fault Indication codes are displayed in the form of a single English letter plus two numbers such as "H01" .

Note;

1. The indication "H" or "F" is displayed on the FIP, and the power is automatically turned off.
When the power is turned on again, the Fault Indication Code will disappear and the unit will return to normal display mode (either clock or counter).
2. This Fault Indication Code will be stored in the Timer microprocessor even with the AC plug disconnected.
The two-digit number portion of the stored Fault Indication Code can be redisplayed in the FIP' s "second" display position (the last 2 digits on the light) by placing the unit in Service Mode Number 2 when turning on Service Information Display as for example "01" or "02" etc.
If a second error occurs, only the most recent error will be displayed and stored.
3. To erase the stored Fault Indication Code data, press "FF" and "Eject" button simultaneously more than 5 seconds.

Display	Condition	Cause	Remedy/Check	
H	H01	Cylinder Lock	After Cylinder lock is detected, the Cylinder does not start rotating again even after tape unloading.	Check the cylinder motor drive.
	H02	Capstan Lock	Cassette tape is not wound up during tape unloading.	Check the capstan motor drive.
F	F03	Loading Lock	Mechanism locks during tape loading.	1. Check the loading motor drive. 2. Check the mecha. phase alignment.
	F04	Unloading Lock	Mechanism locks during tape unloading.	
	F05	Reel FG Detection	Detects abnormal condition during tape loading/unloading.	Check the tension sensor and supply and take-up reel drive.
	F06	Tray In Lock	Tray Motor locks during Tray In.	1. Check the tray motor drive. 2. Check the tray phase alignment.
	F07	Tray Out Lock	Tray Motor locks during Tray Out.	
	F08	Tension Sensor Detection	Detects abnormal condition during tape loading.	1. Check the tension sensor and supply and take-up reel drive.

Fig. 3-3 Self-Test Indication Display

4. Removal of the Cassette Tape

If the electrical circuit is defective and the action of unloading and front unloading do not work properly, it is possible to remove the cassette manually.

There are 2 methods to remove the cassette as follows.

4-1. Battery Operation




Fig. 4-1

4-2. Hand Operation

1. Unload the loading post by turning the loading motor




Fig. 4-2
1—12

2. Take up the tape by turning the supply reel table




Fig. 4-3

3. Eject the tray by turning the tray motor





Fig. 4-4

Control and Connection Sockets

This section gives a detailed explanation of the function of each button, switch and connection socket.




FRONT

- 1 POWER \odot/\ominus**
Press to switch the VCR from on to standby mode or vice versa. In standby mode, the unit is still connected to the mains.
- 2 Infra-red Remote Control Receiver Window**
- 3 STANDBY Indicator**
This indicator is lit when main lead is connected and the power is off.
- 4 POWER Indicator**
This indicator is lit when the power is on.
- 5 TIMER REC Indicator**
This indicator is lit when the timer recording function is on.
- 6 CASSETTE IN Indicator**
This indicator is lit when a cassette is inserted.
- 7 OPEN/CLOSE**
Press to open the front panel or open/close the cassette tray.
- 8 EDIT**
By connecting a movie camera or VCR with an EDIT socket to this socket via an Edit cable, various kinds of editing functions can be performed more quickly and efficiently between two VCRs or between a VCR and a movie camera.

- 9 DV IN/OUT (\square)**
To connect the DV cable to digital video equipment with IEEE 1394-1995 compatible DV terminal.
"i.LINK" is the name of the connector in accordance with the International Standard IEEE1394-1995.
"i.L" is the logo marked on products conforming with the "i.LINK" specifications. For further details on the DV terminal, refer to the Glossary of Terms on page 92.
- 10 EDIT MODE**
PLAYER: When this VCR is used as the playback VCR during editing operations.
RECORDER: When this VCR is used as the recording VCR during editing operations.
• Normally set at this position.
When operating this VCR using another VCR or an editing controller.
PASSIVE:
• The picture quality best suited for editing is selected.
- 11 EDIT CONTROL**
To select a connected component when another component is to be connected for editing, etc.
- 12 DV CASSETTE/MINI DV CASSETTE Indicators**
This indicator corresponds to the size of the cassette inserted is lit.

- 13 JOG/SHUTTLE Indicator**
While this display is lit, the unit is set to the Jog/Shuttle mode.
• Check that the display is lit before proceeding with a jog or shuttle operation.
• The display is automatically turned off if no operation is performed.
- 14 VIDEO INSERT Indicator**
This indicator is lit when the Video Insert editing is performed.
- 15 AUDIO DUB Indicator**
This indicator is lit when the Audio Dubbing or Audio Mixing is performed.
- 16 AUDIO INSERT Indicator**
This indicator is lit when the Audio Insert editing is performed.
- 17 Cassette Tray**
- 18 Indicators for AUDIO MONITOR**
The audio track selected by STEREO SELECT lights. (This applies to a tape recorded in the 12bit audio mode only.)
- 19 MIXING EDIT**
For Mixing Editing.
- 20 TIMER REC \square**
To turn the timer recording function on and off.
 \square is lit when the function is on (standby mode).
Once the operating timer recording function is set, normal VCR operation is not possible unless this button is set to off.
- 21 DIRECT TV REC**
For the Direct TV REC function.
- 22 \vee/\wedge**
To select the required programme position (TV station) of the VCR.
- 23 REC/OTR**
To start recording.
For One-Touch Recording (OTR).
- 24 AUDIO REC LEVEL**
To adjust the audio recording level to peak at +4 dB on the recording level indicator.
• When INPUT SELECT is set to DV IN the audio recording level cannot be adjusted.
- 25 S-VIDEO IN (AV3)**
To connect the S-Video cable to a movie camera or to another VCR that has an S-Video output socket.
• If an S-Video cable is connected, other video input (AV3) is automatically switched off.

- 26 VIDEO IN (AV3)**
To connect the video cable to a movie camera or to another VCR.
- 27 AUDIO \square (AV3)**
To connect the audio cable to a movie camera or to another VCR.
- 28 EDITING CONTROLLER Socket**
When using the editing controller separate from the main unit, remove the modular cap and then connect the editing controller cable.
- 29 DV IN/OUT Indicators**
DV IN: This indicator is lit when INPUT SELECT is set to DV \square .
DV OUT: This indicator is lit when a playback operation is performed using this VCR or when INPUT SELECT is set to other than DV IN.
- 30 Display**
- 31 Indicators for AUDIO DATA**
Displays the audio data that is to be recorded, or the audio data on a tape that has already been recorded. The audio recording mode can be set in the SET UP menu.
12bit-STEREO1: To play back a tape that is recorded in 12bit audio mode.
12bit-STEREO2: To play back a STEREO2 audio tape recorded in the 12bit audio mode.
16bit: To play back a tape that is recorded in 16bit audio mode.
- 32 AUDIO MIX Level**
During the Audio Mixing function:
To adjust the volume of the original audio (STEREO1).
During playback of a tape recorded in the 12bit audio mode:
To adjust the mix balance between the STEREO1 and STEREO2 audio.
- 33 MIC**
To connect to a microphone for recording.
Once connected, this socket has priority.
- 34 PHONES**
To connect stereo headphones.
- 35 PHONES LEVEL**
For adjusting the volume level of connected stereo headphones.



REAR

36 AC IN~

To connect to the main power supply.


37 DIGITAL STILL PICTURE OUT

To connect the VCR with a computer in order to transmit the image data to the computer.

38 AV1 (TV)

This 21-pin scart terminal carries input and output signals for both picture and sound. TV sets equipped with a similar socket can be connected here. The scart terminal is also called

Peritel
Euro Connector
Euro AV



NORMAL (AV1/AV2)

01 AUDIO OUTPUT CH2 (R)	01 AUDIO OUTPUT CH2 (R)
02 AUDIO INPUT CH2 (R)	02 AUDIO INPUT CH2 (R)
03 AUDIO OUTPUT CH1 (L)	03 AUDIO OUTPUT CH1 (L)
04 AUDIO GND	04 AUDIO GND
05 BLUE GND	05 No connection
06 AUDIO INPUT CH1 (L)	06 AUDIO INPUT CH1 (L)
07 BLUE	07 No connection
08 SWITCHING VOLTAGE	08 SWITCHING VOLTAGE
09 GREEN GND	09 No connection
10 CONTROL SIGNAL (AV1 only)	10 CONTROL SIGNAL
11 GREEN	11 No connection
12 No connection	12 No connection
13 RED GND	13 C OUT GND
14 BLANKING GND	14 No connection
15 RED	15 C OUT
16 BLANKING	16 No connection
17 VIDEO OUTPUT GND	17 Y OUT GND
18 VIDEO INPUT GND	18 VIDEO INPUT GND
19 VIDEO OUTPUT	19 Y OUT
20 VIDEO INPUT	20 VIDEO INPUT
21 GND	21 GND

Caution: RGB reservation for only E/E operation when connecting the Pay TV decoder.

39 NORMAL/S-VIDEO OUT

NORMAL: Normally set to this position.

S-VIDEO OUT (AV1):

Set to this position when connecting the VCR to a TV set equipped with 21-pin Euro-AV Connector with pins for separate Y/C signal input.

40 VIDEO IN (AV3)

To connect the video cable to a movie camera or to another VCR.

- If units are connected to the VIDEO input sockets on both the front and rear of this VCR, the rear video inputs are automatically switched off.

41 S-VIDEO IN (AV3)

To connect the S-Video cable to a movie camera or to another VCR that has an S-Video output socket.

- If an S-Video cable is connected, other video input (AV3) is automatically switched off.
- If units are connected to the VIDEO input sockets on both the front and rear of this VCR, the rear video inputs are automatically switched off.

42 S-VIDEO OUT

To connect the S-Video cable to a TV or another VCR that has an S-Video input socket.

43 VIDEO OUT

To connect the video cable to a TV or to another VCR.

44 RF IN

To connect to the external aerial.

45 8mm CONTROL

To connect a movie camera or another VCR equipped with LANC socket for editing.

46 AV2 (EXT/DECODER)

To connect to a decoder or another VCR.

47 AUDIO IN (AV3)

To connect the audio cable to a movie camera or to another VCR.

48 AUDIO OUT


To connect the audio cable to a stereo audio system.

49 RF OUT

To connect to the aerial terminal on a TV set.

Infra-red Remote Controller

VCR OPERATION



1 AUDIO OUT

To select the desired sound mode. At every push of this button, the audio output mode changes as follows.




The Left(L) and Right(R) indicators shown which sound mode is selected in the following way.

Stereo: Both the L and R indicators appear.
Left: The L indicator appears.
Right: The R indicator appears.

2 STEREO SELECT

To select the audio track (STEREO1 audio and/or STEREO2 audio) on a tape which was recorded in the 12bit audio mode. During playback, each time the button is pressed, the sound changes as follows:



- The audio track cannot be selected during the playback of a tape recorded in the 16bit audio mode.
- When **INPUT SELECT** is set to DV and 12bit audio mode input signal is being received, the audio track can be selected by **STEREO SELECT** at any time.

3 Numeric Buttons

Be sure that the VCR/TV switch is set to VCR.

- To select the programme positions (1-99) of the VCR.

9: 9

19: 1 -> 1 -> 9

- To enter a ShowView number

4 INPUT SELECT

To select the A1, A2, A3 or DV IN external recording sources.

5 > (PLAY)

To start playback. ">" is lit during playback.

6 << (REWIND)

In the stop mode: To rewind the tape.
In the playback mode: To search backward for a scene.
In the rewind mode: To view the video.
"<<" is lit during rewind.

7 VCR ⏻

Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still connected to the mains.

8 SEARCH SELECT

To search for a recorded programme using the index/photoshot index search function.

9 JOG/SHUTTLE

Press this to switch to the Jog/Shuttle mode and make JOG/SHUTTLE ON appear on the remote controller display. Press again to make JOG/SHUTTLE ON disappear.


In the stop mode: Still picture (Jog/Shuttle mode).
During playback: Still picture (Jog/Shuttle mode).

10 Jog Dial/Shuttle Ring

Jog Dial (inner dial):
Operate after pressing JOG/SHUTTLE to switch to the Jog/shuttle mode.
To locate any desired field with utmost precision.

Shuttle Ring (outer ring):

Operate after pressing JOG/SHUTTLE to switch to the Jog/shuttle mode.
To adjust playback speed backward or forward.



11 PAUSE/SLOW (II/II)

During playback:

- When pressed once: Still picture. "II" is lit.
- When pressed for 2 seconds or more: Slow playback. "II>" is lit.


During recording: To pause recording.

12 INDEX/PHOTO

For the index/photoshot index search function.

13 DISPLAY


To change the VCR display indication as follows:



- The time code frame values are not displayed on the main unit's VCR display.

14 V (VCR)

To select the required programme position (TV station) of the VCR.



15 VCR/TV switch

VCR: To select the VCR operation mode.
TV: To select the TV operation mode.

16 PRINT

To print out images when the VCR is connected to a video printer with an Edit socket.

17 REC

To start recording.

18 □ (STOP)

To stop playback or recording.

19 ►► (FAST FORWARD)

In the stop mode: To fast forward the tape.
In the playback mode: To search forward for a scene.
In the fast forward mode: To view the video.
"D>" is lit during fast forward.

20 TRANSMIT

To transmit the data that has been set on the remote controller to the VCR.

21 SHOWVIEW

For the ShowView programming.

22 DIRECT TV REC

For the Direct TV REC function.
Press both buttons at the same time.

23 Infra-red Transmitter

24 JOG/SHUTTLE ON Display

While this display is lit, the VCR is set to the Jog/Shuttle mode.

- Check that the display is before proceeding with a jog or shuttle operation.
- The display is automatically turned off if no operation is performed.

25 ^, OFF+

For the Child Lock Function.
See the description on page 11.

26 Timer Recording Operation Buttons

∇ ^, DATE, ON, OFF:

TIMER REC:

To programme a timer recording.
To turn the timer recording function on and off. is lit when the function is on (standby mode).
Once the operating timer recording function is set, normal VCR operation is not possible unless this button is set to off.

CHECK:

To programme a timer recording.
To check and modify timer programmes.

CANCEL:

To cancel timer programmes.

TRANSMIT:

To transmit the data that has been set on the remote controller to the VCR.

27 VPS/PDC

To set the VPS/PDC recording option or cancel the option.

28 On Screen Display Menu Operation Buttons

The buttons with the green characters are used for the on screen display menu operation.

MENU:

To make the On Screen Display Main menu appear on the TV screen.

EXIT:

To exit the menu completely.

OK:

To confirm the selection, or to store.

29 RESET

To reset the tape counter (elapsed time) to "0:00.00".
• The tape counter is automatically reset to "0:00.00" when a video cassette is inserted.
• It is not possible to reset the Time code to "0h00m00s00f" using RESET.

30 ▲▼◀▶

To make selections from the On Screen Display. (When the On Screen Display is displayed.)
These buttons can also be used for the playback, stop, rewind and fast forward mode. (When the On Screen Display is not displayed.)

31 VCR1/2/3

To select the remote control mode. The selected mode appears on the remote controller display.

VCR1:

Set this position on both the VCR and remote controller for normal use with one VCR.

VCR2:

Set this position when using two Panasonic VCRs.

VCR3:

Set this position when using three Panasonic VCRs.

- When the VCR's remote control mode has been switched, select the same remote control mode on the editing controller as well.

32 AV LINK

To select the VCR mode or TV mode for AV LINK.

33 ZERO STOP

For the zero stop function.

34 DATE-OFF/ON, DATE-SELECT


When pictures are recorded using this VCR or a Panasonic Digital Video Camera, the date and time of the recording are automatically recorded onto the tape's sub code track.
This button is used to select the information to be displayed on the On Screen Display.

DATE-OFF/ON:

To make the Date/Time indication appear on the TV screen.

DATE-SELECT:

To change the Indication to be displayed on the TV screen as follows:




35 SP/LP

To select the tape speed desired for recording.

36 Display

TV OPERATION



37 TV

Press to switch the TV from on to standby mode or vice versa. In standby mode, the TV is still connected to the mains.

- With some TV models, it may only be possible to switch the TV to the standby mode using this button. In this case, use the numeric buttons, TV/AV or V to switch the TV on.

38 Numeric Buttons

To select programme positions (1-99) of the TV.

- Be sure that the VCR/TV switch is set to TV.

39 VOLUME

To adjust the volume of the TV.

40 TV/AV (TV)

To select the required programme position (TV station) of the TV.

41 TV/AV

To switch between TV channels and external input channels.


42 TV-SET

To set the remote controller for operation of the TV.

43 OFF

Sets the remote controller for operation of the TV.

Set the VCR/TV switch to TV.




Child Lock function

Holding down **TV/AV** and **OFF** until "CL" and "hold" appear in the VCR display will deactivate all buttons. Any external commands will not be processed by the VCR.

To cancel this function, repeat the same procedure until "CL" and "hold" disappear.

- If a button is pressed while the Child Lock function is on, "CL" and "hold" appear in the VCR display.
- When the power is disconnected, the Child Lock function is automatically cancelled after the roughly 60 minutes of backup time.

Editing Controller



1 SET UP

To make the SET UP screen appear on the TV screen. When the SET UP screen is displayed, use this button to return to the previous screen.

2 ▲ ▼ ◀ ▶ (CURSOR)

To make selections from the SET UP or EDIT MENU screen. (When the SET UP or EDIT MENU screen is displayed.)

3 EXIT


To exit the SET UP or EDIT MENU screen.

4 EDIT MENU

To make the EDIT MENU screen appear on the TV screen, and to return to the previous screen. This button is also used to stop editing functions using the EDIT MENU screen.

5 DISPLAY

To change the VCR display indication as follows:



- The time code frame values are not displayed on the main unit's VCR display.

6 DATE-OFF/ON, DATE-SELECT

When pictures are recorded using this VCR or a Panasonic Digital Video Camera, the date and time of the recording are automatically recorded onto the tape's sub code track.

This button is used to select the information to be displayed on the On Screen Display.

DATE-OFF/ON:

To make the Date/Time indication appear on the TV screen.

DATE-SELECT:

To change the Indication to be displayed on the TV screen as follows:



7 MARK IN

To set edit start points for Programme Editing.

8 MARK OUT

To set edit end points for Programme Editing.

9 REC

To start recording.

10 ◀ (REW)

In the stop mode: To rewind the tape.
In the playback mode: To search backward for a scene.
In the rewind mode: To view the video.
"◀" is lit during rewind.

11 ■ (STOP)

To stop playback or recording.

12 ▶ (PLAY)

To start playback. "▶" is lit during playback.

13 ▶▶ (FF)

In the stop mode: To fast forward the tape.
In the playback mode: To search forward for a scene.
In the fast forward mode: To view the video.
"▶▶" is lit during fast forward.

14 PAUSE/SLOW (II/II▶)

During playback:

- When pressed once: Still picture. "II" is lit.
- When pressed for 2 seconds or more: Slow playback. "II▶" is lit.

During recording: To pause recording.

15 Jog Dial/Shuttle Ring

Jog Dial (inner dial):


Operate after pressing JOG/SHUTTLE to switch to the Jog/shuttle mode.

To locate any desired field with utmost precision.

Shuttle Ring (outer ring):

Operate after pressing JOG/SHUTTLE to switch to the Jog/shuttle mode.

To adjust playback speed backward or forward.



16 Infra-red Transmitter

17 OK

To start Manual editing and to store the selection on the SET UP or EDIT MENU screen.

18 VIDEO INSERT

For the Video Insert function and the AV Insert function.

19 AUDIO INSERT

For the Audio Insert function and the AV Insert function.

20 AUDIO DUB

For the Audio Dubbing function or the Audio Mixing function.

21 JOG/SHUTTLE

To switch to the Jog/Shuttle mode. When the button is pressed, it lights and the VCR enters the Jog/Shuttle mode.
In the stop mode: Still picture (Jog/Shuttle mode).
During playback: Still picture (Jog/Shuttle mode).

22 INPUT SELECT

To select the A1, A2, A3 or DV IN external recording source.

23 RESET

To reset the tape counter (elapsed time) to "0:00.00".
• The tape counter is automatically reset to "0:00.00" when a video cassette is inserted.
• It is not possible to reset the Time code to "0h00m00s00f" using RESET.

24 ZERO STOP

For the zero stop function.

25 PLAYER

To operate the playback unit.

26 SEARCH SELECT

To search for a recorded programme using the Index/photostat Index search.

27 RECORDER

To operate the recording VCR.

28 INDEX/PHOTO

For the Index/photostat index search function.

29 STEREO SELECT

To select the audio track (STEREO1 audio and/or STEREO2 audio) on a tape which was recorded in the 12bit audio mode. During playback, each time the button is pressed, the sound changes as follows:



- The audio track cannot be selected during the playback of a tape recorded in the 16bit audio mode.
- When INPUT SELECT is set to DV IN, the audio track can be selected by STEREO SELECT at any time: It does not have to be during playback.

30 VCR1/2/3

To select the remote control mode. The selected mode appears on the remote controller display.

- VCR1: Set this position on both the VCR and remote controller for normal use with one VCR.
VCR2: Set this position when using two Panasonic VCRs.
VCR3: Set this position when using three Panasonic VCRs.


Note:

While in the editing mode the VCR's Time code or tape counter display cannot be changed.


Remote Controller Setup

Installing the Batteries

- 1 To remove the cover, slide it in the direction of the arrow while pressing down.



- 2 Load the batteries with their polarity (+ and -) aligned correctly.



- 3 Slide the cover back on.

Power Source for the Remote Controller

The remote controller is powered by 2 AA, UM3 or R6 size batteries. The life of the batteries is about one year, although this depends on the frequency of use.

Precautions for Battery Replacement

- Load the new batteries with their polarity (+ and -) aligned correctly.
- Do not apply heat to the batteries, or an internal short-circuit may occur.
- If you do not intend to use the remote controller for a long period of time, remove the batteries and store them in a cool, dry place.
- Remove spent batteries immediately and dispose of them.
- Do not use an old and a new battery together, and never use an alkaline battery with a manganese battery.
- Do not use rechargeable batteries.


Editing Controller Set Up

Installing the Batteries

- 1 To remove the cover, slide it in the direction of the arrow while pressing down.



- 2 Load the batteries with their polarity (+ and -) aligned correctly.



- 3 Slide the cover back on.

Power Source for the Editing Controller

The editing controller is powered by 2 AA, UM3 or R6 size batteries. The life of the batteries is about one year, although this depends on the frequency of use.

Precautions for Battery Replacement

- Load the new batteries with their polarity (+ and -) aligned correctly.
- Do not apply heat to the batteries, or an internal short-circuit may occur.
- If you do not intend to use the editing controller for a long period of time, remove the batteries and store them in a cool, dry place.
- Remove spent batteries immediately and dispose of them.
- Do not use an old and a new battery together, and never use an alkaline battery with a manganese battery.
- Do not use rechargeable batteries.


Operating the Editing Controller

The Editing controller can be operated in any of the following 3 ways:

- It can be operated while remaining attached to the main unit.
- Its batteries can be loaded, and it can be separated from the main unit and operated as the remote controller.
- It can be separated from the main unit, connected using the accessory controller cable and operated as the remote controller.


How to separate the editing controller

While pressing the buttons at the left and right of the main unit's front panel, remove the editing controller with both hands.



How to attach the editing controller

Push down on the editing controller until the areas around the left and right buttons on the unit's front panel click into position.



When connecting the editing controller to the video unit using the controller cable

- 1 Remove the cover over the controller socket on the rear panel of the editing controller, and insert the plug at one end of the editing controller cable into this socket until it clicks into position.



- 2 Remove the modular cap over the unit's controller socket, and insert the plug at the other end of the editing controller cable into this socket until it clicks into position.



When using the editing controller as a remote controller

As a remote controller, the editing controller can be operated at a distance up to about 3 m in front and up to an angle of up to about 30 degrees to the left or right of centre. (This range changes in accordance with the ambient brightness.)

Note:

When the VCR's remote control mode has been switched, switch the remote control mode on the editing controller as well.

Setting the Remote Controller to Operate Your TV

This setting procedure allows you to operate the TVs of some manufacturers using the supplied remote control transmitter.

Preparation

Turn on the TV.

Operations

- 1 Keep **TV-SET** pressed for more than 2 seconds.

Display Symbols

TV-SET



- 2 Press **OFF** several times.

OFF



- When the number matches the manufacturer of your TV, the TV's power is turned off. Read through the information on the following page as well.

- 3 Press **TV-SET**.

TV-SET



- The remote controller display changes as shown.

How to change the number

Each time the "+" side of **OFF** is pressed, the number is counted up by one as follows:

1 → 2 → 3 ... 30

When the "-" side of **OFF** is pressed, the number is counted down by one in the reverse order to that indicated above.

Notes:

- If you are using a Panasonic TV, this setting has already been made, and so you do not need to perform the above setting procedure. However, this remote controller may not work with some Panasonic TVs.
- Some TV models cannot be operated using this remote controller.
- This VCR remote controller is not designed to select all AV positions of some TVs. Use your TV remote controller to select some AV positions.

21pin-Phono Transformer Adaptors



1 21pin-Phono Transformer Adaptor (Output)

Inserting this adaptor into AV1 allows it to be used as the Phono Audio/Video output socket.

VIDEO: To connect the video cable to a TV or another VCR.
AUDIO(L/MONO, R): To connect the audio cable to a monitor or another VCR.

2 21pin-Phono Transformer Adaptor (Input)

Inserting this adaptor into AV1 or AV2 allows it to be used as the Phono Audio/Video input socket.

VIDEO: To connect the video cable to a TV or another VCR.
AUDIO(L, R): To connect the audio cable to a monitor or another VCR.

Manufacturer	Number
Panasonic	01-04
BLAUPUNKT	05
BRANDT	15
BUSH	06
CURTIS	06
DUAL	06
ELEMIS	06
FERGUSON	09-12, 14, 15
GOODMANS	06, 09-12, 14, 15
GRUNDIG	05
HITACHI	17, 18, 29, 30
ITT	21
JVC	27
LOEWE	06
METZ	06
MITSUBISHI	28
MIVAR	23
NOKIA	21, 22
NORDMENDE	15
PHILIPS	06
PYE	06
RADIOLA	06
SABA	09, 11, 12, 14, 15
SALORA	22
SAMSUNG	06, 20
SANYO	25
SEB	06
SELECO	21
SHARP	26
SIEMENS	05, 19
SONY	07
TELEFUNKEN	09-16
THOMSON	09-11, 14, 15
TOSHIBA	24

Inserting the Cassette

- 1 Press OPEN/CLOSE.
• The front panel opens.



- 2 Press OPEN/CLOSE again.
• The cassette tray is extended.



- 3 Align the cassette with the cassette guide and place it on the tray while ensuring that the side of the cassette with the tape exposed is facing up and the label side is turned toward you.

Mini Cassette



Standard Cassette




- 4 Press OPEN/CLOSE.
• The cassette tray is retracted inside the video unit.

Connections and Settings Without Using a 21-Pin Scart Cable

1 Connections

The VCR sends signals to the TV via an RF coaxial cable (supplied).

Make the connections shown in the figure below.




2 Settings

Setting a VCR channel on your TV allows you to view the video picture on your TV in the same way that you watch TV broadcasts. Once the **Country** setting is completed, the VCR automatically searches for TV stations and sets the clock. (This is known as Auto Setup.)

Preparation

Turn on the TV and VCR.



1-21

Operations

- 1 Keep **MENU** pressed for 5 seconds or more.
 - Hold down the button until "Ch" appears in the VCR display.

- 2 Set the TV to an unused position which you wish to use for your video playback.

- Tune the TV until the test pattern appears on the screen. Consult the operating instruction of your TV to find out how to tune it.
- The initial setting of the RF output channel is 35ch.

On Screen Display



(Test Pattern)

- 3 Press **OK** to exit the Test Pattern screen. The **Country** setting screen appears.

Country	Country
Belgium	Denmark
Belgium	France
Belgium	Germany
Belgium	Italy
Belgium	Netherlands
Belgium	Spain
Belgium	Sweden
Belgium	Switzerland
Belgium	United Kingdom
Belgium	USA

- 4 Select the desired country. Auto Setup (auto tuning and auto clock settings) then starts automatically.



To Reset Auto Setup:


Press **EXIT**, then disconnect and reconnect the power source.

The **Country** setting screen will appear on the screen.

Repeat the operations from step 3.

Notes:

- The Auto Setup searches for TV stations from VHF minimum to UHF maximum and stores the data for every programme position. The other programme positions are skipped.
- The Auto Setup takes five minutes or more to search for the TV stations and set the clock.
- If VCR is not set correctly by Auto Setup, see Various Settings on pages 39-42.
- Auto clock setting will not work correctly if teletext information is not available. If the clock setting screen appears after auto tuning has been completed, set the clock manually. Refer to steps 3-5 on page 42.




To Change the RF Output Channel (using the remote controller):

In some rare cases after Auto Setup, interference may be visible on the picture. To avoid interference, you can manually adjust the RF output channel a few steps up or down from the current setting.


Operations

- 1 Turn on the TV and VCR.
- 2 Keep **MENU** pressed for 5 seconds or more.
 - Hold down the button until "Ch" appears in the VCR display.
- 3 Enter the desired channel number (21-69) by using the numeric buttons or ∇ \blacktriangle of the remote controller.
 - Be sure that the VCR/TV switch is set to VCR.
 - Set the RF output channel of the VCR to "—" (RF OFF) when the VCR is connected to the TV via the 21-pin scart cable.

Press the "0" numeric button or ∇ \blacktriangle to display "—".



- 4 Press **OK** to finish the setting mode.
 - Retune your TV to the new channel for the VCR.
 - After the **Country** setting is set, the **Country** setting screen will not be displayed even if the RF output channel is changed and **OK** is pressed.




Set the VCR/TV switch to VCR.

To Check the Settings for Auto Setup:

Use the following procedure to check that the settings for Auto Setup are set correctly.

Operations

- 1 Press **MENU** and select Tuning.



- 2 Select **Manual**.

Pos.	Name	Ch	Pos.	Name	Ch
1	ARD	1	11	ORF	35
2	ZDF	2	12	RTL	4
3	MDR	10	13	SWR	6
4	HRF	20	14
5	BR3	10	15
6	PRO	3	16
7	SRG	20	17
8	SWD	20	18
9	MDR	17	19
10	MDR	22	20

- 3 Looking at the On Screen Display, check that the settings for Auto Setup are set correctly.
 - The desired TV stations have all been displayed and are set in the correct order, Auto Setup is completed. If the TV stations have not been correctly entered and set, perform the manual setting procedure on page 39. Press **EXIT** to exit the On Screen Display.

Note:

Manual tuning is required when there is a * mark at the beginning of the station name display, even if the station name is displayed. See page 40.

Connections and Settings Using a 21-Pin Scart Cable


1 Connections

The VCR sends signals to the TV via a 21-pin scart cable (sold separately).

When connecting the VCR to a TV with the "Q Link", "DATA LOGIC", "NEXTVIEWLINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo, the fully-wired 21-pin scart cable should be used in Step 3. If this cable is not used, the "Preset Download" and "Direct TV REC" functions will not operate. (See pages 25 and 30.)


Make the connections as shown in the figure below.
After making these connections, one of several setting methods is performed.

Type of TV set that you have	Setting method
TV with the "Q Link" or "DATA LOGIC" logo	TV has not been preset. Turn on the TV first. Perform Tuner setup as described in the TV operating Instructions. Download from TV starts and ends automatically.
	TV has already been preset. Go to page 25.
TV with the "NEXTVIEWLINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo	TV has not been preset. Turn on the TV first. Perform Tuner setup as described in the TV operating Instructions. Download from TV starts and ends automatically. When Preset Download has finished, select your country (see page 46), and then restart Download (see page 41).
	TV has already been preset. Go to page 25.
Cases other than the one above	Go to page 23.



Connection to a Decoder

In addition to the connections described on the previous page, connect the AV2 socket to the decoder using a 21-pin scart cable.



Notes:

- If the TV set is provided with an RGB-compatible connector, connect the 21-pin AV cable from the VCR to this connector. Use the fully-wired 21-pin scart cable for connecting the TV set and VCR and for connecting the VCR and decoder.
- Set the RF output channel of the VCR to "—" (RF OFF) when the VCR is connected to the TV via the 21-pin scart cable. See page 20.
- AV2 must first be set to **DECODER** when the decoder is connected to the AV2 socket. (See page 45.)

AV LINK

With this button, the connected colour TV set can be switched from TV mode to VCR mode (and vice versa) when it is connected by means of 21-pin scart cable. This makes a variety of functions possible, such as simultaneous recording and viewing when a Pay TV decoder or a satellite receiver has been connected.

VCR mode (VCR indicator lights up):

To enjoy sound and pictures from the VCR.

- When **MENU**, **SET UP** or **EDIT MENU** is pressed and the OSD (On Screen Display) screen is displayed, the unit also automatically switches to VCR mode. However, if the unit is originally in TV mode, the VCR indicator is not displayed.
- The unit also automatically switches to VCR mode when playback is started. However, the unit cannot be returned to TV mode during playback.

TV mode (VCR indicator goes off):

- To watch another programme on the TV while recording on the VCR.
- Select the programme to be watched using the TV set's tuner.
- The sound and pictures of a different channel are received by the VCR.

	VCR	TV set
Power On	VCR mode TV mode	AV input selected Input from TV set's tuner
Power Off	—	Input from TV set's tuner

*When the VCR is set to the TV mode and the Pay TV channel is selected, the signals will still be scrambled even when Pay TV is selected by the TV set's tuner. In this case, either set the VCR to the VCR mode or switch the TV set's input signals to AV input.


2 Settings

Auto Setup

This setting is used when the VCR is not connected to a TV with the "Q Link", "DATA LOGIC", "NEXTVIEWLINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo using a fully-wired 21-pin scart cable. The VCR automatically searches for TV stations and sets the clock. (This is known as Auto Setup.)

Preparation


Turn on the TV and VCR.



Set the VCR/TV switch to VCR.

The Country setting screen appears.

Select the desired country.



Country	On Screen Display
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch
Belgium	Dutch

- Auto Setup (Auto tuning and Auto clock setting) starts automatically.



To Reset Auto Setup:

Press EXIT, then disconnect and reconnect the power source. The Country setting screen will appear on the screen.

Notes:


- The Auto Setup searches for TV stations from VHF minimum to UHF maximum and stores the data for every programme position. The other programme positions are skipped.
- The Auto Setup takes five minutes or more to search for TV stations and set the clock.
- If VCR is not set correctly by Auto Setup, see Various Settings on pages 39-42.
- Auto clock setting will not work correctly if teletext information is not available. If the clock setting screen appears after auto tuning has been completed, set the clock manually. Refer to steps 3-5 on page 42.
- If you change the tuning details of the TV after Auto Setup has been performed on the VCR, the new information may be automatically downloaded to the VCR, and the input content of Auto Setup may be erased. If this happens, repeat Auto Setup.

To Check the Settings for Auto Setup:

Use the following procedure to check that the settings for Auto Setup have been correctly made.

Operations

- Press MENU and select Tuning.



Menu	Manual
Play	Auto Setup/Restart
Tuning	Download
Clock	Shipping condition
Font/Size	
Language	
Country	

- Select Manual.




Pos.	Name	Co.	Pos.	Name	Co.
1	AFD	1	11	GRB	35
2	ZDF	2	12	RTL	4
3	MDR3	13	13	SWT	3
4	HRS	26	14	----	----
5	BRD	16	15	----	----
6	RAB	3	16	----	----
7	BFB	36	17	----	----
8	DRS	20	18	----	----
9	WDR	17	19	----	----
10	MDR	32	20	----	----

- Looking at the On Screen Display, check that the settings for Auto Setup are set correctly. If the desired TV stations have all been displayed and are set in the correct order, Auto Setup is completed. If the TV stations have not been correctly entered and set, perform the manual setting procedure on page 39. Press EXIT to exit the On Screen Display.

Note:

Manual tuning is required when there is a * mark at the beginning of the station name display, even if the station name is displayed. See page 40.

The "Q Link" functions



Set the VCR/TV switch to VCR.

When the VCR is connected to a TV with the "Q Link", "DATA LOGIC", "NEXTVIEWLINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo using a fully-wired 21-pin scart cable, you can use the "Q Link" functions.

The following Q Link functions are available.

- Preset Download**

When the VCR is connected to the TV, the station list data will be copied from the TV to the VCR, and the TV channels will be preset on the VCR. See page 25.

- Direct TV REC**

This function allows you to immediately record the programme you are watching on the TV at the moment by simply pressing DIRECT TV REC. See page 30.

- TV/VCR Auto Power On**

(This function is only available when the VCR is connected to a TV with the "Q Link" or "DATA LOGIC" logo.) Even if the TV or VCR is in the standby mode, the TV and VCR will automatically turn on when one of the buttons [▶] (PLAY) or [CHECK] is pressed. When a cassette with the opened record prevention tab is inserted into the VCR, the VCR starts up and automatically begins playback. The TV also turns on.

- VCR Auto Power Off**

(This function is only available when the VCR is connected to a TV with the "Q Link" or "DATA LOGIC" logo.)

Turning the TV off will also turn the VCR off. However, this operation works only when the VCR has been set to Rewind or Stop mode, or there is no tape inside.

- If the Power Off command is received while the VCR is rewinding the tape, the VCR will not turn off until rewinding is completed.
- This operation does not work when settings are being made. (Download, Auto Setup, Auto Clock Setting, Manual Search)


- TV On Screen Display Message**

(This function is only available when the VCR is connected to a TV with the "Q Link" or "DATA LOGIC" logo.) With this function, VCR messages appear on the TV screen even in the TV mode.

Message	Conditions when message appears
This programme has already started	Timer recording is starting.


Note:

Depending on the TV, the message may not appear correctly.



1-24

When the VCR is connected to the TV, the station list data will be copied from the TV to the VCR, and the TV channels will be preset on the VCR.
This function is known as "Preset Download".



Applicable to TVs with the "Easy Link", "Megalogic" and "SMARTLINK" logo:
The Country setting screen appears when the VCR is turned on after being connected to the TV using the fully-wired 21-pin scart cable.
Select the desired country.



On Screen Display	
Country	
Belgë	Deutschland
Belgique	Österreich
België	Portugal
Dänemark	Suomi
España	Sverige
France	Schweiz
Italia	Estónia
Nederland	Schizaria
Norge	others



- Applicable to TVs with "Q Link" and "DATA LOGIC":**
 If the VCR is connected to a TV with the "Q Link" or "DATA LOGIC" logo, the "Download" screen appears, and downloading begins immediately.

Download in progress, please wait.
Position 57

- Note:**
Download will only work when the VCR is connected to a TV with the "Q Link", "DATA LOGIC", "NEXTVIEWLINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo using a fully-wired 21-pin scart cable.
When this condition is not met, Auto Setup will be executed.
(See page 23.)

Note:

Technical drawing of a truck chassis. A large rectangular box, labeled with the number '1', is mounted on the frame between the front and rear axles. The drawing shows various mechanical components, including the engine, transmission, and suspension parts.



- Set the VCR/TV switch to VCR.

Display Symbols


-

- 

- 

-


1. The first step is to identify the problem.

- 


- 7** Press **□ (STOP)** to stop the picture.

If you keep ►► (FAST FORWARD) or ◀◀ (REWIND) pressed in step 3 or 4, search playback is activated while the button is pressed, and operation returns to normal playback when the button is released.

Other Playback Functions




1-25



To Change the Playback Speed

- 1 Press JOG/SHUTTLE on the remote controller or the editing controller.
 - The button on the editing controller is lit.
- 2 Rotate Shuttle Ring.



To Locate the Desired Picture Exactly

- 1 Press JOG/SHUTTLE on the remote controller or the editing controller.
 - The button on the editing controller is lit.
- 2 Turn Jog dial.



To View the Video During Fast Forward or Rewind

Keep ►►► (FAST FORWARD) pressed during fast forward.
Keep ◄◄◄ (REWIND) pressed during rewind.



To Return to a Specified Scene

- After playback, press ZERO STOP in the stop mode.
- The tape will be rewound or fast forwarded to 0:00.00 approximately.
 - During Time code display, this function will not work.

Automatic Playback

When a cassette with the opened record prevention tab is inserted, the VCR starts playback automatically.

VCR-off Playback

When the VCR is off, an inserted cassette can be played back by pressing ► (PLAY).

Automatic Rewinding



When the tape reaches the end during recording (except for timer recording) or playback, it will automatically be rewound to the beginning.

- During OTR, this function will not work.

Note:

Cue, review or slow playback will be automatically cancelled after 10 minutes, and still playback after 5 minutes.

Manual Recording



Operations

Display Symbols

- 1 Insert a video cassette with the closed record prevention tab (page 17).
 - If it has already been inserted, press VCR (POWER ON) to turn the VCR on.
- 2 Select the TV station using the ▼ and ▲ buttons.
 - It is also possible to select by pressing the numeric buttons.
 - Be sure that the VCR/TV switch is set to VCR.
- 3 Press REC (REC/OTR) to start recording.
- 4 Press □ (STOP) to stop recording.

To Select the Desired Tape Speed

Press SP/LP before recording.

To Pause Recording

Press PAUSE/SLOW during recording.
Press again to continue recording.

To Select the Desired Audio Mode

Perform the procedure below using the editing controller.

- 1 Press SET UP.


■ Using ▲▼, select Audio Mode and press OK.

3 Using ◄►, select 12bit or 16bit, then press OK.

For details, see Initial Settings for Editing on page 58.

To Record One TV Programme while Viewing Another Programme

After step 3, change to the TV channel of the programme you want to view.



Set the VCR/TV switch to VCR.

To Display the Remaining Tape Time

Press **DISPLAY** repeatedly until the Remaining Tape Time appears on the VCR display.



- The remaining tape time may not be displayed correctly for some tapes.

Recording Stereo and Bilingual Programmes

- 1 Recording is automatically made in the stereo and bilingual mode. This prevents errors in the selection of the dubbed or the original language.
- 2 During playback press **AUDIO OUT** to select the desired sound mode. See page 8.

Notes:

- When a video cassette with the opened record prevention tab is inserted, the "REC" indication will flash to indicate that recording is not possible.
- The recording pause mode will be automatically cancelled after 5 minutes and return to the stop mode.

The NICAM Broadcast System


AG-DV2700 is also equipped with the NICAM sound system.

NICAM is a 2 Channel sound broadcast system that provides either a high quality stereo sound track or 2 independent MONO sound tracks, M1 and M2. NICAM programmes are always accompanied by standard sound broadcasts and you can select the desired sound with **AUDIO OUT** during playback.

- To record the regular sound (ordinary normal sound) on the FM audio tracks when a Stereo, Bilingual or NICAM programme is received, select **Mono ON** during manual tuning procedure. See page 40.

Important Note for the NICAM System


When AG-DV2700 is switched on, the tuner will automatically switch to a NICAM broadcast, if NICAM is being transmitted. During test transmissions, it is possible that the sound received doesn't correspond to the picture being viewed. In order to receive a synchronized sound and picture, select **Mono ON** setting. This will only apply until NICAM transmissions are fully operational. Even if the sound track is in MONO, the stereo indicator will appear.



One-Touch Recording (OTR)

This function only works using REC/OTR on the VCR main unit.

After you start recording, you can use this function to stop recording automatically when the programme is finished (useful for recording when you are out). Simply set the recording duration by pressing **REC/OTR** repeatedly. The duration indicated on the VCR display changes by pressing **REC/OTR** as follows:



Preparation


Insert a video cassette with the closed record prevention tab.

Operations

- 1 Set the video source which is to be recorded, and start recording.
- 2 Press **REC/OTR** repeatedly to select the desired recording duration.
 - The VCR will automatically switch off when OTR is completed. To turn the VCR on again, press **VCR** (POWER ON).

Notes:

- The OTR function works during normal recording or Direct TV REC.
- When the tape reaches the end during OTR, the VCR will turn itself off.
- To stop OTR at any time, press **STOP** or **VCR** (POWER ON).



Direct TV REC

This function allows you to immediately record the programme you are watching on the TV at the moment by simply pressing **DIRECT TV REC**.

However, this function works only when this VCR is connected to a TV with the "Q Link", "DATA LOGIC", "NEXTVIEW LINK", "Easy Link", "Megalogic", "SMARTLINK", or other logo using the fully-wired 21-pin scart cable.

Preparation

Insert a video cassette with the closed record prevention tab.

Operation

When you are watching TV and you want to record the programme immediately, press **DIRECT TV REC** on the VCR main unit or remote controller.

The recording will start.

- It is not necessary to adjust the programme position of your VCR to the TV station that you are watching now.

Notes:

- Even if the programme positions are not the same, the programme position of the VCR switches to the same position of the TV. When recording is finished, the programme position of the VCR returns to the previous position.
- Do not press **AV LINK** during Direct TV REC. Recording may not be performed normally.
- In some cases, it may not be possible to change the TV channel during Direct TV REC.
- Check beforehand whether the tape may be used for recording.

Timer Recording

Timer Recording


This function allows you to record programmes automatically.

There are three ways to record programmes: ShowView programming, where you enter the ShowView number, and On Screen Display recording, where you enter the recording information yourself while viewing the On Screen Display.

ShowView Programming


Programming is now easier than ever: simply enter the ShowView number provided in the programme schedule carried by newspapers and magazines.

ShowView numbers are numbers which are assigned to each programme listed in the TV programme schedule carried in newspapers and TV guides. When these numbers are entered and TRANSMIT is pressed, the numbers are converted to the actual programming.



Preparations

- Insert a video cassette with the closed record prevention tab.
- Confirm that the TV is on and the VCR viewing channel is selected.




Follow the on screen operation guide.

Operations

- 1 Press **SHOWVIEW** and then enter a ShowView number using the numeric buttons.

Example: 920126



- If you have entered the wrong ShowView number, repeat step 1 with the correct ShowView number.

- 2 Press **TRANSMIT**.



Pos	Name	DATE	Start	Stop	SP	VPS
1	27th	10	18:00	19:30	SP	---
2	27th	10	19:30	21:00	SP	---
3	27th	10	21:00	22:30	SP	---
4	27th	10	22:30	24:00	SP	---

- The Programming data that you entered also appears on the VCR display.
- To extend the ending time or to make any corrections, use Δ ∇ \leftarrow \rightarrow or VPS/PDC.
- See page 35 for VPS/PDC recording.

If "—" appears in the programme position: Use Δ or ∇ to select the programme position of your VCR which receives the required TV station.

Pos	Name	DATE	Start	Stop	SP	VPS
1	27th	10	18:00	19:30	SP	---
2	27th	10	19:30	21:00	SP	---
3	27th	10	21:00	22:30	SP	---
4	27th	10	22:30	24:00	SP	---

- A message appears on the On Screen Display for the first few seconds.
- \blacksquare flashes as a warning on the VCR display.
- Once programming is performed after the programme position has been selected here, the guide channel will be automatically stored so that the correct position will appear when the ShowView code for this station is next entered.


- 3 Press **OK** for confirmation.

- 4 Press **TIMER REC** to activate timer recording.
 - Check that \blacksquare is lit on the VCR display. If it is flashing, check the timer recording details again. (See page 34.)

Notes:

- To select the desired tape speed, press SP/LP in step 1.
- To cancel standby mode, press **TIMER REC**.
- When the ShowView number is used for programming, the recording time may be slightly longer than the actual programme time.
- When programming the recording of two or more programmes, repeat steps 1-3.
- The procedures for checking, modifying and cancelling a timer programme are the same as on page 34.

Using the Remote Controller



Preparations


- Insert a video cassette with the closed record prevention tab.
- Confirm that the TV is on and the VCR viewing channel is selected.

For Example:

Programme position (channel): 2
 Date: 27th October
 Starting time: 20:00
 Ending time: 21:00
 (Present date: 16th October)

Operations

- 1 Set the programme position (channel) to "2".



- 2 Set the date to "27/10".




- 3 Set the starting time to "20:00".



- When it is kept pressed, the indication changes in 30-minute intervals.

- 4 Set the ending time to "21:00".



- 5 Press **TRANSMIT**.



Pos	Name	DATE	Start	Stop	SP	VPS
1	27th	10	18:00	19:30	SP	---
2	27th	10	20:00	21:00	SP	---
3	27th	10	21:00	22:30	SP	---
4	27th	10	22:30	24:00	SP	---

- To release from the standby mode, press **TIMER REC**.
- See page 35 for VPS/PDC recording.
- To make a change to what has been programmed (for instance, to change VPS/PDC to ON or OFF), follow the procedure for On Screen Display Programming. (See page 33.)

Note:

To select the desired tape speed, press SP/LP in any of steps 2-4.

Weekly Timer Recording

In step 2, select the desired day by pressing **DATE** (—).
 (SU=Sunday, MO=Monday, TU=Tuesday, WE=Wednesday, TH=Thursday, FR=Friday, SA=Saturday)

Daily Timer Recording

For this timer function, several groups of days can be selected.

- (A) Daily recording from Monday to Friday (MO-FR)
 - (B) Daily recording from Monday to Saturday (MO-SA)
 - (C) Daily recording from Sunday to Saturday (SU-SA)
- In step 2, select the desired days by pressing **DATE** (—).

Timer Recording from External Signal Source

If Timer Recording is performed by a unit connected to AV1 (TV), AV2(EXT/DECODER) socket or AV3 (Audio/Video/S-Video input sockets), select A1, A2 or A3 for the programme position.

- A1: Through the AV1 (TV) socket.
- A2: Through the AV2 (EXT/DECODER) socket.
- A3: Through the AV3 (AUDIO IN/VIDEO IN/S-VIDEO IN) sockets on front panel.

- Timer Recording is not possible if DV IN is set to the programme position.

Using On Screen Display


Up to 8 timer programmes can be recorded up to one month in advance by setting the timer, including weekly and daily programmes.

Preparations

- Insert a video cassette with the closed record prevention tab.
- Confirm that the TV is on and the VCR viewing channel is selected.

For Example:

Programme position (channel): 2
Date: 27th October
Starting time: 20:00
Ending time: 21:00
(Present date: 16th October)



Set the VCR/TV switch to VCR.

Follow the on screen operation guide.

Operations

1 Press CHECK.


2 Select the unoccupied position, and then press OK.



On Screen Display

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

3 Set the programme position (channel) to "2".



Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

4 Set the date to "27/10".



Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						


5 Set the starting time to "20:00".



Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						


- When it is kept pressed, the indication changes in 30-minute intervals.

6 Set the ending time to "21:00".



Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

7 Select the desired Tape speed (SP/LP).



Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

8 Set VPS/PDC to ON or OFF (---).

- See page 35 for VPS/PDC recording.

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						


9 Press OK for confirmation.

10 Press TIMER REC to activate timer recording.

- When the On Screen Display for programming timer recording turns off, the recording information is automatically sorted in the order of recording start times.
- Check that [] is lit on the VCR display. If it is flashing, check the timer recording details again. (See page 34.)

Note:

To cancel from the standby mode, press TIMER REC.



Set the VCR/TV switch to VCR.

Weekly Timer Recording

In step 4, select the desired day by pressing ▼.
(Su=Sunday, Mo=Monday, Tu=Tuesday, We=Wednesday, Th=Thursday, Fr=Friday, Sa=Saturday)

Daily Timer Recording

For this timer function, several groups of days can be selected.

- Ⓐ Daily recording from Monday to Friday (Mo-Fr)
 - Ⓑ Daily recording from Monday to Saturday (Mo-Sa)
 - Ⓒ Daily recording from Sunday to Saturday (Su-Sa)
- In step 4, select the desired days by pressing ▼.

Timer Recording from External Signal Source

■ Timer Recording is performed by a unit connected to AV1 (TV), AV2(EXT/DECODER) socket or AV3 (Audio/Video/S-Video input sockets), select A1, A2 or A3 for the programme position.

- A1: Through the AV1 (TV) socket.
- A2: Through the AV2 (EXT/DECODER) socket.
- A3: Through the AV3 (AUDIO IN/VIDEO IN/S-VIDEO IN) sockets on front panel.

- It is also possible to select by pressing INPUT SELECT.
- Timer Recording is not possible if DV IN is set to the programme position.

Setting other Programmes

Repeat steps 2-9 on page 33.

Checking a Timer Programme

Confirm that the TV is on and the VCR viewing channel is selected.

- 1 Press CHECK.
 - The On Screen Display may be distorted in the VPS/PDC recording standby mode.

- 2 Press CHECK or EXIT to exit the On Screen Display.

On Screen Display

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

Modifying a Timer Programme

- During timer recording, this operation will not work.
- Confirm that the TV is on and the VCR viewing channel is selected.

- 1 Press CHECK.

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

- 2 Select the desired timer programme.

- 3 Modify the programme, following the method described in steps 2-9 on page 33.

- 4 Press OK.

- 5 Press CHECK or EXIT to exit the On Screen Display.

Cancelling a Timer Programme

- During timer recording, this operation will not work.
- Confirm that the TV is on and the VCR viewing channel is selected.

- 1 Press CHECK.

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

- 2 Select the desired timer programme.


- 3 Press CANCEL.

Pos	Name	DATE	Start	Stop	SP	VPS
1						
2						
3						
4						
5						
6						
7						
8						

- 4 Press CHECK or EXIT to exit the On Screen Display.

Notes:


- If timer recording does not reach the end (due to insufficient tape or cancellation by the user), the programmed timer recording data will be erased from the memory by 4 a.m. the next day.
- Either the position number or the station name is displayed here.



- For daily and weekly timer recording, the recording time for only one recording session is displayed.

Checking the Remaining Tape Time

- This displays the remaining time for the inserted tape.



Remaining time indicator

- This indicator is not displayed unless the remaining tape time has already been indicated on the VCR display. Refer to page 29.

VPS (Video Programme System)/PDC (Programme Delivery Control)

The Video Programme System (VPS) or the Programme Delivery Control (PDC) is a very convenient system which assures that the TV programmes you have programmed for timer recording will be recorded exactly from beginning to end, even if the actual broadcasting time differs from the scheduled time due to delayed start or extension of the programme duration. Also, if a programme is interrupted and, for example, some special news is inserted, the recording will also be interrupted automatically and resumed when the programme continues. Depending on the signals sent from the broadcasting stations, the VPS/PDC system may not operate properly even when VPS/PDC has been set to ON. Please check with the broadcasters in your area for details.



- In the case of VPS/PDC recording, use the correct time (VPS/PDC time) for recording the TV programmes. Set VPS/PDC to OFF when the recording time is not the correct time (VPS/PDC time). VPS/PDC recording is not performed when the time (VPS/PDC time) is incorrect, even if only by one minute. To find out the correct time (VPS/PDC time), consult a newspaper or magazine, or other source.

- If the actual broadcasting times of timer recordings overlap (regardless of whether they are VPS/PDC controlled), the recording that starts first always has priority, and the recording of the later beginning programme will start only after the first timer recording has finished.
- When the VPS/PDC signal drops out because the broadcast signal is weak, or when a broadcasting station does not transmit a regular VPS/PDC signal, the timer recording will be performed in the normal mode (without VPS/PDC) even if it was programmed for VPS/PDC. In this case, even if the timer recording is performed, whatever has been programmed will not be cancelled at that particular time but at 4 a.m. on the following day.
- The start times of scheduled programmes listed in the newspaper or magazine may be changed at a later date. Set VPS/PDC to OFF when programming a programme whose start time has been subsequently changed. Particular care must be taken in this respect with ShowView programming since VPS/PDC is automatically set to ON in some countries.
- If a programme listed in a newspaper or magazine has two ShowView numbers, use the ShowView number for VPS/PDC if you wish to proceed with VPS/PDC recording using ShowView programming.
- The default settings for VPS/PDC differ depending on the country concerned. Refer to the table below.

Programming method	ShowView programming	Changes in ShowView programming start time	Non-ShowView programming
Selected Country			
France, Belgium, Netherlands, Sweden, Denmark, Finland, Norway	ON	OFF	OFF
Germany, Switzerland, Austria, other countries	ON	ON	ON
Italy, Spain, Portugal	OFF	OFF	OFF

- "—" appears for the VPS/PDC item at the outset if the broadcasting station is not transmitting VPS/PDC signals.

Search Functions



- For the reverse direction, press INDEX/PHOTO \lll .
- Up to 20 index signals can be searched for in either direction.
- When the opposite INDEX/PHOTO is pressed, the number shall be decreased until 1 is reached.
- The figure on the display is reduced by 1 each time an index signal is located.
- The INDEX search function can only work correctly if the index signals are spaced at least 5 minutes apart.
- Repeat the procedure if the index signal for the specified number is not found.

Recording Index Signals

Index signals are recorded in the following cases.

- When a recording is started by pressing REC (REC/OTR).
- When timer recording is activated.
- When REC on the remote controller or the editing controller is pressed during recording.


Photoshot Index Search System

Photo shot index signals are automatically recorded when a Panasonic Digital Video Camera is used for photo shot mode. Photo shot images are searched using these signals, and when such an image is located, the image is played back as a still picture.

For example:

Searching for the 2nd photo shot image in the forward direction.

- 1 Press SEARCH SELECT so that "P —" appears on the VCR display.

**Display Symbols**

- 2 Press INDEX/PHOTO \ggg twice.
 - The image to be viewed will be found.

- For the reverse direction, press INDEX/PHOTO \lll .
- Any of up to 20 images ahead on the tape can be designated.
- When the opposite INDEX/PHOTO is pressed, the number shall be decreased until 1 is reached.
- The figure on the display is reduced by 1 each time an index signal is located.
- It may not be possible to search for a particular image properly if photo shot images have been recorded continuously.
- At every press of the corresponding button, the tape is fast-forwarded or rewound to the next still picture recorded in the Photoshot Mode. After reaching the next still picture, the still picture is played back continually together with the sound (only for approx. 4 seconds).


Index Search System

It is easy to find the beginning of each recording because a special index signal is recorded at the start of each recorded segment on the tape.

For example:

Searching for the 2nd recorded segment in the forward direction.


- 1 Press SEARCH SELECT so that "—" appears on the VCR display. (This operation is performed while the VCR is in the stop mode or normal playback mode.)

**Display Symbols**

To stop the operation at any time
Press \square (STOP).


Using the VCR with a Video Printer

Still pictures can easily be printed out when the VCR is connected to a Panasonic video printer equipped with an EDIT socket.



Preparation

- Connect a video printer to this VCR as shown.



Video Printer:

- Turn the Video Printer on.
- Make the necessary settings on the Video Printer according to the input signal.

VCR:


- Turn the VCR on.
- Set EDIT CONTROL to PRINTER.
- Press D (PLAY).
- Search for the picture from which you would like to print, and then press PAUSE/SLOW.
- Press PRINT.

Notes:

- Read the operating instructions of the Video Printer.
- The OSD and DATE/TIME display are also printed out. If a picture without these displays is required, proceed as follows.
 - Set OSD on the VCR's Main menu to OFF.
 - Press DATE-OFF/ON on the remote controller or editing controller.
- Printing cannot be stopped at any point in time until it is completed.
- For printing, screens cannot be divided and the zoom function cannot be used.

Using the VCR with a Computer

The Personal Computer Connection Kit VW-DTA1E (Optional) for Digital Video Equipment makes it possible to connect the VCR to a computer and transmit still video images to it.



Computer System Requirements

DV STUDIO can be installed in a PC/AT personal computer which can run Microsoft® Windows® 95.

- Compatible machines:** Personal computer with 80486DX4 or higher CPU(Pentium™ or higher recommended)
- Graphic card:** True Color (approx.16.7million colours) recommended (operation also possible even with 256 colours)
- Installed memory:** 16 MB or more (32 MB or more recommended)
- Free hard disk space:** At least 10 MB
- Disk drive:** CD-ROM drive
- Serial port:** RS-232C (D-Sub 9pin)
- Other requirements:** Mouse

To connect the VCR to the computer, use the special Interface Adaptor contained in the Personal Computer Connection Kit.


- Pictures that you intend to import into a computer application should be recorded in the SP Mode.
- When recording, take care that the Time code is uninterrupted from the beginning of the tape.
- Windows® 95 is a trademark of Microsoft Corporation U.S.A.
- Pentium™ is a trademark of Intel Corporation.
- All other company and product names in the operating instructions are trademarks of their respective corporations.

Storing TV Stations into Your VCR

The VCR is fitted with its own tuner (just like a normal TV set) and can be pre-set to receive up to 99 TV broadcast stations. If VCR is not correctly tuned by Auto Setup, follow the procedure below.

Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Turn on the VCR.



Set the VCR/TV switch to VCR.

Manual Tuning Procedure

Follow the on screen operation guide.


When deleting stations, adding "blank" positions and changing (moving) the programme position:

These indications do not appear on the screen after performing Preset Download (Download).

- Press MENU and select Tuning.



- Select Manual.



- Select the desired programme position.

- Follow the steps indicated below.



- Delete: Press VPS/PDC (red) to delete the station.
- Add: Press SP/LP (green) to add a blank position.
- Move: Press DATE-OFF/ON (yellow) to change (move) the programme position.
- The blue indication represents no function.
- These indications do not appear after performing Preset Download (Download).

- Press OK, and then press EXIT.

Changing the Programme Position (Pos)

Follow 1 to 3 in the first procedure.

- Press OK and then select Pos.
- Be sure that the VCR/TV switch is set to VCR.




- Press OK to confirm.

- Press MENU, and then press EXIT.

Changing the Channel (Channel)

Follow 1 to 3 in the first procedure.

- Press OK and then select Channel.
- Be sure that the VCR/TV switch is set to VCR.



- Press OK to confirm.

- Press MENU, and then press EXIT.

Changing the Station name (Name)

Follow steps 1 to 2 on page 39.

- Select the station(s) name *□□□□.

Establish which channel you are viewing by checking your TV Guide/Newspaper.



On Screen Display

Pos	Name	Ch	Pos	Name	Ch
1	ARD	1	11	RTL	4
2	ZDF	2	12	RTL	4
3	MDR	10	13	RTL	4
4	HRD	20	14	RTL	4
5	BRD	18	15	RTL	4
6	BRD	5	16	RTL	4
7	BRD	17	17	RTL	4

- *□ indicates the position number or station name. This is the same as steps 4 and 5.


- Select Name.



Enter characters into all five *□□□□ positions from the table using the arrows and press OK after each character. Use a blank space if required. To enter a blank, select the area between Z and *.

- To cancel during entry, press EXIT.

The characters that have been entered will remain as the station name. Enter the correct station name as failure to do so may result in malfunctioning.



- Press MENU. If any other station names are marked *□□□□, repeat steps 3-5.

- Press EXIT.

Fine Tuning

Follow steps 1 to 3 on page 39.

- Press OK and then select Fine tuning.



- Press ▲ or ▼ to obtain the best tuning condition.
- To return the tuning to its former state (AUTO), press ►.

- Press OK to confirm.

- Press MENU, and then press EXIT.

Decoder

Follow steps 1 to 3 on page 39.

- Press OK and then select Decoder ON or Decoder OFF.
- To preset pay TV stations.
- To preset normal TV stations.



- Press OK to confirm.

- Press MENU, and then press EXIT.

Changing the Recording Sound (Mono)

Follow steps 1 to 3 on page 39.

- Press OK and then select Mono OFF.
- Select Mono ON to record the normal sound during a stereo, bilingual or NICAM broadcast or if the stereo sound is distorted due to inferior reception conditions.



- Press OK to confirm.

- Press MENU, and then press EXIT.

Notes:

- When channels have been set with Manual Tuning, the channel position will need to be entered the first time ShowView is used.
- If you change the tuning details of the TV after Manual Tuning has been performed on the VCR, the new information may be automatically downloaded to the VCR, and the input content of Manual Tuning may be erased. If this happens, perform VCR Auto Setup or Downloading and then repeat Manual Tuning.

Channel Plan

Channel Indication	Germany/Italy	Other Countries
2-12	*E2-E12	E2-E12
13-20	A-H (Only Italy)	-
21-69	21-69	21-69
74-78	S01-S05	S1-5
80-82	S1-S3	M1-M3
83-89	S4-S10	M4-M10
90-99	S11-S20	U1-U10
121-141 Hyperband	**S21-S41	S21-S41

*In Italy: H1...(11), H2...(12)

**Only for 8 MHz channel raster

- This channel plan has been designed for continental Europe, and may differ according to the region.

Auto-Setup Restart

When your address changes, follow the procedure below.

- Press **MENU** and select **Tuning**.



On Screen Display

- Select **Auto-Setup Restart** and press **OK**.



- Press **OK** again.


**Download**

To perform downloading again, follow the procedure below in the stop mode.


- Press **MENU** and select **Tuning**.



- Select **Download** and press **OK**.



- Press **OK** again.

**Shipping Condition**

If you want to return the VCR to the factory-preset condition, follow the procedure below.


- Press **MENU** and select **Tuning**.



- Select **Shipping condition** and press **OK**.



- Press **OK** twice.



Manual
Auto-Setup Restart
Download
Shipping condition

Note:


To re-tune the VCR, disconnect and then reconnect the mains lead.

Setting the Clock of Your VCR

The built-in clock is used to activate the timer for automatic recording and must be set to the correct time. The built-in digital clock employs the 24-hour system. If VCR is not correctly set by Auto Setup, follow the procedure below. The clock backup system operates for at least 60 minutes in the event of power failure.


Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Turn on the VCR.





- Check that the **Automatic** setting is **OFF**, then press **OK**.

- If the setting is **ON** when you open the On Screen Display, do not turn it **OFF**, as then you will not be able to set the time automatically.



- Set **Time and Date**.

- Press **←** to return to the previous item.



- Press **OK** to confirm.

- Press **EXIT**.

Note:

When the **Automatic** setting is **OFF**, the time may become incorrect. If this happens, reset it following the method described above.

Automatic Clock Setting

When "**Automatic**" is set to **ON**, the automatic time correcting function is activated every day.

The automatic time correcting function is only activated when the power is off.

This function is not activated during timer recording standby mode.

Note:


Even if "**Automatic**" is set to **ON**, if the time is incorrect, check first that the country has been selected correctly (see page 46), re-set "**Automatic**" to **ON** following step 2, then always press **OK**.

Manual Clock Setting


Follow the on screen operation guide.

Operations

- Press **MENU**, and then select **Clock**.



On Screen Display



Settings Using On Screen Display

The VCR indications shown on the TV screen are known as the On Screen Display (OSD). This VCR allows many settings to be made at the OSD.


Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Turn on the VCR and TV.

Display


Channel Guide

- Press MENU, and then select Display.




OSD

- Press MENU, and then select Display.



To use the On Screen Display:



TV station

Video system

STEREO, M1 or M2 Indicator

When receiving a TV programme with the Stereo, Bilingual or NICAM sound system, the type of sound system in which it is broadcast is automatically indicated.

STEREO: When receiving a Stereo/NICAM stereo broadcast.

M1/M2: When receiving a Bilingual/NICAM dual-sound broadcast.

M1: When receiving a NICAM monaural broadcast.

Audio Data Indicator

Audio Output Mode Indicator

The Left (L) and Right (R) indicators show which sound mode is selected with AUDIO OUT (see page 8).

Stereo: Both the L and R indicators appear.
Left: The L indicator appears.
Right: The R indicator appears.

Tape speed Indicator

Audio Monitor Indicator

STEREO1: 12bit STEREO1 sound
STEREO2: 12bit STEREO2 sound
MIX: STEREO1 and STEREO2 mixed sound

Tape running display

Stop, Eject	□
Rewind	◀◀
Fast Forward	▶▶
Playback	▶
Reverse Playback	◀
Reverse Slow Playback	◀
Slow Playback	▶
Still Playback, Pause	
Recording	●

Present time/Time code/Remaining tape time/ Tape counter/Index/Photoshot Index Search/ One-Touch Recording (OTR)

Present time	17:24:31
Time code	TC 0h25m32s04f
Remaining tape time	REMAIN: 1:16
Tape counter	-1:35.47
Index/Photoshot index Search	▶▶ ■
One-Touch Recording (OTR)	OTR 60

Index/Photoshot Index Search Indicator

Notes:


- When the item OSD is set to OFF, the On Screen Display will not appear.
- When the AV position (A1, A2, A3 or DV IN) has been selected or during playback, the On Screen Displays (1, 2, 3) do not appear.
- On Screen Display is not displayed when the SET UP or EDIT MENU screen is displayed.
- On Screen Display (2) is not displayed while playing a tape that was recorded in 16bit audio mode.
- When a wide-display TV is used as a monitor, parts of the On Screen Display may not be visible depending on the type of broadcast (16:9, PAL Plus) received.

VCR display


- 1 Press **MENU**, and then select **Display**.



- 2 Select **VCR display**.



- 3 Select **ON**, **OFF** or **DIMMED**.



ON: When VCR is turned off, the characters are lit in the VCR display.

OFF: When VCR is turned off, the characters are not lit in the VCR display.


DIMMED: When VCR is turned off, the characters are dimmed in the VCR display.

- 4 Press **EXIT** to exit the On Screen Display.

Functions

AV2

- 1 Press **MENU**, and then select **Functions**.



- 2 Select **AV2**.



- 3 Select **EXT** or **DECODER**.



EXT: When another VCR or a satellite receiver is connected to the AV2 (EXT/DECODER) socket.

DECODER: When the decoder is connected to the AV2 (EXT/DECODER) socket.


- 4 Press **EXIT** to exit the On Screen Display.

To Set the Colour Mode

- 1 Press **MENU**, and then select **Functions**.



- 2 Select **Colour mode**.



- 3 Select **COLOUR** or **B/W**.



COLOUR: When performing recording and playback in colour.

B/W: When performing recording and playback in black-and-white.

- 4 Press **EXIT** to exit the On Screen Display.

Note:


When **Colour mode** is set to **B/W**, the On Screen Display will be displayed in black-and-white.

Comb filter


- 1 Press **MENU**, and then select **Functions**.



- 2 Select **Comb filter**.



- 3 Select **ON** or **OFF**.



ON: Set to increase detail. Normally set to this position.

OFF: Set to reduce picture noise.

- 4 Press **EXIT** to exit the On Screen Display.

To Set the Remote mode

- 1 Press **MENU**, and then select **Functions**.



- 2 Select **Remote**.



- 3 Select **VCR1**, **VCR2** or **VCR3**.




This allows the remote controller to be set for operating VCR1, VCR2 or VCR3.

• When changing the remote control mode, press **VCR1/2/3** to change the remote control mode of the remote controller. If this is not done, it will not be possible to operate the VCR using the remote controller.

- 4 Press **EXIT** to exit the On Screen Display.

Language

- 1 Press **MENU**, and then select **Language**.



- 2 Select the desired language.



- 3 Press **EXIT** to exit the On Screen Display.

Country

- 1 Press **MENU**, and then select **Country**.



- 2 Select the desired country.



- 3 Press **EXIT** to exit the On Screen Display.

Editing Functions

Using this VCR, 4 types of **One-Touch-Edit**, 3 types of **Manual Editing** and 3 types of **Programme Editing** can be selected.

■ **Programme Editing**, after setting the edit start/end point, editing can be performed automatically. Edit programmes can be set up to 10 scenes for each editing function (40 scenes for Assemble editing).

One-Touch-Edit

- Assemble Editing (page 62)
- Insert Editing (Video, Audio, AV) (page 64)
- Audio Dubbing (page 64)
- Audio Mixing (page 66)

Manual Editing

- Copying (page 68)
- Insert Editing (Video, Audio, AV) (page 70)
- Audio Dubbing (page 72)

Programme Editing

- Assemble Editing (page 74)
- Insert Editing (Video, Audio, AV) (page 78)
- Audio Dubbing (page 82)

Copying

Allows the re-recording (copying) of the picture and sound from one tape onto another tape.



Performing the Copying operation on a tape that was recorded in 12bit audio mode.

Video Insert


Allows the partial replacement of the picture on a recorded tape. Sound is left in its original state.

Audio Insert

Allows the partial replacement of sound on a recorded tape. Picture is left in its original state.

AV Insert

Allows the partial replacement of the picture and sound on a recorded tape.



Performing the AV Insert editing operation on a tape that was recorded in 12bit audio mode.

Audio Dubbing

Allows the addition of the new sound on the STEREO2 track of a recorded tape. The original sound is left on the STEREO1 track.



Performing the Audio Dubbing operation on a tape that was recorded in 12bit audio mode.


Audio Mixing

Allows the mixing of the original sound on the STEREO1 track with the new sound from the external recording source and recording the mixed sound on the STEREO2 track of a recorded tape. The original sound is left on the STEREO1 track.



Assemble Editing

Allows the required scenes (picture and sound) to be picked up from a recorded tape and recorded in any desired order onto another tape.



Performing the Programme Assemble editing operation on a tape that was recorded in 12bit audio mode.

Creating the Tapes For Editing

In order to operate editing functions correctly, use these tapes for editing as follows:

- **Tape on which the picture and sound have been recorded properly for about 20 seconds prior to the edit start point:** [Playback unit] [Recording unit]
This VCR first rewinds the tape to the section prior to the edit start point and then commences editing. For this reason, accurate editing cannot be performed if the tape has been left blank or if the picture and sound have not been recorded properly for 20 seconds prior to the edit start point.
- **Tape on which the Time code has been recorded continuously:** [Playback unit] [Recording unit]
If the recording is broken up or if the tape is blank in places, the Time code will lack continuity, and editing will be aborted.
- **Tape which was recorded in SP mode:** [Recording unit]
(This applies to Insert, Audio Dubbing and Audio Mixing only.)
The above types of editing operations cannot be performed on a tape which was recorded in the LP mode.
- **Tape which was recorded in the 12bit audio mode:** [Recording unit]
(This applies to AV Insert, Audio Dubbing and Audio Mixing editing only.)
The above types of editing operations cannot be performed on a tape which was recorded in the 16bit audio mode.

When a tape which was recorded on another video recorder is used for Insert, Audio Dubbing or Audio Mixing editing operations, the sound may deteriorate and the picture may be disturbed.

If tapes answering to the above description are not available, proceed with dubbing by following the steps below to create the tapes for editing.


- 1 Load the original cassette tape into the playback unit and the new cassette tape into the recording VCR (the AG-DV2700).
- 2 Connect the playback unit and recording VCR (the AG-DV2700).
For the connection, use the DV cable when the contents of the original cassette are to be copied using their original digital signals, and use the AV cable when the contents are to be copied using the signals from the video and audio sockets.
(To dub a 16bit audio tape and make a 12bit audio tape, connect the units using the AV cables, and proceed with the dubbing.)
- 3 Check that **EDIT CONTROL** is at the OFF position.
- 4 Set the VCR's tape speed to **SP**.
- 5 Record a blank picture for about 20 seconds.
Set the playback unit to the stop mode, set **INPUT SELECT** on the recording VCR (the AG-DV2700) to A2 or A3, and start recording.
- 6 Switch over the input of the recording VCR (the AG-DV2700).
If the DV cable was used for the connection in step 2, switch over to "DV IN"; if the AV cable was used, switch over to A1, A2 or A3.
- 7 Press the play button on the playback unit to start playing the original tape.
- 8 Press **REC (REC/OTR)** on the recording VCR (the AG-DV2700) to start dubbing.

Notes:

- Digital copying using a DV cable yields a picture quality which undergoes hardly any deterioration at all.
- If a digital video tape is dubbed without connecting the DV cable, the original sub code data (Photoshot index signals, date information, etc.) will not be copied.
- The Time code is simultaneously recorded over the sub code of the tape when the tape is recorded. Also recorded in the sub code are the photoshot index signals, information on the recording date, etc.
For further details on the Time code, see page 92.


Connecting with a Digital Video Camera

Example for connecting Panasonic AG-EZ30 Digital Video Camera as the playback unit, when controlling the playback unit through the AG-DV2700.



Notes:

- Before connecting any cables, first make sure that the power for both units is off.
- Insert a recorded cassette into the playback unit, and a cassette with the closed record prevention tab into the VCR.
- If the playback unit is connected to the recording unit via an S-VIDEO cable, the video signal on the S-VIDEO cable takes priority. If the playback unit does not have an S-VIDEO socket do not connect the S-VIDEO cable to the AG-DV2700.
- If units are connected to the VIDEO input sockets on both the front and rear of this VCR, the rear video inputs are automatically switched off.
- Use of an AC adaptor as the power source for the Digital Video Camera is recommended. Doing so avoids a situation where the camera shuts down due to low battery power.
- It is recommended that the DV cable be disconnected for editing with INPUT SELECT set to A1-A3. If INPUT SELECT is set to A1-A3 with the connections shown in the figure left unchanged, the TV picture may be disturbed or noise may occur. (This has no effect on the actual editing operations.)
- When the units are connected using the DV cable and editing is performed, some editing functions will differ compared with when the units are connected using the AV cable. Refer to Glossary of Terms on page 92.
- When performing editing by connecting the units via a 21-pin scart cable, set the AV2 setting to EXT. See page 45.
- Read the operating instructions of the Digital Video Camera.
- Do not change the EDIT CONTROL or EDIT MODE settings while performing setting or editing operations at the SET UP or EDIT MENU screens. Be sure to quit these screens before changing these settings.
- When using a Panasonic Digital Video Camera as the playback unit, the following editing functions can be used by connecting the camera to the AG-DV2700 with just a DV cable:
Copying
Video Insert
Audio Insert
Assemble
In this case, simply set INPUT SELECT to DV IN, and set EDIT CONTROL to DV.
(This function may not operate properly with some models.)
- Use Time codes for Programme Editing when the playback unit is connected to the AG-DV2700 via only a DV cable.



Playback Unit (Digital Video Camera)

Recording Unit (the AG-DV2700)

- 1 Turn the power on.
- 2 Make the Time code appear on the LCD monitor or the viewfinder.
- 3 Prepare the tape for playback.

- 1 Turn the power on.
- 2 Set EDIT MODE to RECORDER.




- 3 Set EDIT CONTROL to EDIT.
- 4 Press INPUT SELECT on the editing controller so that DV IN is selected.
• When performing Audio Dubbing or AV Insert, select A2 or A3.

Connecting Two Digital Video Cassette Recorders (Both This Model)



Example for connecting two AG-DV2700s, when controlling the playback VCR through the recording VCR.

Refer to the diagram below and connect the cables required for the desired editing function.



Notes:

- Before connecting any cables, first make sure that the power for both VCRs is off.
- Insert a recorded cassette into the playback VCR, and a cassette with the closed record prevention tab into the VCR.
- When the units are connected using the DV cable and editing is performed, some editing functions will differ compared with when the units are connected using the AV cable. Refer to Glossary of Terms on page 92.
- Use Time codes for programme editing when the playback VCR is connected to the AG-DV2700 via only a DV cable.
- When performing editing by connecting the units via a 21-pin scart cable, set the AV2 setting to EXT. See page 45.
- It is recommended that the DV cable be disconnected for editing with INPUT SELECT set to A1-A3. If INPUT SELECT is set to A1-A3 with the connections shown in the figure left unchanged, the TV picture may be disturbed or noise may occur. (This has no effect on the actual editing operations.)
- If one of either the 21-pin scart cable or the AV cable is connected, it is not necessary to connect the other. If both cables are connected, electronic noise may be generated when the playback VCR and the recording VCR are in stop mode. Although this noise will not have any effect on the actual editing operations, if it does become annoying, set the INPUT SELECT on the playback VCR to a position for which no cable is connected.
- When the connections and setting are made as shown above, then :
 - The Timer recording On Screen Display cannot be displayed on the playback VCR.
 - The >(PLAY), >>(FAST FORWARD), REC (REC/OTR), and the other such buttons on the playback VCR or the remote controller cannot be used to control the playback VCR directly. In order to permit direct control, set EDIT CONTROL on the playback VCR to OFF.
 - Do not change the EDIT CONTROL or EDIT MODE settings while performing setting or editing operations at the SET UP or EDIT MENU screens. Be sure to quit these screens before changing these settings.
 - The following editing functions can be used by connecting the playback VCR with just a DV cable:
 - Copying
 - Video Insert
 - Audio Insert
 - Assemble
- In this case, simply set INPUT SELECT to DV IN, and set EDIT CONTROL to DV.



Playback VCR

- 1 Turn the power on.
- 2 Set EDIT MODE to PASSIVE.
- 3 Set EDIT CONTROL to EDIT.



Recording VCR

- 1 Turn the power on.
- 2 Set the EDIT MODE to RECORDER.
- 3 Set EDIT CONTROL to EDIT.
- 4 Press INPUT SELECT on the editing controller so that DV IN is selected.
 - When performing Audio Dubbing or AV Insert, select A2 or A3.



Controlling the Recording VCR through the Playback VCR

Follow the procedure described below:

- Connect the edit cable to the EDIT socket on both the playback VCR and the recording VCR.
- Use 21pin-scart cable or AV cables to connect the input sockets on the recording VCR with the output sockets on the playback VCR.
- Connect two TVs, one to each of the VCRs, so that the screens from both VCRs can both be seen.
- Set EDIT CONTROL on both the playback VCR and the recording VCR to EDIT.
- Press INPUT SELECT on the playback VCR and select a position to which a cable is not connected.
- Set EDIT MODE on both VCRs as follows:
 - Playback VCR : PLAYER
 - Recording VCR : PASSIVE




Notes:

- When this connection is made, the recording VCR cannot be controlled using the DV cable.
- Although noise may appear on the screen, depending on the connections, the noise has no effect on the actual editing operations.
- Audio Insert and AV Insert are not possible in this configuration.
- When performing editing with this connection, the editing accuracy may be worse than when controlled from the recording VCR.

Connecting an S-VHS (VHS) Video Equipment with an Edit Socket


Example for connecting an S-VHS (VHS) video equipment with an Edit socket as the playback unit, when controlling the playback unit through the recording VCR (this unit).

Refer to the diagram below and connect the cables required for the desired editing function.




Notes:

- Before connecting any cables, first make sure that the power for both units is off.
- Insert a recorded cassette into the playback unit, and a cassette with the closed record prevention tab into the VCR.
- If the playback unit is connected to the recording unit via an S-VIDEO cable, the video signal on the S-VIDEO cable takes priority. If the playback unit does not have an S-VIDEO socket do not connect the S-VIDEO cable to the AG-DV2700.
- If units are connected to the VIDEO input sockets on both the front and rear of this VCR, the rear video inputs are automatically switched off.
- When performing editing by connecting the units via a 21-pin scart cable, set the AV2 setting to EXT. See page 45.
- If one of either the 21-pin scart cable or the AV cable is connected, it is not necessary to connect the other. If both cables are connected, electronic noise may be generated when the playback VCR and the recording VCR are in stop mode. Although this noise will not have any effect on the actual editing operations, if it does become annoying, set the INPUT SELECT on the playback VCR to a position for which no cable is connected.
- Read the operating instructions of the playback unit.
- Do not change the EDIT CONTROL or EDIT MODE settings while performing setting or editing operations at the SET UP or EDIT MENU screens. Be sure to quit these screens before changing these settings.
- When using this VCR as the recording VCR and performing editing by connecting the units via the AV cable or a 21-pin Scart cable, the On Screen Display (date/time, Time Code) may scroll vertically when still playback or slow playback are performed by the playback VCR.



Playback Unit (S-VHS (VHS) Video Equipment with an Edit socket)

- 1 Turn the power on.
- 2 Set the unit so that it is ready to be controlled.
 - Read the operating instructions of the playback unit and make the necessary settings.



Recording VCR (the AG-DV2700)

- 1 Turn the power on.
- 2 Set EDIT MODE to RECORDER.




- 3 Set EDIT CONTROL to EDIT.
- 4 Press INPUT SELECT on the editing controller so that A3 is selected.
 - If the playback unit is connected to the external input on the rear of the AG-DV2700, select A2.

Connecting the AG-DV2700 as the Playback VCR to an S-VHS (VHS) VCR

Follow the procedure described below.


- Connect the edit cable to the EDIT socket on both the playback VCR and the recording VCR.
- Use 21pin-scart cable or AV cables to connect the output sockets on the AG-DV2700 with the input sockets on the S-VHS (VHS) VCR.
- Connect two TVs, one to the AG-DV2700 and one to the S-VHS (VHS) VCR, so that the screens from both VCRs can both be seen.
- Set EDIT CONTROL on the AG-DV2700 to EDIT.
- Set EDIT MODE on the AG-DV2700 to PLAYER.
- Press INPUT SELECT on the playback VCR and select a position to which a cable is not connected.
- Make the necessary editing control settings for the S-VHS (VHS) VCR. (Read the operating instructions of S-VHS (VHS) VCR.)



Note:
Audio Insert and AV Insert are not possible in this configuration.


Connecting a Video Equipment with a LANC Socket

Example for connecting another manufacturer's video equipment with a LANC terminal (L control) as the playback unit, when controlling the playback unit through the VCR.




Notes:

- Before connecting any cables, first make sure that the power for both units is off.
- Insert a recorded cassette into the playback unit, and a cassette with the closed record prevention tab into the VCR.
- The AG-DV2700 cannot be controlled through video equipment with a LANC socket.
- Some types of LANC sockets have a different shape to the LANC socket on the AG-DV2700.
- If an attempt is made to perform an operation through the AG-DV2700 that the playback unit does not support, the unit may operate incorrectly.
- If the playback unit is connected to the recording unit via an S-VIDEO cable, the video signal on the S-VIDEO cable takes priority. If the playback unit does not have an S-VIDEO socket do not connect the S-VIDEO cable to the AG-DV2700.
- If units are connected to the VIDEO input sockets on both the front and rear of this VCR, the rear video inputs are automatically switched off.
- When the units are connected using the DV cable and editing is performed, some editing functions will differ compared with when the units are connected using the AV cable. Refer to Glossary of Terms on page 92.
- Read the operating instructions of the playback unit.
- Do not change the EDIT CONTROL or EDIT MODE settings while performing setting or editing operations at the SET UP or EDIT MENU screens. Be sure to quit these screens before changing these settings.
- When using this VCR as the recording VCR and performing editing by connecting the units via the AV cable or a 21-pin Scart cable, the On Screen Display (date/time, Time Code) may scroll vertically when still playback or slow playback are performed by the playback VCR.



Playback Unit
(a Video Equipment with a
LANC socket)



Recording VCR
(the AG-DV2700)

1 Turn the power on.

2 Set the unit so that it is ready to be controlled.
• Read the operating instructions of the playback unit and make the necessary settings.

1 Turn the power on.


2 Set the EDIT CONTROL to 8mm.



3 Press INPUT SELECT on the editing controller so that A3 is selected.
• If the playback unit is connected to the external input on the rear of the AG-DV2700, select A2.
• When the playback unit is connected via a DV cable, select DV IN.
• When performing Audio Dubbing or AV Insert, select A2 or A3.

Initial Settings for Editing

This VCR also allows some settings for editing to be made at the On Screen Display (OSD).



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-57.

Search with Sound

- 1 Press SET UP.



- 2 Select Search With Sound and press OK.



On Screen Display



- 3 Select OFF, EDIT ONLY or ALWAYS ON, and then press OK.



- OFF:** The sound cannot be heard during special playback.
- EDIT ONLY:** The sound can be heard during special playback only when an editing operation is in progress.
- ALWAYS ON:** The sound can be always heard during special playback.

- 4 Press EXIT to exit the On Screen Display.

Audio Mode

- 1 Press SET UP.



- 2 Select Audio Mode and press OK.



- 3 Select 12bit or 16bit, and then press OK.



- 12bit:** Divides the audio area into two stereo audio tracks, STEREO1 and STEREO2. If a recording is made in 12bit audio mode, the sound is recorded on STEREO1 only, and is not recorded on STEREO2. STEREO2 is used to record new audio that is added through Audio Dubbing or Audio Mixing.

- 16bit:** Uses the entire audio area in order to record audio with greater quality.

- 4 Press EXIT to exit the On Screen Display.

One-Touch-Edit

- 1 Press SET UP.



- 2 Select One-Touch-Edit and press OK.



On Screen Display



- 3 Select OFF or ON, and then press OK.



- OFF:** Select this whenever you are performing any editing function other than One-Touch-Edit.
- ON:** Select this in order to perform One-Touch-Edit.
- One-Touch-Edit is possible only when **EDIT CONTROL** is set to either **DV**, **EDIT**, or **8mm**, and **EDIT MODE** is set to **RECORDER**.

- 4 Press EXIT to exit the On Screen Display.

AV-IN Colour Level

- 1 Press SET UP.



- 2 Select AV-IN Colour Level, and press OK.




- 3 Select SOURCE or ADJUST, and then press OK.



- SOURCE:** Normally set this position.
- ADJUST:** To adjust the colour level of the input external recording source.

If you select **ADJUST** and then press **OK**, the **AV-IN Colour Level** screen is displayed.

- 4 Adjust the colour level using ◀▶.



Press ◀ to make the colour lighter
Press ▶ to make the colour darker
The setting can be adjusted over a range of ± 2.0 .


- 5 Press SET UP, and then press EXIT to exit the On Screen Display.

Notes:

- If **INPUT SELECT** is set to **DV IN**, the **Audio Mode** menu, and the **AV-IN Colour Level** menu cannot be selected.
- The **SET UP** or **EDIT MENU** screen is displayed in English, regardless of the language that is set for the On Screen Display.
- The **AV-IN Colour Level** menu can be selected in following cases:
INPUT SELECT is set to **A1**, **A2** or **A3**;
When the VCR is in stop mode

Editing when Not Using an Edit Cable

To connect a VCR or Movie Camera without an Edit Socket and use the AG-DV2700 as the Recording VCR.



Preparations

- Complete necessary connections and settings. See pages 50-59.
- Connect the AV1 socket on the AG-DV2700 to the TV.
- Connect the AV2 socket or the AUDIO/VIDEO/S-VIDEO IN (AV3) sockets on the AG-DV2700 to the playback unit. Set **INPUT SELECT** on this VCR as follows:
A2: Through the AV2 socket
A3: Through the AV3 sockets on the front panel or rear panel.
- If the playback unit has a DV terminal, connect to the DV IN/OUT on the AG-DV2700 with a DV cable.

Operations

- Using the controls on the playback unit, search for the edit start point, and then pause the playback.

- Press **JOG/SHUTTLE** on the AG-DV2700, and check that the button is lit.



- Search for the edit start point.



- Press the button for the editing mode on the AG-DV2700.

To copy the contents of the tape in the playback unit as is: Press **REC**.

To insert picture: Press **VIDEO INSERT**.

To insert sound: Press **AUDIO INSERT**.

To insert picture and sound: Press **VIDEO INSERT** and then press **AUDIO INSERT** (or vice versa).


To add new sound: Press **AUDIO DUB**.

For Audio Mixing: Press **AUDIO DUB** and then press **MIXING EDIT** on the front right panel.

- The Audio Mixing procedure differs in part from other editing operations. See page 66.

- The indicator that corresponds to the selected editing mode lights on the VCR display.

Indicators On the VCR Display



- Press **PAUSE/SLOW** on the AG-DV2700 and start playback on the playback unit simultaneously.

- Editing begins.


- Press **■ (STOP)** on the AG-DV2700, and then press **STOP** on playback unit to stop editing.

Notes:

- Although Copying can be performed in LP mode, Insert and Audio Dubbing cannot be performed with a tape recorded in LP mode. It is necessary to first copy the tape in SP mode.
- Video Insert and Audio Insert are not possible in the following cases:
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
- AV Insert, Audio Dubbing and Audio Mixing are not possible in the following cases:
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in 16bit audio mode;
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
When **INPUT SELECT** is set to DV IN.
- If the time display on the AG-DV2700 is set to tape counter mode during editing, the AG-DV2700 stops the editing operation automatically when the counter reaches "0:00:00".
(This function does not work when using the Copying or Audio Dubbing functions.)

One-Touch Assemble


If the One-Touch Edit function is used, Assemble editing can be performed by controlling the playback unit through the AG-DV2700.




Preparations


- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.
- Set to **One-Touch-Edit ON** on SET UP menu.


Operations

- 1 Press **JOG/SHUTTLE** on the AG-DV2700, and check that the button is lit. 

- 2 Search for the edit start point on the AG-DV2700. 

- 3 Press **REC**.
 - The picture from the playback unit appears on the screen.

- 4 Search for the edit start point on the playback unit using Jog dial and Shuttle Ring on the AG-DV2700. 

- 5 Press **JOG/SHUTTLE** on the AG-DV2700.
 - Editing begins.
 - To continue editing, press **JOG/SHUTTLE** on the AG-DV2700, and repeat steps 4-5.


- 6 Press **■ (STOP)** on the AG-DV2700, to stop editing.

Notes:

- Although Assemble editing can be performed in LP mode, Insert, Audio Dubbing, and Audio Mixing cannot be performed with a tape recorded in LP mode. It is necessary to first copy the tape in SP mode.
- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- When using the editing controller for remote control: In order to conserve battery power, **JOG/SHUTTLE** turns off after one minute. If **JOG/SHUTTLE** turns off after the edit start point has been set on the recording unit (step 2), it is necessary to press **JOG/SHUTTLE** again (so that it is lit) before searching for the edit start point on the playback unit. If **JOG/SHUTTLE** turns off after the edit start point has been determined on the playback unit (step 4), it is necessary to press **JOG/SHUTTLE** twice in order to start editing.

One-Touch Insert /Audio Dubbing

If the One-Touch Edit function is used, Insert (Video Insert, Audio Insert, and AV Insert) and Audio Dubbing can be performed by controlling the playback unit through the AG-DV2700.



Preparations


- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.
- Set to One-Touch-Edit ON on SET UP menu.

Operations

- 1 Press **JOG/SHUTTLE** on the AG-DV2700, and check that the button is lit.



- 2 Search for the edit start point on the AG-DV2700.



- 3 Press the button for the editing mode on the AG-DV2700.

To insert picture: Press **VIDEO INSERT**.
To insert sound: Press **AUDIO INSERT**.
To insert picture and sound: Press **VIDEO INSERT** and then press **AUDIO INSERT** (or vice versa).
To add new sound: Press **AUDIO DUB**.

- The indicator that corresponds to the selected editing mode lights on the VCR display.
- The picture from the playback unit appears on the screen.

Indicators On the VCR Display



VIDEO INSERT



AUDIO INSERT



AV INSERT



AUDIO DUBBING

- 4 Search for the edit start point on the playback unit using Jog dial and Shuttle Ring on the AG-DV2700.



- 5 Press **JOG/SHUTTLE** on the AG-DV2700.
 - Editing begins.
 - To continue editing, press **JOG/SHUTTLE** on the AG-DV2700, and repeat steps 4-5.



- 6 Press **■ (STOP)** on the AG-DV2700, to stop editing.

To monitor the edited audio after Audio Dubbing

Press **STEREO SELECT** during playback and select **STEREO2**.

Notes:


- Video Insert and Audio Insert are not possible in the following cases:
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
- AV Insert and Audio Dubbing are not possible in the following cases:
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in 16bit audio mode;
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
When **INPUT SELECT** is set to DV IN.
- If the time display on the AG-DV2700 is set to tape counter mode during editing, the AG-DV2700 stops the editing operation automatically when the counter reaches "0:00:00".

- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- When using the editing controller for remote control:
In order to conserve battery power, **JOG/SHUTTLE** turns off after one minute.
If **JOG/SHUTTLE** turns off after the edit start point has been set on the recording unit (step 2), it is necessary to press **JOG/SHUTTLE** again (so that it is lit) before searching for the edit start point on the playback unit.
If **JOG/SHUTTLE** turns off after the edit start point has been determined on the playback unit (step 4), it is necessary to press **JOG/SHUTTLE** twice in order to start editing.

One-Touch Audio Mixing

This function is used to mix the audio on STEREO1, which has already been recorded, with audio from an external recording source (A2 or A3), and record the result on STEREO2.

This function is useful for adding new audio, such as music or a narration, to the original audio which has already been recorded.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.
- Set to **One-Touch-Edit ON** on SET UP menu.

Operations

- 1 Press **JOG/SHUTTLE** on the AG-DV2700, and check that the button is lit.



- 2 Search for the edit start point on the AG-DV2700.



- 3 Press **AUDIO DUB** on the AG-DV2700.
 - The picture from the playback unit appears on the screen.

Notes:

- Audio Mixing is not possible in the following cases:
 - When the tape in the recording VCR (the AG-DV2700) is:
 - Recorded in 16bit audio mode;
 - Recorded in LP mode;
 - Blank, or contains a blank portion in the middle.
 - When **INPUT SELECT** is set to DV IN.
- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.

- 4 Press **MIXING EDIT** on the AG-DV2700.

- 5 Search for the edit start point on the playback unit using Jog dial and Shuttle Ring on the AG-DV2700.



- 6 Press **JOG/SHUTTLE** on the AG-DV2700.

- Editing begins.
- If you wish to adjust the volume of the original audio (STEREO1) and external recording source (A2 or A3) during Audio Mixing,
 - AUDIO MIX:** To adjust the volume of the original audio (STEREO1).
 - AUDIO REC LEVEL:** To adjust the volume of the audio from external recording source (A2 or A3).
- To continue editing, press **JOG/SHUTTLE** on the AG-DV2700, and repeat steps 5-6.




- 7 Press **■ (STOP)** on the AG-DV2700, to stop editing.

To monitor the mixed signal after Audio Mixing

Press **STEREO SELECT** during playback and select **STEREO2**.

When editing with a microphone


1. Connect the microphone to the MIC socket.
2. Press **JOG/SHUTTLE**.
3. Use Jog Dial and Shuttle Ring to search the recording start point.
4. Press **AUDIO DUB**.
5. Press **MIXING EDIT**.
6. Use **AUDIO REC LEVEL** slider to adjust the microphone level.
7. Press **PAUSE/SLOW**.
8. Press **■ (STOP)** to stop editing.



- The audio from the microphone is recorded as monaural audio. Use audio cables to connect audio equipment, etc., in order to record in stereo.
- If both the MIC socket and the line inputs are connected, the audio from the MIC socket is given priority in recording.

Manual Copying

This function can be used to copy tapes between digital video equipments with practically no deterioration in quality. This function can also copy a tape that was recorded in S-VHS (VHS) format onto a digital video tape.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.

Operations

- 1 Press **EDIT MENU**.



- 2 Check that **Copying** is selected and press **OK**.



On Screen Display



- 3 Press **PLAYER**, and then press **JOG/SHUTTLE**.

- The picture from the playback unit appears on the screen.



- 4 Search for the edit start point on the playback unit.



- 5 Press **RECORDER**, and then press **JOG/SHUTTLE**.

- The picture from the recording VCR appears on the screen.



- 6 Search for the edit start point on the recording VCR.



- 7 Select **Start Copying**.



- 8 Press **OK**.
- Editing begins.



- 9 Press **EDIT MENU** to stop editing.




- Operation now returns to the screen which appears in step 3. This makes it possible to continue with editing or change the point at which editing is to start.

- 10 Press **EXIT**.



- The On Screen Display disappears.




Notes:

- If a digital video tape is copied without connecting a DV cable, the original sub code data (photoshot index signals, recording date, etc.) is not copied.
- Although Copying can be performed in LP mode, Insert and Audio Dubbing cannot be performed with a tape recorded in LP mode. It is necessary to first copy the tape in SP mode.
- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- The pause operation may be indicated on the display of the playback unit even though the playback unit is actually playing the tape in slow motion.
- Up to ± 1 second of slight deviation in the specified edit start position can be corrected. See page 90 for Edit Timing Adjustment.

Manual Insert

This function is used to replace the picture and sound on a recorded tape.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.

Example: Video Insert


Operations

- 1 Press **EDIT MENU**.



- 2 Select **Video Insert**, and then Press **OK**.

To insert picture: Select **Video Insert**.
To insert sound: Select **Audio Insert**.
To insert picture and sound: Select **AV Insert**.



On Screen Display




- 3 Press **PLAYER** and **JOG/SHUTTLE**.

• The picture from the playback unit appears on the screen.



- 4 Search for the edit start point on the playback unit.



- 5 Press **RECORDER** and **JOG/SHUTTLE**.

• The picture from the recording VCR appears on the screen.



- 6 Search for the edit start point on the recording VCR.



- 7 Select **Start Insert**.



- 8 Press **OK**.

• Editing begins.



- 9 Press **EDIT MENU** to stop editing.





- Operation now returns to the screen which appears in step 3. This makes it possible to continue with editing or change the point at which editing is to start.

- 10 Press **EXIT**



- The On Screen Display disappears.




Notes:

- **Video Insert and Audio Insert are not possible in the following cases:**
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
- **AV Insert is not possible in the following cases:**
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in 16bit audio mode;
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
When INPUT SELECT is set to DV IN.

- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- The pause operation may be indicated on the display of the playback unit even though the playback unit is actually playing the tape in slow motion.
- Up to ± 1 second of slight deviation in the specified edit start position can be corrected. See page 60 for Edit Timing Adjustment.

Manual Audio Dubbing

This function is used to add new sound on the STEREO2 track of previously recorded tape.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.

Operations

- 1 Press **EDIT MENU**.



- 2 Select **Audio Dubbing**, and then Press **OK**.




- 3 Press **PLAYER** and **JOG/SHUTTLE**.
 - The picture from the playback unit appears on the screen.



- 4 Search for the edit start point on the playback unit.



On Screen Display



- 5 Press **RECORDER** and **JOG/SHUTTLE**.
 - The picture from the recording VCR appears on the screen.



- 6 Search for the edit start point on the recording VCR.



- 7 Select **Start Dubbing**.



- 8 Press **OK**.
 - Editing begins.



- 9 Press **EDIT MENU** to stop editing.



- Operation now returns to the screen which appears in step 3. This makes it possible to continue with editing or change the point at which editing is to start.

- 10 Press **EXIT**.




- The On Screen Display disappears.

To monitor the mixed signal after Audio Mixing

Press **STEREO SELECT** during playback and select **STEREO2**.


Notes:

- Audio Dubbing is not possible in the following cases:
 - When the tape in the recording VCR (the AG-DV2700) is:
 - Recorded in 16bit audio mode;
 - Recorded in LP mode;
 - Blank, or contains a blank portion in the middle.
 - When **INPUT SELECT** is set to **DV IN**.
- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.



Programme Assemble

This function can be used to link together desired scenes on a tape.
This function can also be used to skip unnecessary scenes recorded on a tape and copy them onto a separate tape.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings.
See pages 50-59.

Operations

- Press **EDIT MENU**.



- Select **Programme Editing**, and then Press **OK**.



On Screen Display



Notes:

- Programme Editing can be performed using either the tape counter or Time code display, but the Time code display should be used if the units are connected only by a DV cable.
- If you attempt to switch to the tape counter display in order to perform editing after setting the editing points using the Time code display, the Erase all programmes screen is displayed.
(The Erase all programmes screen is also displayed when you change from the tape counter display to the Time code display.)
- After setting a programme, if you attempt to set another programme in a different editing operation, the set contents for the previous editing operation remain on the setting screen. In order to prevent editing errors, perform the Erase all programmes operation (page 87) whenever you set a programme under a different editing mode.
- Programme editing can not be performed with a movie camera that has a 4-digit counter.

- Select **Assemble**, and then Press **OK**.




- Press **PLAYER** and **JOG/SHUTTLE**.


The picture from the playback unit appears on the screen.





- Search for the edit start point on the playback unit and press **MARK IN**.



- Search for the edit end point on the playback unit and press **MARK OUT**.




(Continued on next page)



Notes:


- Although Assemble editing can be performed in LP mode, Insert, Audio Dubbing, and Audio Mixing cannot be performed with a tape recorded in LP mode. It is necessary to first copy the tape in SP mode.
- Order ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- The editing operation may not be performed correctly if the set duration of a programme is less than 4 seconds.
- On a video equipment whose Time code display or tape counter display does not show the frame value, the area where the frame value is displayed appears as "00" or it remains blank.
With some units, the frame value may be displayed when **MARK IN** or **MARK OUT** is pressed in steps 5 and 6 even if the unit concerned does not show the frame value.

Programme Assemble (continued)




7 Press **RECORDER** and **JOG/SHUTTLE**


- The picture from the recording VCR appears on the screen.



8 Search for the edit start point on the recording VCR and press **MARK IN**.



On Screen Display



9 Press **OK**




To check and change programmes:

Select Confirm/Change and then press **OK**.

- To confirm, change, insert or erase editing programmes, see pages 86-87.
- Programmes cannot be inserted or erased through the recording unit.

To continue setting programmes:

- 1 Press **EDIT MENU**.
- 2 Press **PLAYER**.
- 3 Using **◀ ▶**, select the programme number.
The programme number changes each time these buttons are pressed.
(Up to 40 programmes can be set. 10 programmes can be set on one page; if this number is exceeded, the display automatically changes to the next page.)
- 4 Repeat steps 4-6 and 9.




10 Select **Start Assemble** to start editing, and then press **OK**.

- Editing begins after the playback unit and the recording VCR both rewind their tapes to the edit start points.



11 After completing editing, select **Review**, and then press **OK**.

- The edited pictures are played back.




To interrupt editing or Review: Press **EDIT MENU**.

Notes:

- The Preview function cannot be used with the Assemble function.
- Up to ± 1 second of slight deviation in the specified edit start/end position can be corrected. See pages 88-89 for Edit Timing Adjustment.

Programme Insert

This function is used to replace the picture and sound on a recorded tape.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-58.

Example: Video Insert

Operations

- Press **EDIT MENU**.



- Select **Programme Editing**, and then Press **OK**.



On Screen Display



Notes:

- Programme Editing can be performed using either the tape counter or Time code display.
- If you attempt to switch to the tape counter display in order to perform editing after setting the editing points using the Time code display, the Erase all programmes screen is displayed. (The Erase all programmes screen is also displayed when you change from the tape counter display to the Time code display.)

- After setting a programme, if you attempt to set another programme in a different editing mode, the set contents for the previous editing mode remain on the setting screen. In order to prevent editing errors, perform the Erase all programmes operation (page 87) whenever you set a programme under a different editing mode.
- Programme Editing can not be performed with a movie camera that has a 4-digit counter.
- Video Insert and Audio Insert are not possible in the following cases:**
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in LP mode;
Blank, or contains a blank portion in the middle.

- Select the desired editing operation, and then press **OK**.
To insert picture: **Video Insert**.
To insert sound: **Audio Insert**.
To insert picture and sound: **AV Insert**.



- Press **PLAYER** and **JOG/SHUTTLE**
The picture from the playback unit appears on the screen.



- Search for the edit start point on the playback unit and press **MARK IN**.



- Search for the edit end point on the playback unit and press **MARK OUT**.



(Continued on next page)




- AV insert is not possible in the following cases:**
When the tape in the recording VCR (the AG-DV2700) is:
Recorded in 16bit audio mode;
Recorded in LP mode;
Blank, or contains a blank portion in the middle.
When **INPUT SELECT** is set to **DV IN**.

Notes on editing point setting

- The Programme Insert and Audio Dubbing functions require the setting of only three editing points: the in and out points on the playback unit and the in point on the recording unit, or the in point on the playback unit and the in and out points on the recording unit.
- If both in and out points are set on both the playback unit and the recording unit, and the times between the points do not match, editing stops at the first out point that is reached.

- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- The editing operation may not be performed correctly if the set duration of a programme is less than 4 seconds.
- On a video equipment whose Time code display or tape counter display does not show the frame value, the area where the frame value is displayed appears as "00" or it remains blank.
With some units, the frame value may be displayed when **MARK IN** or **MARK OUT** is pressed in steps 5 and 6 even if the unit concerned does not show the frame value.

Programme Insert (continued)




7 Press **RECORDER** and **JOG/SHUTTLE**

- The picture from the recording VCR appears on the screen.



8 Search for the edit start point on the recording VCR and press **MARK IN**.



On Screen Display



9 Press **OK**



To check and change programmes:

- Select Confirm/Change and then press **OK**.
- To confirm, change, insert or erase editing programmes, see pages 86-87.

To continue setting programmes:

- Press **EDIT MENU**.
- Press **PLAYER**.
- Using **◀▶**, select the programme number. The programme number changes each time these buttons are pressed. Up to 10 programmes can be set.
- Repeat steps 4-9.



10 Select **Preview** to confirm the editing operation before performing actual editing, and then press **OK**.

- Preview begins after the playback unit and the recording VCR both rewind their tapes to the edit start points.



11 Select **Start Insert** to start editing, and then press **OK**.

- Editing begins after the playback unit and the recording VCR both rewind their tapes to the edit start points.



12 After completing editing, select **Review**, and then press **OK**.

- The edited pictures are played back.




To Interrupt editing, Preview or Review: Press **EDIT MENU**.

Note:

Up to ± 1 second of slight deviation in the specified edit start/end position can be corrected. See pages 88-89 for Edit Timing Adjustment.

Programme Audio Dubbing

This function is used to add new sound on the STEREO2 track of previously recorded tapes.



Preparations

- Confirm that the TV is on and the VCR viewing channel is selected.
- Complete necessary connections and settings. See pages 50-59.

Operations


- Press **EDIT MENU**.



- Select **Programme Editing**, and then Press **OK**.




On Screen Display



Notes:

- Programme Editing can be performed using either the tape counter or Time code display.
- If you attempt to switch to the tape counter display in order to perform editing after setting the editing points using the Time code display, the Erase all programmes screen is displayed. (The Erase all programmes screen is also displayed when you change from the tape counter display to the Time code display.)
- Programme editing can not be performed with a movie camera that has a 4-digit counter.
- After setting a programme, if you attempt to set another programme in a different editing mode, the set contents for the previous editing mode remain on the setting screen. In order to prevent editing errors, perform the Erase all programmes operation (page 87) whenever you set a programme under a different editing mode.
- Audio Dubbing is not possible in the following cases: When the tape in the recording VCR (the AG-DV2700) is: Recorded in 16bit audio mode; Recorded in LP mode; Blank, or contains a blank portion in the middle. When **INPUT SELECT** is set to DV.


- Select **Audio Dubbing**, and then press **OK**.




- Press **PLAYER** and **JOG/SHUTTLE**.
 - The picture from the playback unit appears on the screen.



- Search for the edit start point on the playback unit and press **MARK IN**.



- Search for the edit end point on the playback unit and press **MARK OUT**.




(Continued on next page)

Notes on editing point setting

- The Programme Insert and Audio Dubbing functions require the setting of only three editing points: the in and out points on the playback unit and the in point on the recording unit, or the in point on the playback unit and the in and out points on the recording unit.
- If both in and out points are set on both the playback unit and the recording unit, and the times between the points do not match, editing stops at the first out point that is reached.
- In order to ensure that the editing operation is performed properly, the editing points should be set at least 20 seconds after the beginning of the tape.
- The editing operation may not be performed correctly if the set duration of a programme is less than 4 seconds.
- On a video equipment whose Time code display or tape counter display does not show the frame value, the area where the frame value is displayed appears as "00F" or it remains blank. With some units, the frame value may be displayed when **MARK IN** or **MARK OUT** is pressed in steps 3 and 6 even if the unit concerned does not show the frame value.


Programme Audio Dubbing (continued)



- 7** Press **RECORDER** and **JOG/SHUTTLE**.
- The picture from the recording VCR appears on the screen.



- 8** Search for the edit start point on the recording VCR and press **MARK IN**.



- 9** Press **OK**.




To check and change programmes:
Select **Confirm/Change** and then press **OK**.
To confirm, change, insert or erase editing programmes, see pages 86-87.


- To continue setting programmes:**
- Press **EDIT MENU**.
 - Press **PLAYER**.
 - Using **◀ ▶**, select the programme number. The programme number changes each time these buttons are pressed. Up to 10 programmes can be set.
 - Repeat steps 4-9.



- 10** Select **Preview** to confirm the editing operation before performing actual editing, and then press **OK**.
- Preview begins after the playback unit and the recording VCR both rewind their tapes to the edit start points.



- 11** Select **Start Dubbing** to start editing, and then press **OK**.
- Editing begins after the playback unit and the recording VCR both rewind their tapes to the edit start points.



- 12** After completing editing, select **Review**, and then press **OK**.
- The edited sounds are played back.



To interrupt editing, Preview or Review:
Press **EDIT MENU**.


To monitor the edited audio after Audio Dubbing

Press **STEREO SELECT** during playback and select **STEREO2**.

Note:
Up to ± 1 second of slight deviation in the specified edit start/and position can be corrected. See pages 88-89 for Edit Timing Adjustment.

Other Editing Functions

These functions are used to confirm, change, etc. programmes.



Once all programme settings are completed, the screen shown at right is displayed.

Example: Video Insert

This portion varies, depending on the editing function that was programmed.

On Screen Display



To check/change programmes:



- 1 Select Confirm/Change, and then press OK.
•The programme list for the playback unit is displayed.

To check the programme list for the recording unit, press **RECORDER**.

To just confirm the programme settings, press **EDIT MENU**.


If corrections are needed, continue with the procedure described below.

- 2 Select the programme number for which changes are to be made, and then press OK.
•The Programme Change screen for the selected programme number is displayed.
- 3 Press **JOG/SHUTTLE**.
- 4 Use the Jog Dial/Shuttle Ring to search for the editing point that is to be corrected.
- 5 To change an edit start point, press **MARK IN**.
To change an edit end point, press **MARK OUT**.
- 6 Once all changes are completed, press **OK**.
- 7 Press **EDIT MENU**.




To insert a new programme between existing programmes:

- 1 Select **Insert a programme**, and then press OK.
•The programme list is displayed.
- 2 Select the programme number where a programme is to be inserted, and then press OK.
•The Insert a programme screen is displayed.
- 3 Refer to the pages that describe the Programme Editing functions (on pages 74-85), and set the new programme.
- 4 When setting is complete, press **OK**.
- 5 Press **EDIT MENU**.



To cancel a programme:

- 1 Select **Erase a programme**, and then press OK.
•The programme list is displayed.
- 2 Select the programme number to be erased, and then press OK.
- 3 Press **EDIT MENU**.



To cancel all editing programmes:


- 1 Press **EDIT MENU** twice.
- 2 Select **Programme Editing**, and then press OK.
- 3 Check that **Erase all programmes** is selected and press OK.
•The Erase all programmes screen is displayed.
- 4 Select **YES**, and then press OK.
•The screen returns to the Programme Editing menu.
•After the message indicating that "All programmes have been erased," appears on the screen, operation returns to the EDIT MENU screen.
- 5 Press **EDIT MENU**.



If the EDIT MENU screen is cancelled before the above procedure is performed, the method for displaying the Programme Editing changes.

Press **EDIT MENU** so that the EDIT MENU screen is displayed. Use to select **Programme Editing**, and then press **OK**.


Note:
Programmes set in the recording unit for the Assemble editing function cannot be inserted or erased.



Edit Timing Adjustment

When performing editing in conjunction with a unit which has a different mechanism, there may be a lag in the edit start point due to a deviation between the time a pause cancellation signal is received by the recording unit and the time recording actually begins.

Edit Timing Adjustment is used to compensate the edit start and end time in light of this start-up time deviation.



Programme Editing

After setting edit start/end points, the actual editing operation may start slightly before or slightly after the position that was set, depending on the equipment that is connected. The procedure described below can adjust the edit timing in order to correct for errors of up to ± 1 second.

Example: Video Insert

Operations

1 Press **EDIT MENU**.



2 Select **Programme Editing**, and then Press **OK**.



On Screen Display




Notes:

- The procedure described on these pages is to be performed after exiting the EDIT MENU screen. If this procedure is performed after having executed Start Editing or Review, start this procedure from step 4 on the Video Insert (Assemble, Audio Insert, AV Insert or Audio Dubbing) screen.
- The adjusted frame unit is applied to all of the programmes that have been set at the moment when the adjustment is made.

3 Select desired editing operation, and then press **OK** twice.



4 Select **Timing Adjust**, and then press **OK**.



5 Adjust the timing for the edit start point by setting the amount of the discrepancy for the start-up time.

- The setting is displayed in frames (1/25 of a second) units.

Press **▶** if the start point is too early; press **◀** if it is too late.

- Each time the button is pressed, the tape moves by 1 frame.

- Corrections can be made in the range of ± 30 frames.



6 Press **OK**.




7 Adjust the timing for the edit end point in same way.




8 Press **OK**.




9 Select **Start Insert (Assemble or Dubbing)**, and then press **OK**.



- If the results of editing indicate that the adjustment is inadequate, repeat steps 4-8.



Edit Timing Adjustment (continued)



Manual Editing

If there is a deviation in the results of a manual editing operation, the timing of the edit start (In) position on the playback unit can be adjusted by approximately ± 1 second. Perform the procedure described below when setting an edit start point in any editing mode.

Example: Manual Copying

Operations

- 1 Select **Timing Adjust**, and then press **OK**.



- 2 Adjust the timing for the edit start point by setting the amount of the discrepancy for the start-up time.

- The setting is displayed in frames (1/25 of a second) units.

Press **▶** if the start point is too early; press **◀** if it is too late.

- Each time the button is pressed, the tape moves by 1 frame.
- Corrections can be made in the range of ± 30 frames.

- 3 Press **OK**.





- 4 Select **Start Copying (Insert, Dubbing)**, and then press **OK**.



- If the results of editing indicate that the adjustment is inadequate, repeat steps 1-3.

On Screen Display



On Screen Display Messages

Before requesting service, check the following points once again.

The error message is indicated in brackets [].

These messages are displayed in the language that is set for On Screen Display.

[This action is not possible before time and date are set.]
 • **SHOWVIEW** or **CHECK** is pressed when the date and time are not set. Set date and time.

[Please Insert video tape!]
 • **REC (REC/OTR)**, **DIRECT TV REC**, **▶ (PLAY)**, **▶▶ (FAST FORWARD)** or **◀◀ (REWIND)** is pressed when no cassette is in the VCR. Insert a video cassette.

[Recording not allowed. Check setting of the record-prevention tab.]
 • **REC (REC/OTR)** or **DIRECT TV REC** has been pressed when using a cassette with the opened record-prevention tab. Use a cassette with the closed record-prevention tab.

[No timer programmes to be done!]
 • **TIMER REC** was pressed even though nothing has been programmed. Programme a timer recording.

[Please put VCR into stop mode first.]
 • Changes to programming details were attempted during timer recording.

Messages of On Screen Display for Editing Operations

These messages are displayed in English regardless of the set for On Screen Display.

[Please insert video tape!]
 • **REC (REC/OTR)**, **▶ (PLAY)** or **JOG/SHUTTLE** has been pressed when the editing operation using **EDIT MENU** screen is performed in the VCR. Insert a video cassette.

[Recording not allowed. Check setting of the record-prevention tab.]
 • **REC (REC/OTR)** has been pressed when using a cassette with the opened record-prevention tab. Use a cassette with a closed record-prevention tab.

[This function cannot be made in the blank part of the tape.]
 • Are you trying to edit using a blank tape, or a tape that contains a blank segment in the middle? Editing is not possible in blank segments (because there are no Time codes). In order to use such a tape for editing, copy the tape once so that continuous Time codes are recorded on the tape, even if there is nothing else recorded on the tape.

[This function is not allowed in LP-recorded section of the tape.]

• It is not possible to edit a tape that was recorded in LP mode, or that was recorded partly in SP mode and partly in LP mode. Make a copy of the tape in SP mode end then use that tape.

[This function cannot be made with 18bit mode audio recording.]
 • Does the audio mode change in the middle of the tape? The Audio Dubbing and AV Insert functions can only be used on a tape that was recorded in 12bit audio mode.

[Copying of this material is not allowed.]
 • Tapes which contain copy protection codes cannot be edited, whether in the playback unit or the recording unit.

[EDITING cannot be made. Please check switches setting and cables.]
 • Are the necessary cables for controlling the playback unit (Edit cable, LANC cable, DV cable) connected?
 • Is the playback unit turned off?
 • Are **EDIT MODE**, **EDIT CONTROL**, and the **INPUT SELECT** setting on the AG-DV2700 set properly for the desired editing operation?
 • Are there more than one digital video device (including personal computers) connected to the AG-DV2700?
 • Are the AG-DV2700 and the unit connected to the AG-DV2700 both set to control each other (if the connected unit is a digital video device)?

[Audio Dubbing or Audio Mixing cannot be made with DV input mode.]
 • Audio Dubbing and Audio Mixing functions will not work if **INPUT SELECT** is set to DV IN. Set to A2 or A3.

[AV Insert cannot be made with DV input mode.]
 • AV Insert will not work if **INPUT SELECT** is set to DV IN. Set to A2 or A3.


[Please select DV input mode.]
 • Is **EDIT CONTROL** set to DV, but **INPUT SELECT** is set to something other than DV IN?

[This tape is an incorrect type. Please replace the tape.]
 • A video cassette tape other than a DV or MINI DV cassette has been inserted. DVCPRO cassettes cannot be used with the AG-DV2700.


Other messages may also appear. Follow the instructions in the message.

Flow Chart for On Screen Displays

SET UP On Screen Display





EDIT MENU On Screen Display (Manual Editing)



Flow Chart for On Screen Displays (continued)

Programme Editing On Screen Display





Memo

SECTION 2 ADJUSTMENT PROCEDURES

1. Disassembly/Assembly Procedures for cabinet parts, C.B.A. and Mechanism Unit

1-1. Disassemble Flow Chart for cabinet parts, C.B.A. and Mechanism Unit.

This flow chart indicates the disassembly steps the cabinet parts, C.B.A. and Mechanism Unit in order to access to items to be serviced. When reinstalling, perform the steps in reverse order.




Fig. 1-1 Flow Chart




Fig. 1-2

1-2. Disassembly/Assembly Procedures (for cabinet parts, C.B.A. and Mechanism Unit)

No.	ITEM / PART	FIG.	REMOVAL (SCREW)
1	Top Panel	Fig. D-1	4-Screws (A) 1-Screw (B) Remove Side Plate (6 Hooks).
2	Front Panel	Fig. D-2 Fig. D-3	2-Screws (C) 1-Connector (P3701) 9-Locking Tabs (a) When Front Panel is installed, confirm the Connector P7504.
3	AV Digital C.B.A.	Fig. D-6 Fig. D-5	2-Screws (D) 2-Connectors (FP3201, P3701) Note 1: When the EVR Connection C.B.A. is installed, confirm the arrow direction on C.B.A..
4	Analog Y/C C.B.A.	Fig. D-6	2-Screws (E)
5	Audio C.B.A.	Fig. D-6	Note 2: 2-Locking Tabs (b)
6	Motor Power C.B.A.	Fig. D-6	1-Connector (P2502) Note 2: 2-Locking Tabs (c)
7	Power C.B.A.	Fig. D-6	1-Connector (P1102) 7-Locking Tabs (d)
8	Front (L) C.B.A.	Fig. D-3	1-Connector (P4851) 2-Locking Tabs (e)
9	Front (R) C.B.A.	Fig. D-3	1-Screw (F) 1-Connector (P4801) 2-Locking Tabs (f)
10	5P Jack C.B.A. & DV Jack C.B.A.	Fig. D-5	1-Screw (G) 2-Connectors (P3781, P7651) 1-Locking Tab (g)
11	Timer C.B.A.	Fig. D-4	3-Connectors (P7501, P7502, P7503) 6-Locking Tabs (h)
12	Mechanism Unit	Fig. D-5	Remove the Tray Angle. Set the Mechanism to the "Eject" position. 4-Connectors (P2705, FP5002, P6504, P6505) 3-Screws (H)
13	Main C.B.A.	Fig. D-6	4-Screws (D/E) 2-Screws (I) 4-Screws (J) 7-Locking Tabs (I)




Fig. D-1




Fig. D-2




Fig. D-3




Fig. D-4




Fig. D-5




Fig. D-6

2. Disassembly/Assembly Procedures for Mechanism

2-1. Disassemble Flow Chart for Mechanism

This procedure starts with the condition that the mechanism unit has been removed from the unit.

The following chart indicates disassembly steps of the mechanical parts in order to gain access to part for servicing. When reinstalling, perform the steps in reverse order.




Fig. 2-1 Flow Chart




Fig. 2-2

2-2. Disassembly/Assembly Procedures (for Mechanical Parts)

1. Mechanism Connection C.B.A.

Unscrew 4 screws and disconnect following connectors.




Fig. 2-3

2. Tray Unit

2-1. Cassette Cover

- Fig. T-1 Set the Mechanism to Tray open position. Unscrew 2 screws (A), then slide the Cassette Cover and unhook the hooking portion.
- Fig. T-2 When the Tray can not be opened normally, slowly turn the Tray Drive Shaft until the Tray is fully opened.

2-2. Tray Unit

- Fig. T-3 Unscrew 4 screws (B) and disconnect P6502 when Mechanism Drive C.B.A. is connected to Mechanism Unit.
- Fig. T-4 Since the Side Plate (S) is located underneath the Tray Connection Rod, then shift the Side Plate (S) in the front direction and lift it up.

Note of Installation

- Fig. T-5 Push the Tray Connection Rod in the rear direction and install the Tray Unit so that the Reel Shaft on the Side Plate (S) meets the groove on the Tray Connection Rod.

2-3. Side Plate (S) and (T)

- Fig. T-6 Set the Pinion Gear so that the projection (A) is aligned to the Dot Mark on the Rack (S) and (T) and remove the Side Plate (S) and (T).

Note of Installation

- Fig. T-10 Confirm the position of the Cassette Change Lever. (Down position)
- Fig. T-7 Install the Pinion Gear so that the projection (B) on the pinion Gear is aligned to the hole on the Tray Drive Shaft Gear.
- Fig. T-6 Install the Side Plate (S) and (T) so that the projection (A) is aligned to the dot mark on the Rack (S) and (T).

2-4. Tray Front Panel

- Fig. T-8 Unscrew 2 screws (C) and unlock 4 locking tabs (A), then remove the Tray Front Panel.

2-5. Cassette Holder

- Fig. T-9 Slightly open the S and T Rack Unit and slowly remove the Cassette Holder from the Groove on the S and T Rack Unit.




Fig. T-1




Fig. T-2




Fig. T-3




Fig. T-4




Fig. T-5




Fig. T-6




Fig. T-7




Fig. T-8




Fig. T-9




Fig. T-10

Note of Installation

Fig. T-10 Shift the S and T Rail on the S and T Rack Unit to make the Tray down condition.

Fig. T-11 Install the Cassette Holder Unit so that the projection (C) on the Cassette Holder meets the groove on the S and T Rack unit.

2-6. Tray Motor Drive Unit

Fig. T-12 Unlock 3 locking tabs (B) and remove the Tray Motor Drive Unit.

Fig. T-13 Remove the Syncro. Drive Gear, Worm Foil Gear, Worm Gear and Tray Motor.

3. Mechanical Parts

3-1. Head AMP

Fig. M-1 Unscrew 2 screws (E).

Fig. M-2 Slide the Shield Case in up direction and remove the Shield Case.
Disconnect FP5001.

3-2. Pinch Solenoid and Pinch Arm

Fig. M-3 Unscrew 2 screws (F) and remove Cut Washer. Shift the Pinch Solenoid in left direction and remove the Pinch Solenoid and Pinch Arm.

3-3. Loading Motor Base

Fig. M-4 Unscrew 5 screws (G) and (H) and remove the Loading Motor Base.

Note of Installation

Fig. M-7 Set the Motor Worm Gear to the Loading Motor Shaft.

Fig. M-5 Install the Loading Motor Base so that the projection (D) on the Mode SW meets the Hole on the Main Cam Gear.

3-4. Main Cam Gear

Fig. M-6 Remove the Main Cam Gear.

3-5. Main Cam Arm and Motor Worm Gear

Fig. M-7 Remove the Main Cam Arm and Motor Worm Gear.

Note of Installation

Fig. M-8 Install the Main Cam Arm so that the projection (E) on the Main Cam Arm meets the hole on the Main Rod.




Fig. T-12




Fig. T-13




Fig. T-11




Fig. M-1




Fig. M-2





Fig. M-3




Fig. M-4




Fig. M-5




Fig. M-6




Fig. M-7




Fig. M-8

3-6. T1 Guide

Fig. M-9 Unscrew 2 screws (I) and remove the T1 Guide.

3-7. Cleaning Arm and T2 Arm

Fig. M-10 Unhook the Cleaning Spring.
Unlock the locking portion of the Cleaning Arm.
Remove the T2 Arm with Spring.

3-8. Cleaning Solenoid Base and Cleaning Solenoid

Fig. M-11 Unscrew 3 screws (J) and remove the Cleaning Solenoid Base.

Fig. M-12 Unscrew 2 screws (K) and remove the Cleaning Solenoid.

Note of installation

Fig. M-10 Adjust the Cleaning Solenoid Base so that the gap between the Cylinder and Cleaning Arm becomes $1.0\text{mm} \pm 0.1\text{mm}$.

Confirm that the Cleaning Roller rotates when the Cleaning Solenoid is turned on in the play mode.

3-9. S-Post Base

Fig. M-13 Unscrew 1 screw (L) and remove the S-Post Base.

3-10. Main Rod

Fig. M-14 Slide the Main Rod and remove it.
When the Cleaning Solenoid Base is not removed;
Slightly shift the Cleaning Solenoid Base in direction and slide the Main Rod since the Main Rod is stopped by Cleaning Solenoid Base.

Note of installation

Fig. M-15 Install the Main Rod so that the each drive shaft meets the groove of the Main Rod. To lock the Main Rod, slide it in left direction.

3-11. T4 Sector Gear and Tension Regulator Arm

Fig. M-16 Remove the T4 Sector Gear and Tension Regulator Arm.

Note of installation

Fig. M-17 Install the T4 Sector Gear so that the alignment hole of the T4 Sector Gear is aligned to the alignment gear of the T4 Arm.




Fig. M-10




Fig. M-11




Fig. M-9




Fig. M-12




Fig. M-13




Fig. M-16




Fig. M-14




Fig. M-15




Fig. M-17

3-12. Cylinder Unit

Fig. M-18 Unscrew 4 screws (M) and (N). Then remove the Cylinder Unit carefully.

Fig. M-19 When removing or installing the Cylinder Unit, use extreme care so as not to damage the flexible cable.

3-13. Loading Rail

Fig. M-20 Unscrew 2 screws (O) and (P). Then slightly lift up the Loading Rail and slowly remove the S and T Loading Posts from the top side of the Loading Rail.

Note of installation

Fig. M-20 Install the S and T Loading Posts to the Loading Rail and set the Loading Rail to the chassis. Then install 2 screws (O) and (P).

3-14. T Loading Arm (Post)

Fig. M-21 Remove the E-Ring, washer and T Loading Arm.

When replacing the T Loading Arm, perform the "Mechanical Adjustment Procedures".

Note of installation

Fig. M-21 Install the T Loading Arm so that the hole on the gear of the T Loading Arm is aligned to the hole on the T Sector Gear.

3-15. Tension Arm

Fig. M-22 Remove the cut washer and unhook the spring, then remove the Tension Arm.

When replacing the Tension Arm, perform the "Mechanical Adjustment Procedures".

3-16. S Loading Arm (Post)

Fig. M-23 Remove the E-Ring, washer and S Loading Arm.

When replacing the S Loading Arm, perform the "Mechanical Adjustment Procedures".

Note of installation

Fig. M-23 Install the S Loading Arm so that the hole on the gear of the S Loading Arm is aligned to the hole on the S Sector Gear.

3-17. Tension Regulator Hook and Tension Sensor

Fig. M-24 Unscrew 1 screw (Q) located under the S Brake Solenoid, washer and Tension Sensor.

Remove the cut washer and Tension Regulator Hook.

When replacing the Tension Sensor, perform the "Mechanical Adjustment Procedures".

Note of installation

Fig. M-25 After installed Tension Sensor, confirm the position of the Tension Sensor cable.

3-18. Pinch Arm

Fig. M-26 Remove the cut washer and Pinch Arm with spring.

Note of installation

Fig. M-26 Confirm the hooking portion of the spring.

3-19. T4 Arm and T4 Connection Gear

Fig. M-27 Remove the Nylon Nut using tweezers or box driver (2.5mm).

Remove the washer, spring and T4 Arm.




Fig. M-19





Fig. M-20




Fig. M-21




Fig. M-18



Fig. M-22




Fig. M-25




Fig. M-23




Fig. M-26




Fig. M-24




Fig. M-27

Fig. M-28 Remove the cut washer and T4 Connection Gear. When replacing the T4 Arm and/or T4 Connection Gear, perform the "Mechanical Adjustment Procedures".

Note of Installation

Fig. M-28 Install the T4 Connection Gear and cut washer.

Fig. M-27 Install the T4 Arm so that the through hole on the T4 Arm is aligned to the alignment hole on the T4 Connection Gear as shown in Fig. M-28.

3-20. S and T Sector Gear

Fig. M-29 Turn the S and T Sector Gears to clockwise and remove these Gears.

3-21. Gear Holder

Fig. M-30 Unscrew 2 screws (R) and remove the Gear Holder.

Note of installation

Fig. M-30 When installing the Gear Holder, confirm the position of the flexible cable of the Capstan Motor.

3-22. S-Brake Solenoid

Fig. M-31 Unscrew 2 screws (S).

When removing the S-Brake Solenoid, the Tray Connection Rod must be removed because of the connector of the Solenoid is located between the Chassis and Tray Connection Rod.

Note of installation

Fig. M-33 Adjust the S-Brake Solenoid so that the gap between the S-Brake and S-Reel Table becomes 0.2 to 0.5 mm (just release).

3-23. T-Brake Solenoid

Fig. M-32 Unscrew 2 screws (T) and remove the T-Brake Solenoid.

Note of installation

Fig. M-33 Adjust the T-Brake Solenoid so that the gap between the T-Brake and T-Reel Table becomes 0.2 to 0.5 mm (just release).

3-24. Tape Beginning Sensor (T Sensor)

Fig. M-34 Unlock the locking portion and remove the Tape Beginning Sensor.

3-25. Tape End Sensor (S Sensor)

Fig. M-35 Unlock the locking portion and remove the Tape End Sensor.

3-26. MIC Stopper

Fig. M-36 Unscrew 2 screws (U) and remove the MIC Stopper.

3-27. MIC Connector Unit

Fig. M-37 Unscrew 1 screw (V) and remove the cut washer and MIC Connector Unit.

Note of Installation

Fig. M-37 Install the MIC Connector Unit so that the projection (F) meets the hole on the MIC Connector Unit.

3-28. T Reel Table

Fig. M-38 Unscrew 4 screws (W) and remove the T Reel Table with 2 shifts.




Fig. M-28




Fig. M-29




Fig. M-30




Fig. M-31




Fig. M-32




Fig. M-33



Fig. M-34




Fig. M-35




Fig. M-36




Fig. M-37




Fig. M-38

Note of installation

Fig. M-40 Set the inner and outer shafts to the T Reel Table.

Fig. M-41/42 Install the T Reel Table with 2 shafts so that the groove under the T Reel Table meets the projection (G) on the T Base Drive Arm.
Then install 4 screws (W).

3-29. S Reel Table

Fig. M-39 Unscrew 4 screws (X) and remove the S Reel Table with 2 shifts.

Note of installation

Fig. M-40 Set the inner and outer shafts to the S Reel Table.

Fig. M-41/42 Install the S Reel Table with 2 shafts so that the groove under the S Reel Table meets the projection (G) on the S Base Drive Arm.
Then install 4 screws (X).

3-30. Reel Release Angle

Fig. M-42 Unscrew 2 screws (Y) and remove the Reel Release Angle.

3-31. S and T Base Drive Arm

Fig. M-43 Remove the cut washer, S and T Base Drive Arms.

Note of installation

Fig. M-43 Install the S and T Base Arms so that the projections (H) on the S and T Base Arms meet the groove on the Slide Rod.

3-32. Communication Arm

Fig. M-44 Remove the cut washer and Communication Arm.

3-33. Tray Connection Rod and Lock Gear

Fig. M-45 Pull the Tray Connection Rod in front direction to release the lock and remove it.
Remove the Lock Gear.

Note of installation

Fig. M-46 Install the Tray Connection Rod.
Then install the Lock Gear so that the hole on the Lock Gear is aligned to the hole on the Tray Connection Rod.

3-34. Slide Rod

Fig. M-47 Remove the cut washer and Slide Rod.

3-35. Sensor LED

Fig. M-48 Unscrew 1 screw (Z) and Sensor LED.

Note of installation

Fig. M-25 After installed Sensor LED, confirm the position of the Sensor LED cable.

3-36. Capstan Motor

Fig. M-49 Unscrew 4 screws (a) and Capstan Motor.




Fig. M-40




Fig. M-41




Fig. M-39




Fig. M-42




Fig. M-43




Fig. M-47




Fig. M-44




Fig. M-48




Fig. M-45




Fig. M-49




Fig. M-46

4. Mechanical adjustment

4-1. Name of Tape Transportation




Fig. M-1

4-2. Cleaning Procedures

Make sure the power is off before cleaning. Use ethanol (more than 99% purity) as cleaning liquid.

4-2-1. Cleaning of Video Head

Clean heads by applying even pressure and rotating cylinder a few times. Never wipe in up and down motion. Never touch a cylinder by naked hand. First wipe with a cloth soaked by cleaning liquid. Then wipe with dry cloth.




Fig. M-2

4-2-2. Cleaning of Drum Lead

Be careful not to touch ■ head chip. Clean the drum lead with a pick.




Fig. M-3

4-2-3. Cleaning of Pinch Roller and Capstan

Wipe the Pinch Roller and Capstan with a cloth soaked by cleaning liquid.




Fig. M-4

4-2-4. Cleaning of each Post

Wind a cloth on ■ pick. Wipe each post dry with that pick. Wipe again with a dry cloth. For metal posts wipe with cleaning liquid. Then wipe dry again.




Fig. M-5

4-3. Reel Offset and Tension Arm Adjustment

Note:

Before beginning adjustment from the Item 4-4., the "Reel Offset" and "Tension Arm Adjustment" described on the "5. Electrical Adjustment" must be done as shown in Fig. E-1.

4-4. T4, S4 and S5 Post Height Pre-Adjustment

Note :

Before this adjustment, the Servo Adjustment must be done.
(Refer to "5. Electrical Adjustment".)

1. Confirm the Reel Table is located at L (Standard) cassette position.
If it is located at S (Mini-DV) cassette position, turn power on and insert L cassette and eject the L cassette.
2. Turn power off. Remove the Front Loading Unit. Then place the Mech. Plate (VFK1348A) on the Reel Table.
3. Place the Post Height Adj. Tool (VFK1450) on the Mech. Plate as shown in Fig. M-6 and adjust the T4 post height by using the Box Driver (VFK1151).
4. Adjust the S4 and S5 post height by using the Post Driver (VFK1278).
5. Then turn S4 and S5 posts 1 round counterclockwise from lower limit position.

T4 Post : Lower Limit (-0.5 ± 0.05 mm)

S4 Post : Lower Limit ($+0.2 \pm 0.05$ mm)

S5 Post : Lower Limit ($+0.2 \pm 0.05$ mm)




Fig. M-6

4-5. Tape Pass Adjustment Procedures




Fig. M-7

4-5-1. Tape Pass Limit Confirmation

1. Place unit into Play mode, and adjust the height of each post do not to occurred tape damage.
2. Regarding the S1 Post and T1 Post, refer to item "4-5-2. Envelope Waveform Adjustment".
3. Confirm the tape pass limit of each post as shown in Fig. M-8.

POST NAME	TAPE LIMIT							ADJUSTMENT PORTION	TAPE PASS LIMIT
	A	B	C	D	E	F	G		
4-5-1. Play Tape Pass Limit Confirmation									
S5 Post	×	×	○	○	×	×	×	S5 Post	Lower Limit
S4 (Tension) Post	×	×	×	○	×	×	×	S4 (Tension) Post	Lower Limit
S1 Post	×	○	×	×	×	×	×	S1 Post	Envelope Adjustment
T1 Post	×	○	×	×	×	×	×	T1 Post	Envelope Adjustment
T4 Post	×	×	○	×	×	×	×	T4 Post Arm Nut	Free Limit
4-5-7. REV Tape Pass Limit Adjustment									
S5 Post	×	○	○	○	×	×	×	S5 Post	Lower Limit
S4 (Tension) Post	×	×	○	○	×	×	×	S4 (Tension) Post	Lower Limit
S1 Post	×	○	×	×	×	×	×	S1 Post	Envelope Adjustment
T1 Post	×	○	○	○	×	×	×	T1 Post	Envelope Adjustment
T4 Post	×	×	○	×	×	×	×	T4 Post Arm Nut	Free Limit
4-5-8. Play Tape Pass Limit Confirmation									
S5 Post	×	×	○	○	×	×	×	S5 Post	Lower Limit
S4 (Tension) Post	×	×	×	○	×	×	×	S4 (Tension) Post	Lower Limit
S1 Post	×	○	×	×	×	×	×	S1 Post	Envelope Adjustment
T1 Post	×	○	×	×	×	×	×	T1 Post	Envelope Adjustment
T4 Post	×	×	×	○	×	×	×	T4 Post Arm Nut	Free Limit
4-5-9. REV Tape Pass Limit Confirmation									
S5 Post	×	○	○	○	×	×	×	S5 Post	Lower Limit
S4 (Tension) Post	×	○	○	○	×	×	×	S4 (Tension) Post	Lower Limit
S1 Post	×	○	×	×	×	×	×	S1 Post	Envelope Adjustment
T1 Post	×	○	○	○	×	×	×	T1 Post	Envelope Adjustment
T4 Post	×	○	○	○	×	×	×	T4 Post Arm Nut	Free Limit
4-5-10. FF / REW Tape Pass Limit Confirmation									
S5 Post	×	○	○	○	×	×	×	S5 Post	Lower Limit
S4 (Tension) Post	×	×	○	○	×	×	×	S4 (Tension) Post	Lower Limit
S1 Post	×	○	×	×	×	×	×	S1 Post	Envelope Adjustment
T1 Post	×	○	○	○	×	×	×	T1 Post	Envelope Adjustment
T4 Post	×	○	○	○	×	×	×	T4 Post Arm Nut	Free Limit
<div>○ : means acceptable ×</div>									

Fig. M-8

4-5-2. Envelope Waveform Adjustment

<Pre-Adjustment>

1. Hook up the PC EVR System as shown in Fig. 2-7 (Section 1). Then starts the RF / VITERBI Adjustment in the Video Section.
2. Connect the oscilloscope to "Envelope" and "GND" on the Measuring TP Board (VFK1409). Then playback the Alignment Tape (VFM3110EDS) and adjust S1 and T1 posts so that the envelope output is within following specification (Fig. M-9). Use "HID1" as a trigger.
When the S1 and T1 posts are adjusted, first raise the post height and make small the entrance and exit side of the envelope, then down the post until envelope becomes flat.
3. Adjust T1 post and makes exit side of the envelope flat then adjust S1 post.




Fig. M-9

<Fine Adjustment>

1. Playback the self recorded tape and readjust S1 and T1 posts so that the BER counter number becomes the minimum.
2. After adjustment, unload the tape then loading the tape. Then confirm the waveform style and BER counter number is minimized.

4-5-3. PG Adjustment

Since the adjustment procedure for "PG Adjustment" is supported only "PC EVR System", refer to "PC EVR" software.

4-5-4. Confirmation of Envelope Waveform in REV, REW and FF mode

1. Hook up the PC EVR System as shown in Fig. 2-7 (Section 1).
2. Connect the oscilloscope to "Envelope" and "GND" on the Measuring TP Board (VFK1409).
3. Confirm the Envelope Waveform signal is in the specification in the REV, REW and FF mode as shown in Fig. M-10.
4. If it is out of specification, after adjusting the "4-5-6. S4 Tension Post Height Adjustment", confirm this "Envelope Waveform in REV, REW and FF mode" again.




Fig. M-10

4-5-5. Confirmation of Envelope Waveform at the beginning of track

1. Observe the Envelope Waveform signal by oscilloscope and confirm the envelope signal is in the specification in the transition from FF to Play, from REW to Play, from REV to Play and from Loading completion to Play.
2. If it is out of specification, after adjusting the "4-5-6. S4 Tension Post Height Adjustment", confirm this "Envelope Waveform at beginning of track" again.




Fig. M-11

4-5-6. S4 Tension Post Height Adjustment

Note :

This adjustment should be done when the "4-5-2. Envelope Waveform Adj.", "4-5-4. Confirmation of Envelope in REV, REW and FF mode" or "4-5-5. Confirmation of Envelope Waveform at the beginning of Track" can not be achieved the specification.

1. Rotate the S4 Tension Post height 90 degrees counterclockwise from lower limit position.
2. Adjust S1 and T1 post height adjustment again. Refer to the "4-5-2. Envelope Waveform Adjustment".
3. Confirm the "Play Start Envelope Waveform". Refer to the "4-5-5. Confirmation of Envelope Waveform at the beginning of Track".
4. If it is not in the specification, repeat item 1 to 3. The maximum rotation angle is 360 degrees.
5. Even the height is still out of specification, confirm the "4-4. T4, S4 and S5 Post Height Pre-Adjustment".




Fig. M-12

4-5-7. REV Tape Pass Limit Adjustment

1. Place unit into REV mode, and adjust T4 Post so that the lower limit touches the tape.
2. Confirm the tape pass limit of each post as shown in Fig. M-8.
3. This adjustment must be done after "4-5-2. Envelope Waveform Adjustment".

4-5-8. Play Tape Pass Limit Confirmation

1. Place the unit into Play mode, and confirm the each post limit is in the specification as shown in Fig. M-8.
2. This adjustment must be done after "4-5-2. Envelope Waveform Adjustment".
3. Regarding T4 Post, confirm and adjust this confirmation alternately with "4-5-9. REV Tape Pass Limit Confirmation".
4. Confirm the tape pass limit for both L and S cassettes.

4-5-9. REV Tape Pass Limit Confirmation

1. Place the unit into REV mode, and confirm the each post limit is in the specification as shown in Fig. M-8.
2. This adjustment must be done after "4-5-2. Envelope Waveform Adjustment".
3. This adjustment should be done alternately with "4-5-8. Play Tape Pass Limit Confirmation".
4. Confirm the tape pass limit for both L and S cassettes.

4-5-10. FF, REW Tape Pass Limit Confirmation

1. Place the unit into FF and REW mode, and confirm the each post limit is in the specification as shown in Fig. M-8.
2. This adjustment must be done after "4-5-2. Envelope Waveform Adjustment".
3. Confirm the tape pass limit for both L and S cassettes.

5. Electrical Adjustment

Since the "PG Shifter Adj." and Video adjustments except "EE Y Level Adj." are required the "PC EVR System", these adjustment procedures are described on "Tatsujin" software.

1. Servo Circuit

1-1. T and S Reel Offset Adj.

[Take up Reel Offset Adj.]

TP	ADJ	MODE	Jig & Tool
TP2701 (T ET) TP2702 (T GND)	VR2702 (T VR)	Cassette Down (Stop)	_____
TAPE	M. EQ	SPEC.	
Mini DV	D.V.M.	0 +/- 1mV	

[T Reel Offset Adj.]

1. Set a cassette on the tray and make the cassette down condition.
2. Connect the Digital Volt Meter between TP2701 (T ET) and TP2702 (T GND).
3. Adjust VR2702 (T VR) so that the voltage becomes 0 +/- 1mV.

[Supply Reel Offset Adj.]

TP	ADJ	MODE	Jig & Tool
TP2703 (S ET) TP2704 (S GND)	VR2701 (S VR)	Cassette Down (Stop)	_____
TAPE	M. EQ	SPEC.	
Mini DV	D.V.M.	0 +/- 1mV	

[S Reel Offset Adj.]

1. Set a cassette on the tray and make the cassette down condition.
2. Connect the Digital Volt Meter between TP2703 (S ET) and TP2704 (S GND).
3. Adjust VR2701 (S VR) so that the voltage becomes 0 +/- 1mV.

Tension Adjustment

When this adjustment is done, melt the grew of the adjustment screws as shown in Fig. E-6




Fig. E-1

1-2. Tension Arm Offset Adj.

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3)	VR6501 (TEN SET)	Cassette Down (Stop)	_____
TAPE	M. EQ	SPEC.	
Mini DV	D.V.M.	0 +/- 0.03V	

1. Set a cassette on the tray and make the cassette down condition.
2. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
3. Adjust VR6501 (TEN SET) so that the voltage becomes 0 +/- 0.03V.

1-3. Tension Arm Neutral Adj.

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3)	Tension Regulator Base	Loading Condition (Service Mode 7)	VFK1208 (Black with Hole)
TAPE	M. EQ	SPEC.	
_____	D.V.M.	0 +/- 0.06V	

1. Remove the Tray Unit.
2. Set the VFK1208 to the Supply Post Base (A) as shown in Fig. E-2.
3. Place the unit into the no tape-loading mode by using Service Mode described as follows.
 1. Press the "FF" and "Eject" buttons simultaneously in eight times to set the Service Mode No. 7.
 2. Set the mechanism to loading condition by pressing the "Play" button.

Play button : Loading direction
Stop button : Unloading direction
4. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
5. Loosen screw (A).
6. Adjust the Tension Regulator Base so that the voltage becomes 0 +/- 0.06V by moving the (D) portion with tweezers that are not magnetized.
7. Then tighten the screw (A).

Caution

Don't touch the magnetized driver or tweezers to S-Reel FG magnet portion, when the "D" portion is adjusting.




Fig. E-2

1-4. Tension Arm Play Voltage Adj.

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3)	VR6502 (TEN GAIN)	Loading Condition (Service Mode 7)	VFK1156 (Black)
TAPE	M. EQ	SPEC.	
—	D.V.M.	0.92 +/- 0.03V	

1. Remove the Tray Unit.
2. Set the VFK1156 to the Supply Post Base (A) as shown in Fig. E-3.
3. Place the unit into the no tape-loading mode by using Service Mode.
4. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
5. Adjust the VR6502 (TEN GAIN) so that the voltage becomes 0.92 +/- 0.03V.




Fig. E-3

1-5. Confirmation of REV position of the Tension Arm

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3)	—	Loading Condition (Service Mode 7)	VFK1155 (White)
TAPE	M. EQ	SPEC.	
—	D.V.M.	-0.92 +/- 0.2V	

1. Remove the Tray Unit.
2. Set the VFK1155 to the Supply Post Base (A) as shown in Fig. E-4.
3. Place the unit into the no tape loading mode by using Service Mode.
4. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
5. Confirm the voltage is in the specification.
6. If it is out of specification, readjust "1-3. Tension Arm Neutral Adj." and "1-4. Tension Arm Play Voltage Adj."
7. If it is still out of specification, replace the Tension Post unit and readjust the Tension Arm Adjustment from "1-2. Tension Arm Offset Adj."




Fig. E-4

1-6. Tension Regulator Spring Adj.

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3) Tension Post	Tension Regulator Spring Position	Loading Condition (Service Mode 7)	VFK1188 (Dial Tension Gauge)
TAPE	M. EQ	SPEC.	
—	D.V.M. Dial Tension Gauge	0.92 V (Play Position) 11 +/- 1gf	

1. Remove the Tray Unit.
2. Place the unit into the no tape loading mode by using Service Mode.
3. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
4. When pressing the R portion of the Tension Post in arrow direction by Dial Tension Gauge (VFK1188) until the voltage becomes 0.92V (Play Position) as shown in Fig. E-5, loosen screw (C) and adjust the Tension Regulator Spring position (Hook B) so that the tension is in the specification 11 +/- 1gf.
5. Tighten screw (C).




Fig. E-5

1-7. Confirmation of REV Tension

TP	ADJ	MODE	Jig & Tool
TP6502 (TP2) TP6503 (TP3) Tension Post	Tension Regulator Spring Position	Loading Condition (Service Mode 7)	VFK1188 (Dial Tension Gauge)
TAPE	M. EQ	SPEC.	
—	D.V.M. Dial Tension Gauge	-0.92 V (REV Position) 18 +/- 2gf	

1. Remove the Tray Unit.
2. Place the unit into the no tape loading mode by using Service Mode.
3. Connect the Digital Volt Meter between TP6502 (TP2) and TP6503 (TP3).
4. When pressing the R portion of the Tension Post in arrow direction by Dial Tension Gauge (VFK1188) until the voltage becomes -0.92V (REV Position) as shown in Fig. E-5, confirm the tension is in the specification 18 +/- 2gf.
5. If it is not, adjust "1-6. Tension Regulator Spring Adj." again.
6. Grease the screw A, B and C after Tension Arm Adjustment. The grease quantity at B portion is half of A and C portions as shown in Fig. E-6.




Fig. E-6




Fig. E-7

1-8. Supply and Take-up Photo Sensor Sensitivity Adj.

[Supply Photo Sensor Adj.]

TP	ADJ	MODE	Jig & Tool
TP6501 TP6504 (S Photo)	DIP SW (S6504)	Stop	VFK1426 (6%) VFK1217 (49%) Sensor Cassette
TAPE	M. EQ	SPEC.	
Sensor Cassette	D.V.M.	0.5 - 1.0 V Refer to Fig. E-8	

[Supply Photo Sensor Adj.]

1. Set all of the DIP SW (S6504) to ON.
2. Insert the 6% Sensor Cassette VFK1426.
3. Connect the Digital Volt Meter between TP6501 and TP6504 (S Photo).
4. Adjust the DIP SW as shown in Fig. E-8.
5. Confirm that the tape is not loaded when installing the 49% Sensor Cassette VFK1217.
6. If the tape is loaded when install the 49% Sensor Cassette readjust this adjustment.

[Take-up Photo Sensor Adj.]

TP	ADJ	MODE	Jig & Tool
TP6501 TP6505 (T Photo)	DIP SW (S6504)	Stop	VFK1426 (6%) VFK1217 (49%) Sensor Cassette
TAPE	M. EQ	SPEC.	
Sensor Cassette	D.V.M.	0.5 - 1.0 V Refer to Fig. E-9	

[Take-up Photo Sensor Adj.]

1. Set all of the DIP SW (S6504) to ON.
2. Insert the 6% Sensor Cassette VFK1426.
3. Connect the Digital Volt Meter between TP6501 and TP6505 (T Photo).
4. Adjust the DIP SW as shown in Fig. E-9
5. Confirm that the tape is not loaded when installing the 49% Sensor Cassette VFK1217.
6. If the tape is loaded when install the 49% Sensor Cassette, readjust this adjustment.

[Supply Sensor]

TP6501 - TP6504 VOLTAGE	DIP SW (S6504) ADJUSTMENT PROCEDURES	RESULT OF THE ADJUSTMENT	REMARKS
When the voltage is 0 - 0.5 V.	1. Change only SW 6 to OFF 2. Change only SW 5 to OFF 3. Change SW 5 and 6 to OFF 4. Change only SW 4 to OFF 5. Change SW 4 and 5 to OFF 6. Change SW 4 and 5 to OFF	If the voltage is not 0.5 - 1.0 V, proceed to the item 2. If the voltage is not 0.5 - 1.0 V, proceed to the item 3. If the voltage is not 0.5 - 1.0 V, proceed to the item 4. If the voltage is not 0.5 - 1.0 V, proceed to the item 5. If the voltage is not 0.5 - 1.0 V, proceed to the item 6.	If the voltage is in the specification (0.5 - 1.0 V), this adjustment is done.
When the voltage is 0.5 - 1.0 V.	This adjustment is not necessary.		
When the voltage is more that 1.0V.	NG Replace the Supply Photo Sensor. Then readjust this adjustment.		

Fig. E-8 Supply Photo Sensor Adj.

[Take-up Sensor]

TP6501 - TP6505 VOLTAGE	DIP SW (S6504) ADJUSTMENT PROCEDURES	RESULT OF THE ADJUSTMENT	REMARKS
When the voltage is 0 - 0.5 V.	1. Change only SW 1 to OFF 2. Change only SW 2 to OFF 3. Change SW 1 and 2 to OFF 4. Change only SW 3 to OFF 5. Change SW 1 and 3 to OFF 6. Change SW 2 and 3 to OFF	If the voltage is not 0.5 - 1.0 V, proceed to the item 2. If the voltage is not 0.5 - 1.0 V, proceed to the item 3. If the voltage is not 0.5 - 1.0 V, proceed to the item 4. If the voltage is not 0.5 - 1.0 V, proceed to the item 5. If the voltage is not 0.5 - 1.0 V, proceed to the item 6.	If the voltage is in the specification (0.5 - 1.0 V), this adjustment is done.
When the voltage is 0.5 - 1.0 V.	This adjustment is not necessary.		
When the voltage is more that 1.0V.	NG Replace the Take-up Photo Sensor. Then readjust this adjustment.		

Fig. E-9 Take-up Photo Sensor Adj.

2. Video Circuit

2-1. Phase Difference of Y/C Sepa. V Blanking Pulse Adj.

TP	ADJ	MODE	Input
TP30001 TP30005	VR30001	Stop (E-E)	Colour Bar Signal
TAPE	M. EQ	SPEC.	
—	Oscilloscope	Phase Difference T 24±0.5H	




Fig. E-10

2-2. Phase Difference of Y/C Sepa. H blanking Pulse Adj.

TP	ADJ	MODE	Input
TP30004 TP30005	VR30003	Stop (E-E)	Colour Bar Signal
TAPE	M. EQ	SPEC.	
—	Oscilloscope	Phase Difference T=9.0±0.25μsec.	




Fig. E-11

2-3. PAL Encoder Free Run Frequency Adj.

TP	ADJ	MODE	Input
TP30009 (TP30010 TP30007, 8)	VC30002	Free Run	—
TAPE	M. EQ	SPEC.	
—	Frequency Counter	Output Freq. = 4.433619MHz±50Hz	

1. Connect TP30010 to GND and put the unit into Free Run mode.
2. Apply 5V DC power to TP30007 and 2.6V DC to TP30008.

2-4. Edit OSD Colour Burst Clock Frequency Adj.

TP	ADJ	MODE	Input
TP30003 (TP30002)	VC30001	Stop (E-E)	—
TAPE	M. EQ	SPEC.	
—	Frequency Counter	Output Freq. = 4.433619MHz±50Hz	

1. Connect TP30002 to GND.

2-5. Edit OSD dot Clock Frequency Adj.

TP	ADJ	MODE	Input
TP30013 (TP30002)	VC30003	Stop (E-E)	—
TAPE	M. EQ	SPEC.	
—	Frequency Counter	Output Frequency = 6.860MHz±50KHz	

1. Connect TP30002 to GND.

2-6. Phase Difference of Color GTL Burst Gate Pulse Adj.

TP	ADJ	MODE	Input
TP30011 TP30012	VR30004	Stop (E-E)	Colour Bar Signal
TAPE	M. EQ	SPEC.	
—	Oscilloscope	Phase Difference T=9.0±0.25μsec.	

1. Connect TP30002 to GND.




Fig. E-12

2-7. E-E Y Level Adj.

TP	ADJ	MODE	Input
TP3002 (I/O Pack)	VR30002 (Analog Y/C Pack)	Stop (E-E)	Colour Bar Signal
TAPE	M. EQ	SPEC.	
—	Oscilloscope	Y Level = 2.0±0.1Vp-p	

1. Terminate the VIDEO OUT at 75Ω.




Fig. E-13

3. Audio Circuit


























3-1. Level Meter Adj.

TP	ADJ	MODE	Input
Level Meter on the Front Panel	VR4004	Stop (E-E)	1 kHz, -6dB Audio Signal
TAPE	M. EQ	SPEC.	
—	—	[dB] Indicator on the Audio Level Meter just lights up.	

1. Set the Audio Rec Level Volume to center (click position : 5)
2. Set the output level of the Signal Generator to 1 kHz / -6dB and supply it to both Audio Input Line 1 terminals (L) and (R).
3. Adjust VR4004 until the 0dB of the Level Meter on the FIP just lights up.


6. SPECIAL FIXTURES AND TOOLS

In order to keep the factory adjustment specifications, the following special tools should be used to conduct mechanical and electrical adjustments and servicing.


Electrical Service and Adjustment				
VFK1409 Measuring Board 	VFK1410 Connection Board 	VFK1317 30pin Flat Cable (Needs 2 cables) 	VFK1405 Audio Extender Board 	VFK1406 Digital Extender Board 
VFK1407P Y/C Extender Board 	VFK1408 Motor Extender Board 	VJA0941 DC Cable (For Measuring Board) 	VFK1436 14pin Extender Cable 	VFK1448 12pin Extender Cable 
VFK1446 32 Flat Cable 	VFK1445 26 Flat Cable 	VFK0849 20pin Flat Cable 	VFK1485 EVR Software 	VFM3110EDS Alignment Tape (Color Bar) 
Mechanical Service and Adjustment				
VFK1348A Neutral Plate 	VFK1450 Post Height Fixture 	VFK1151 Box Driver  2.5mm IO	VFK1149 Post Driver 	VFK1188 Dial Tension Gauge 
VFK1217 49% Sensor Cassette 	VFK1426 6% Sensor Cassette 	VFK1155 Neutral Position Tool (REV/White) 	VFK1156 Neutral Position Tool (PLAY/Black) 	VFK1208 Neutral Position Tool (NEUTRAL/ Black w/Hole) 

LOCATION OF TEST POINTS & CONTROLS


MECHANISM DRIVE C.B.A.



TIMER C.B.A.




INPUT / OUTPUT C.B.A.




(FOIL SIDE)

ANALOG C.B.A.



(COMPONENT SIDE)



(FOIL SIDE)

Memo

SECTION 3

BLOCK DIAGRAMS & SCHEMATIC DIAGRAMS

3-1. ABBREVIATIONS

INITIAL/LOGO		ABBREVIATIONS			
A	A GND	Analogue GND	AILRCK	L/R Clock (to A/D Converter)	
	A. COMP	Audio Component Signal	AIMCK	Master Clock (to A/D Converter)	
	A. D.P [L]	Audio Dubbing Pause ㊶	ALC CNT	Auto Level Control Control	
	A. DEF [S]	Audio Defeat	ALC MAIN	Auto Level Control Drive	
	A. DUB P [L]	Audio Dubbing Pause ㊶	ALE	Address Latch Enable	
	A. ERASE	Audio Erase	A-LOCK	Full Auto Switch	
	A. HASW	Audio Head Amp Switching Pulse	ANLPTH	Analogue Loop Through High	
	A. HSW	Audio Switching Pulse	AORP	Audio Overlap Pulse	
	A. IN [L]	Audio Input (L)	APCNT	Aperture Control	
	A. IN [R]	Audio Input (R)	APS	Auto Power Save	
	A. MUT [H]	Audio Mute ㊶	ART. V	Artificial Vertical Sync Signal	
	A. MUTE [H]	Audio Mute ㊶	ART. V. MM	Artificial Vertical Sync Signal Mono Multi	
	A. OUT [L]	Audio Output (L)	ART. V/H/N	Artificial Vertical Sync Signal ㊶/Normal	
	A. OUT [R]	Audio Output (R)	AT. V/H/N	Artificial Vertical Sync Signal	
	A. RF OUT	Audio RF Signal Output	ATSW/TEST/NOR/SE	Test/Normal/Service	
	A. TR	Auto Tracking	AT CNT	Automatic Tracking Gain Adjust	
	A0-8, 0-17	Memory Address	ATF	Automatic Track Finding	
	A3V2	AD Converter Reference Voltage	ATFCLK	41.85MHz Clock	
	AB0-4	Address Bus	ATFG	Auto Track Gain	
	AB0-4, AB12-15	Address Bus Line 0-4, 12-15	ATL	Auto Lock Select	
	ABSF	Focus Encoder Input	ATN	Absolute Track Number	
	AC. O/EE. H	AC Online/EE ㊶	ATR OFF(H)	Auto Tracking Off (H)	
	ACI	Analogue Channel Cording IC	ATV	Advanced TV	
	AD	AD Converter	AUDIO SELECT [H]	Audio Select ㊶	
	AD	Auto Date, Analogue Digital Converter	AVDD	Analogue VDD	
	AD CLK	AD Clock	AVSS	Analogue Ground	
	AD REC	Audio Delayed REC	AWTB	Auto White Balance B-Y	
	AD0-6	Address	AWTR	Auto White Balance R-Y	
	AD0-6, ADR0-6	Address Data Line			
	ADCLK	Analogue Digital Converter Clock	B	B MODE. H	■ Mode ㊶
	ADCNT	Analogue Digital Control		B.G.P	Burst Gate Pulse
	ADCS	Analogue Digital Chip Select		BACK	Back-up
	A-DET	Audio Detect		BACK UP	Microcomputer Back-up
	ADREC	Audio Delaied Rec		BACK VDD	Back-up Power
	ADUB	Audio Dubbing		BATT	Battery
	AE	Auto Expose		BATT ALARM	Battery Alarm
	AECNT	Auto Expose Control		BATT REF	Reference Voltage for Battery
	AEE(H)	Audio E-E (H)		BCB	B Carrier Balance
	AEH	Audio Erase Head		BCBM(B-Y)	B-Y Carrier Balance
	AEIRQ	Auto Expose Interrupt Request		BCBM(R-Y)	R-Y Carrier Balance
	AF DIS CS	AF DIS Chip Select		BD0-7	REC/Play In/Out Buss
	AFC S C	AFC S Curve		BDCK	Standard Bus Data Clock (9MHz)
	AFC [S]	AFC S Curve		BDEN	Standard Bus Data Enable
	AFC. DEF	AFC Defeat		BEND	Data Block End Request
	A-FADE(L)	Audio Fade (L)		BF	Burst Flag Pulse
	AF-AMP	AF HALL Bias		BFA	Burst Flag Pulse for Encoder
	AFCS	Auto Focus Chip Select		BFO/BFI	Burst Flug Input/Output
AFRP	Audio PLL Voltage Control	BI, BO		Buffer Input, Output	
AGC	Automatic Gain Control	BI/MI [L]		Bilingual/Mix ㊶	
AGCCNT	Automatic Gain Control Control	BIL		Bilingual	
AGND	Analogue Ground/Audio Ground	BIL [L]		Bilingual ㊶	
AGS	Anti Ground Shooting	BL		Back Light	
AH(P) / (R)	Audio Head (Play) / (Record)	BL ON		Back Light ON (L)	
AHASW	Audio Head Amp Switch Pulse	BL4V		Back Light 4V	
AHSW	Audio Head Switch Pulse	BLC 0, 1		Back Light Y Control Out, In	
AI, AO	Buffer Input, Output	BLDI/O		Back Light Drive Input/Output	
AIBCK	Bit Clock (to A/D Converter)	BLK	Blanking Pulse		
AIDAT	Serial Data (to A/D Converter)	BLKA	Blanking for Encoder		

INITIAL/LOGO	ABBREVIATIONS	INITIAL/LOGO	ABBREVIATIONS
BLKA	Blanking Pulse for Encoder	CH1	Channel 1 (Odd Field)
BLKI/O	Blanking Pulse In/Out	CHR	Character
BLKZ	Blanking Pulse for Zoom Encoder	CHR BACK	Character Back-up
BM	Balance Modulator	CHR MIX	Character Mix
BQUIET	Bus Out Control Signal	CI, CO	Buffer In/Out
BS CLOCK	BS Clock	CI, CO	Buffer Input & Output
BS DATA	BS Data	CIF	Control Signal Forward Input
BS LCH IN	BS L Channel Input	CIF, CIR	Positive Control Pulse, Negative Control Pulse
BS MIX [H]	BS Mix (H)	CIR	Control Signal Reverse Input
BS MONI [H]	BS Monitor (H)	CK	Clock
BS MONI [H]	BS Monitor (H)	CKL	Ratch Lock
BS RCH IN	BS R Channel Input	CKS	Shift Lock
BUF IN/OUT	Buffer In/Out	CL/CLK	Clock
B-Y KB	B-Y Carrier Balance	CLASS	Classification Signal for Compress (DCT/VLC)
B-YO	B-Y Signal Out	CLASS 0.1	Class Control Signal During DCT/VLC
C		CLK135	13.5MHz System Clock
C A In/Out	Pre-Aperture In/Out	CLK18	18MHz System Clock
CAPSTP	Capstan Stop Flag	CLK2	Clock 2 (824XFH: 12.875MHz)
C CNT	Colour Control	CLK246	24.576MHz Clock
C SYNC	Composite Sync Signal	CLK27	27MHz System Clock
C/N	Carrier/Noise	CLK450	450KHz Clock
CO-7, CO0-07	Chrominance Signal 0-7	CLKDCLK	Digital Clock
CAGAIN	Aperture Gain Control	CLK-PH	Clock Phase Control
CAM TL	Capstan Trque Limit	CLK-REF	Reference Clock
CAP EC	Capstan Trque Control	CLP-RST-H	Clamp Reset High Signal
CAP M GND	Capstan Motor GND	CLY FG	Cylinder FG Signal
CAP P(H)	Capstan Power On (H)	CMEMO0-3	Chroma Memory Output Signal 0-3
CAP R/F/S	Capstan Reverse (H)/Stop (M)/Forward (L)	CMIX	Character Mix
CAP SW	Capstan Power Control Switch	CMO	Chrominance Memory Output
CAP. ET	Capstan Torque Control	COL/BW/NOR	Colour/Black & White/Normal
CAP. FG1	Capstan FG1 Pulse	COLOR [H]	Colour (H)
CAP. FG2	Capstan FG2 Pulse	COMPC	Position Detection Pulse
CAPSTP H	Capstan Stop Flag (Stop High)	COM RDY	Serial Enable Signal
CAPVM	Capstan Motor Current	CNCLK	Clock
CAPVS	Capstan Motor Power Control Switch	CNR	Chrominance Noise Reduction
CAS. SW	Cassette SW	CNT, CONT	Control
CAS	Compression, Audio Process, Shuffling/Deshuffling	CO	Control Out
CAS	Memory Address Strobe (Active Low)	CO0-7	Chrominance Output 0 to 7 (Digital)
CASDOWN, DWN	Cassette Down (L)	COM	Common
CB, CR	Chroma B, Chroma R	COM RDY	Serial Transmission Enable
CBLK	Composite Blanking Pulse	COMB	Comb Filter
CC	Channel Cording	COS EQ	Cosin Equalizer
CCA	Current Drive Control	CP	Clamp Pulse
CCA	Current Control Amp	CP ON(H)	Camera Power On(H)
CCD	Charge Coupled Device	CP2, 20	Clamp Pulse
CCW	Counterclockwise	CP2A, CP2O	Encoder Clamp Pulse
CD SP0-7	Digital Chroma	CPN	Component Signal
CDS	Correlate Double Sampling Signal	CPOB	Clamp Pulse for Optical Blanking
CDS1, 2	Sampling Pulse for CCD Output Signal	CPS	Composite Signal
CE	Chip Enable	CPV	Gate Scan Clock
CE	Control Pulse Erase	CR OUT	Pre Apature Out
CEC	Capstan Error Code	CR POW SW	Camera Remote Power On Switch
C-ERA(H)	Control Erase (H)	CRA	Aperture Gain Control
CFEM	Chrominance Memory Signal	CRA	Pre Apature Gain Control
CFM	Chrominance Field Memory	CS	Chip Select
CFM1-4	Chroma Field Memory Signal	CS 0-7	Chrominance Signal Out 0-7
CG CLK	Character Generator Clock	CSEL	Clock Phase Select
CG CLK DATA	Clock Generator Data	CSI 0-7	Chrominance Signal In 0-7
CG DATA	Character Generator Data	CTSW	Crosstalk Switch
CGC	Chrominance Gain Control	CURR	Current
CGCS	Character Generator Chip Select	CURRENT LIM	Current Limmitter
CGO	Character Generator Serial Data	CW	Clockwise
CH	Charge	CYL ET	Cylinder Motor Trque Control

INITIAL/LOGO		ABBREVIATIONS	
	CYL PG CYL VM	Cylinder Motor PG Cylinder Motor Current or Power	
D	D CLK	Digital Clock	
	D MODE	Digital Mode Switch Signal	
	D. FM REC [H]	Delayed FM Recording (H)	
	D. FM REC [L]	Delayed FM Recording (L)	
	DA UV SEL	D/A Converter U/V Select	
	DAC	Digital Analogue Converter	
	DAG	Digital Analogue Ground	
	DB0-7	Data 0-7	
	DB0-7	Microprocessor Data	
	DCC	DC Clamp Control	
	DCCNT	DC Control	
	DCI	Digital Channel Cording IC	
	DCLR	Digital Clear	
	DCP	Digital Clamp Pulse	
	DCS-CLK, DA	CAS & DV I/F Serial Clock	
	DC-STP1	DCS Serial Start	
	DC-STP2	DCS Serial Stop	
	DCT	Discrete Cosine Transform (Compression)	
	DCX7	Serial Data	
	DEDP 0-3	Playback Data	
	DEDR 0-3	Rec Data	
	DEMO	Demodulation	
	DEMP	A/D Converter Emphasis Control	
	DEMP	De-Emphasis	
	DFD 0-7	Encode Data In/Out Between Shuffling Memory	
	DFD0-7	Encode Input/Output Signal for Shuffling Memory	
	DIBDCK	Bit Clock	
	DICLK	Digital Clock	
	DIDAT	Serial Data	
	DIDAT	Serial Data During Digital Audio In	
	DIF	Digital Interface	
	DILRCK	L/R Clock	
	DILRCK	Serial Clock During Digital Audio In	
	DIMCK	Master Clock	
	DIMCK	Master Clock During Digital Audio In	
	DIO 1-8	Data In/Out	
	DIOS	Data In/Out Select Control Signal	
	DIOS	Select Signal for Digital In/Out	
	DIS	Digital Image Stabilizer	
	DIS R/B	Digital Image Stabilizer Read (H)/Busy (L)	
	DIS R/B	DIS IC Ready/Busy	
	DIS/KAND	Digital Image Stabilizer/Sensitivity	
	DISCS	Dis Chip Select	
	DISP	Display	
	DL	Delay Line	
	DOBCK	Audio A/D Converter Bit Clock	
	DOCTL	Data Output Control Signal	
	DODAT	Serial Data (to D/A Converter)	
	DOLRCK	Audio A/D Converter LR Clock	
	DOLRCK	L/R Clock (to D/A Converter)	
	DOMCK	Audio A/D Converter Master Clock	
	DOMCK	Master Clock (to D/A Converter)	
	DQ 1-16	Memory Data	
	DRAM CAS	D-RAM Column Address Strobe	
	DRAM OE	D-RAM Out Enable	
	DRAM RAS	D-RAM Read Address Strobe	
	DREC	AV Delayed REC Start Pulse	
	DRK	Dark (LPF Switch for Auto Focus)	
	DS1, 2	Double Sampling Pulse	
	DSF 0-7	Data In/Out for Shuffling Memory	
INITIAL/LOGO		ABBREVIATIONS	
	DSF 0-7	Input/Output Data to Shuffling Memory (18MHz)	
	DSP	Digital Signal Processor	
	DSP R/B	DSP IC Ready/Busy	
	DSP-48K-H	DSP IC Clock Select	
	DSTB	Data Strobe Signal	
	DSV	Digital Sum Variation	
	DV	Digital Video	
	DVB	Digital Video Broadcast	
	DVC	Digital Video Cassette	
	DVDD	Digital VDD	
	DVIO	Digital Video Input Output	
	DVSS	Digital GND	
E	E2 CS or E2P CS	EEPROM Chip Select	
	E2 R/B	EEPROM Ready/Busy	
	E2P	EEPROM	
	EARP	Earphone	
	EC	Torque Control	
	ECC	Error Correction Cording	
	ECM	Electric Condenser Mic	
	ECR	Reference Voltage for Capstan Torque	
	EDA	Error Correction, DCI, ATF Servo	
	EDT TRIG [L]	Edit Trigger (L)	
	EDIT [H]	Edit (H)	
	EE [H]	EE (H)	
	EE CS	EEPROM Chip Select	
	EE R/B	EEPROM Read (H)/Busy (L)	
	EEPROM	Electric Erasable Programmable Read Only Memory	
	EIS	Electric Image Stabilizer (DIS)	
	EMP	A/D Converter Emphasis Control	
	ENAB	Enable	
	ENV	Envelope	
	EOB	End of Block	
	EP [H]	LP (H)	
	EP/LP [H]	LP (H)	
	EP/LP/SP	LP/SP	
	EP/SS [H]	LP/Slow/Still/Stop (H)	
	EPROMCS	EPROM Chip Select	
	EQ	Equalizer	
	EXT S DATA	Serial Data for Edit	
	EXT SCK	Serial Clock for Edit	
F	FACT MODE	Factory Mode (not used in the service)	
	FB	Feed Back	
	FC	Saw Tooth Signal In	
	FCK	Clock	
	FCO	Saw Tooth Signal Generator	
	FEND	Frame End Pulse	
	FF/REW [L]	First Forward/Rewind (L)	
	FG1 IN	FG1 Pulse Input	
	FG2 IN	FG2 Pulse Input	
	FH2B	FH/2 (15.625KHz / 2=7.8125KHz)	
	FIX OSD	Auto Tracking Off (H)	
	FLICK	Flicker Output	
	FLY ERASE [H]	Flying Erase Head On (H)	
	FM	Field Memory	
	FM MUT [H]	FM Audio Mute (H)	
	FM MUTE [H]	FM Audio Mute (H)	
	FM0-7	Field Memory 0-7	
	FMCO0-3	Field Memory Chrominance Out 0-4	
	FMDIR	Focus Motor Direction	
	FMOEM	Field Memory Enable	
	FMOEO	Field Memory Enable	

INITIAL/LOGO		ABBREVIATIONS	
	FMT1-4	Focus Motor Terminal 1-4	
	FMY00-07	Field Memory Luminance Out 0-7	
	FMY10-07	Field Memory Luminance In 0-7	
	FNO	F Value	
	FPS	Frame Reference Signal	
	FR	Capstan Reverse High	
	FRP	Frame Reference Pulse	
	FRPSO	Frame Start Pulse	
	FUL. E [H]	Full Erase Head On (H)	
	FULL. E [H]	Full Erase Head On (H)	
G	G1, G2, G3	Gap 1, 2 and 3	
	GCA	Gain Control AMP	
	GCNT	Gain Control	
	G-CNT	AGC Adjustment	
	GCTRL	Gain Control	
	GENE	Generator	
	GF	FG AMP Terminal	
	GSW	Ground for Switching Power	
H	H/M/N	Hi-Fi / Mix / Normal	
	H/N	Hi-Fi / Normal	
	H. SYNC	Horizontal Sync	
	HAP	Horizontal Aperture	
	HASW	Head AMP Switching Pulse	
	HB	Hall Bias	
	HBR SET	High Brightness Set	
	HBRST	High Brightness Set	
	HCLR	High Clear	
	HCP	Shift Clock for Horizontal Drive	
	HD	Horizontal Drive Pulse	
	HDTV	High Definition TV	
	HEX	Hexadecimal	
	HG	Hall Gain	
	HID	Head Switching Pulse	
	HLT	High Bright Signal	
	HALL IN(+), (-)	Input Signal from Hall IC	
	HP	Headphone	
	HPF	High Pass Filter	
	HSE	Modulated Data Output	
I	HSP	Timing Pulse for Shuffling Memory	
	HSS	Horizontal Sync Signal	
	HSW	Head Switching Pulse	
	I/F	Interface	
	I-2 C	Inter Integrated Circuit	
	ID(H)	Wide Television (H)	
	IMP	Inter Microprocessor Protocol	
	IN SELA1	Input Select A1 Position	
	IN SELA2	Input Select A2 Position	
	IN SELA3	Input Select A3 Position	
	INS L/R [L]	Insert Lch/Rch (L)	
	INS. [H]	Insert (H)	
	INTER	Interval Recording	
	INV	Inverter	
	IOU	R-Y Analogue Signal Output	
	IOV	B-Y Analogue Signal Output	
	IOY	Y Analogue Signal Output	
	IR	Infrared Rays	
	IRDET	Infrared Ray Detection	
	IREF	Current Adjustment Terminal	
	IRIS/SH	Iris / Shutter Control	
	IRQ	Interrupt Request	


INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	NWE	Write Enable (Low Active)		R-B	R Bias
O	OB	Optical Black		RCB	R Carrier Balance
	OBCNT	Optical Black Control		RE	Read Enable
	OBREF	Reference Voltage for Optical Black Control		RE(F), (S)	Rotary Erase Head Transformer
	OCH	Control AGC Circuit		REB	R Bias
	OE	Output Enable		REC CC	Rec Current Control
	OFH	Horizontal Counted Down Clock Signal (Reference)		REC CCNT	Rec Current Control
	OFS	Offset		RECCTRL	Recording Control Pulse
	OP	Operation AMP Output		RECI	Rec Amp Switch
P	OSD	ON Screen Display		RENCF	Lens Control (Forward)
	OVL	Overlap Pulse		RENCR	Lens Control (Reverse)
	P. FAIL	Power Failure Detect		RERASE	Rotary Erase Head
	P. OFF [H]	Power Off ☉		RF. CHROMA	RF Chrominance Signal
	P. OFF [L]	Power Off ☉		RGBIV1-2	1V Inverted Signal 1-2
	P SW	Power Switch		RGO R/G OFF	Offset Voltage for AWT R
	PB1-3	PNP Base 1-3		RSF	Capstan Direction (Reverse / Stop / Forward)
	PBCTL	Play Back Control		RST	Reset
	PBCTL	Pre-Blanking Control		RSTB	R Strobe
	PBH	Head Amp Switch		RSTPWD	Reset Power Down Input
	PBLK	Pre-Blanking (Pulse)		RSTR	Reset Read
	PC1-3	Corrector of PNP Transistor		RSTW	Reset Write
	PCBM	Carrier Balance		RT	Saw Tooth Terminal
	PCH	Phase Compensator (Hall AMP)		RVCO	Resistor for Oscillation
	PCI	Phase Compensator (Current)		RW	Read Write
	PCO	Phase Compensator Out		RWAE	Read Write Enable
	PCS	Switching Power Control	S	S IN	Serial Data Input
	PCV	Phase Compensator (Voltage)		S OUT	Serial Data Output
	PE	Emitter of PNP Transistor		S-PHOTO	Supply Photo Transistor
	PED	Pedestal		S-RL. PLS	Supply Reel Pulse
	PEDECNT	Pedestal Control		S. CLK	Serial Clock
	PENO	Alarm (L)		S. CLK/AV	Serial Clock/AV
	PFP	Pilot Frame Position		S. DATA	Serial Data
	PGA, ■	Power Ground A, B		S. TAB [L]	Safety Tab SW ON ☉
	PGC	Pulse Generator Comparator		S/H	Sampling Hold
	PGI	Pulse Generator Input		S/PIN	SECAM/PAL/NTSC
	PGMM	Pulse Generator Monostable Multivibrator		S/S	Start/Stop
	PGO	Output of Pulse Generator AMP		SBD	Serial Data
	PMODE	Select Signal for Normal / Wide Screen		SBI	Serial Data Input
	PON	Power On		SBO	Serial Data Output
	POR	Power On Reset		SBT	Serial Clock
	POSCOM	Common Position		SC IN	Serial Clock Input
	PREAMP	Pre-AMP		SC OUT	Serial Clock Output
	PREBLK	Pre-Blanking		SCAN0-5	Key Scan 0-5
	PT	Protect for V Voltage		SCK	Serial Clock
	PWM	Pulse Width Modulation		SCK SELECT	Serial Clock Select
	PWMB	Pulse Width Modulation Pulse		SCR	Search
	PWRFAIL	Power Failure Detect		SCR, S.C.R.	Still Cue Review
Q	Q2H	Source Output Select		SEG.	Segment
				SET	White Balance Set
R	R CTL P	Recorded Control Pulse (+)		SH/IRIS	Shutter/Iris Control
	R CTL R	Recorded Control Pulse (-)		SHIFT	Capasitor for Phase Shift
	R/B	Read/Busy		SI	Serial Data Input
	R/L	Direction Control for Data Transmission		SiC	Shift In Clock Input
	R/S/F	Reverse ☉/Stop ☹/Forward ☺		SIF	Sound Intermediate Frequency
	RA	Recording AMP		SIOC	Serial In/Out Control
	RA1	Rec AMP 1		SMCE	Shuffling Memory Chip Enable
	RAC AC	Rec Audio Current		SMRS	Shuffling Memory Read Strobe
	RAD	Read Address Data		SMWE	Shuffling Memory Write Enable
	RAE	Read Address Enable		SMWS	Shuffling Memory Read Strobe
	RB	Read Busy		SNAP	Snap Shot
				SNS LED	Sensor LED
				SO	Serial Data Output



INITIAL/LOGO	ABBREVIATIONS	INITIAL/LOGO	ABBREVIATIONS
	SPA ATF Smapping Pulse SPEN Bit Shift Register Enable SPK Speaker SPO Reset for Switching Power SPST 8 Bit Shift Register Strobe SREELP Supply Reel Pulse SRT Start SSA Start Sync block Area SSS [L] Slow/Still/Stop SSW Select Signal for Low Pass Filter ST5V Safety Tab 5V STAB Safety Tab Switch STB Stand by Signal STB Strobe SWB Switching Pre-Drive Pulse SYL EC Cylinder Torque Control SYL FG Cylinder FG		VDDX X Drive Power for Colour LCD VDDXY XY Drive Power for Colour LCD VDDY Y Drive Power for Colour LCD VDREC Video Delayed Rec Vgg Voltage for Gate IC Vgl Gate off Voltage VID Video Signal Out VIN Video In VITC Vertical Interval Time Code VITERBI One of Signal Detection Method VL Low Voltage VLC Variable Length Cording VLOCKP Artificial Sync Pulse VLP Artificial Sync Pulse VM Motor Voltage VMD Velocity Mode Data VMD1-3 Electric Shutter Mode VMODE NTSC/PAL Select Switch VMVH VH Filter Switching VORP Video Overlap VRB Voltage Reference Bottom VRBS Voltage Reference Bottom Output VREFH Reference Voltage High Side VREFL Reference Voltage Low Side VRI Reference Voltage Input VRO Reference Voltage Output VRT Voltage Reference Top VRTS Voltage Reference Top Output VS Switching Comparator VSS Vertical Sync Signal
T	T-PHOTO Take-Up Photo Transistor T-RL PLS Take-Up Reel Pulse T. BUSCLK Timer Bus Clock T. BUSLSN Timer Bus Listen T. BUSTLK Timer Bus Talk TBC Time Base Control TFT Thin Film Transistor TH Thermostat for Battery TI Test Mode Select TL Torque Limit TM Sub Code TMD Sub Code Data TRE Tracking Error Signal TREEL(P) Take-up Reel (Pulse) TRFIX Tracking Fix TRIWAVE Tracking Wave TRP Tracking Position TRP Trap TSR Head Switching Reference TST Time Scale Transfer TU. AUDIO Tuner Audio TU. GND Tuner GND TU. V. IN Tuner Video Signal Input TU. VIDEO Tuner Video	W	W/N Mode Select for Window Mode W/N Wide / Normal WAD Write Address Enable WAE Write Address Enable WAERAE Write Address Enable WARI Interrupt WB White Balance WE Write Enable WEM Memory Write Enable WSB B AGC Control WSR R AGC Control WTV Wide TV
U	U/V SEL R-Y/B-Y Select Signal UNLOAD Un-Loading UNRE Microprocessor Read Enable UNWE Microprocessor Write Enable UV R-Y/B-Y UV SEL R-Y/B-Y Select Signal	X	X IN Oscillator Input X OUT Oscillator Output XP FG Logic Reset
V	V. REF Reference Voltage V. EE [H] Video EE (H) V. EE [L] Video EE (L) VCO REF Reference Oscillator V1-V4 V. CCD Drive Pulse VB VH Filter Switching VCE Power Terminal VCNTL Video Control VCO Voltage Control Oscillator VCP Shift Clock Output for Vertical Drive VCTLD Video Control VCTRL Voltage Charge Control VD Vertical Drive Pulse	Y	Y FM0-7 Y Field Memory 0-7 YCE Cylinder Error Code YGC Y Gain Control YMO 0-7 Y Field Memory 0-7 YNCST Noise Canceller YNR Luminance Noise Reduction YSDP 0-7 Digital Y Out 0-7


The diagram illustrates the internal architecture of a VCR, divided into several key functional blocks:

- INPUT / OUTPUT:** Manages external connections including Front S-Video, AV3, AV2, AV1, RF Converter, S-Video Out, AV2 A (R) IN, AV2 A (L) IN, AV1 A (R) OUT, AV1 A (L) OUT, AV1 A (R) IN, AV1 A (L) IN, Audio Out (R-CH, L-CH), Rear Audio (R-CH IN, L-CH IN), Front Audio (R-CH IN, L-CH IN), and Headphone Output.
- ANALOG Y/C:** Processes analog video and color signals using ICs like 3903 (Video Sele), 3801 (Y/C), 3004 (AGC), 3008 (Y/C SEP), 3001 (Y/C), 3007 (Y/C), 3009 (Y/C), 3010 (Y/C), 3011 (Y/C), 3012 (Y/C), 3013 (Y/C), 3014 (Y/C), 3015 (Y/C), 3016 (Y/C), 3017 (Y/C), 3018 (Y/C), 3019 (Y/C), 3020 (Y/C), 3021 (Y/C), 3022 (Y/C), 3023 (Y/C), 3024 (Y/C), 3025 (Y/C), 3026 (Y/C), 3027 (Y/C), 3028 (Y/C), 3029 (Y/C), 3030 (Y/C), 3031 (Y/C), 3032 (Y/C), 3033 (Y/C), 3034 (Y/C), 3035 (Y/C), 3036 (Y/C), 3037 (Y/C), 3038 (Y/C), 3039 (Y/C), 3040 (Y/C), 3041 (Y/C), 3042 (Y/C), 3043 (Y/C), 3044 (Y/C), 3045 (Y/C), 3046 (Y/C), 3047 (Y/C), 3048 (Y/C), 3049 (Y/C), 3050 (Y/C), 3051 (Y/C), 3052 (Y/C), 3053 (Y/C), 3054 (Y/C), 3055 (Y/C), 3056 (Y/C), 3057 (Y/C), 3058 (Y/C), 3059 (Y/C), 3060 (Y/C), 3061 (Y/C), 3062 (Y/C), 3063 (Y/C), 3064 (Y/C), 3065 (Y/C), 3066 (Y/C), 3067 (Y/C), 3068 (Y/C), 3069 (Y/C), 3070 (Y/C), 3071 (Y/C), 3072 (Y/C), 3073 (Y/C), 3074 (Y/C), 3075 (Y/C), 3076 (Y/C), 3077 (Y/C), 3078 (Y/C), 3079 (Y/C), 3080 (Y/C), 3081 (Y/C), 3082 (Y/C), 3083 (Y/C), 3084 (Y/C), 3085 (Y/C), 3086 (Y/C), 3087 (Y/C), 3088 (Y/C), 3089 (Y/C), 3090 (Y/C), 3091 (Y/C), 3092 (Y/C), 3093 (Y/C), 3094 (Y/C), 3095 (Y/C), 3096 (Y/C), 3097 (Y/C), 3098 (Y/C), 3099 (Y/C), 3100 (Y/C), 3101 (Y/C), 3102 (Y/C), 3103 (Y/C), 3104 (Y/C), 3105 (Y/C), 3106 (Y/C), 3107 (Y/C), 3108 (Y/C), 3109 (Y/C), 3110 (Y/C), 3111 (Y/C), 3112 (Y/C), 3113 (Y/C), 3114 (Y/C), 3115 (Y/C), 3116 (Y/C), 3117 (Y/C), 3118 (Y/C), 3119 (Y/C), 3120 (Y/C), 3121 (Y/C), 3122 (Y/C), 3123 (Y/C), 3124 (Y/C), 3125 (Y/C), 3126 (Y/C), 3127 (Y/C), 3128 (Y/C), 3129 (Y/C), 3130 (Y/C), 3131 (Y/C), 3132 (Y/C), 3133 (Y/C), 3134 (Y/C), 3135 (Y/C), 3136 (Y/C), 3137 (Y/C), 3138 (Y/C), 3139 (Y/C), 3140 (Y/C), 3141 (Y/C), 3142 (Y/C), 3143 (Y/C), 3144 (Y/C), 3145 (Y/C), 3146 (Y/C), 3147 (Y/C), 3148 (Y/C), 3149 (Y/C), 3150 (Y/C), 3151 (Y/C), 3152 (Y/C), 3153 (Y/C), 3154 (Y/C), 3155 (Y/C), 3156 (Y/C), 3157 (Y/C), 3158 (Y/C), 3159 (Y/C), 3160 (Y/C), 3161 (Y/C), 3162 (Y/C), 3163 (Y/C), 3164 (Y/C), 3165 (Y/C), 3166 (Y/C), 3167 (Y/C), 3168 (Y/C), 3169 (Y/C), 3170 (Y/C), 3171 (Y/C), 3172 (Y/C), 3173 (Y/C), 3174 (Y/C), 3175 (Y/C), 3176 (Y/C), 3177 (Y/C), 3178 (Y/C), 3179 (Y/C), 3180 (Y/C), 3181 (Y/C), 3182 (Y/C), 3183 (Y/C), 3184 (Y/C), 3185 (Y/C), 3186 (Y/C), 3187 (Y/C), 3188 (Y/C), 3189 (Y/C), 3190 (Y/C), 3191 (Y/C), 3192 (Y/C), 3193 (Y/C), 3194 (Y/C), 3195 (Y/C), 3196 (Y/C), 3197 (Y/C), 3198 (Y/C), 3199 (Y/C), 3200 (Y/C), 3201 (Y/C), 3202 (Y/C), 3203 (Y/C), 3204 (Y/C), 3205 (Y/C), 3206 (Y/C), 3207 (Y/C), 3208 (Y/C), 3209 (Y/C), 3210 (Y/C), 3211 (Y/C), 3212 (Y/C), 3213 (Y/C), 3214 (Y/C), 3215 (Y/C), 3216 (Y/C), 3217 (Y/C), 3218 (Y/C), 3219 (Y/C), 3220 (Y/C), 3221 (Y/C), 3222 (Y/C), 3223 (Y/C), 3224 (Y/C), 3225 (Y/C), 3226 (Y/C), 3227 (Y/C), 3228 (Y/C), 3229 (Y/C), 3230 (Y/C), 3231 (Y/C), 3232 (Y/C), 3233 (Y/C), 3234 (Y/C), 3235 (Y/C), 3236 (Y/C), 3237 (Y/C), 3238 (Y/C), 3239 (Y/C), 3240 (Y/C), 3241 (Y/C), 3242 (Y/C), 3243 (Y/C), 3244 (Y/C), 3245 (Y/C), 3246 (Y/C), 3247 (Y/C), 3248 (Y/C), 3249 (Y/C), 3250 (Y/C), 3251 (Y/C), 3252 (Y/C), 3253 (Y/C), 3254 (Y/C), 3255 (Y/C), 3256 (Y/C), 3257 (Y/C), 3258 (Y/C), 3259 (Y/C), 3260 (Y/C), 3261 (Y/C), 3262 (Y/C), 3263 (Y/C), 3264 (Y/C), 3265 (Y/C), 3266 (Y/C), 3267 (Y/C), 3268 (Y/C), 3269 (Y/C), 3270 (Y/C), 3271 (Y/C), 3272 (Y/C), 3273 (Y/C), 3274 (Y/C), 3275 (Y/C), 3276 (Y/C), 3277 (Y/C), 3278 (Y/C), 3279 (Y/C), 3280 (Y/C), 3281 (Y/C), 3282 (Y/C), 3283 (Y/C), 3284 (Y/C), 3285 (Y/C), 3286 (Y/C), 3287 (Y/C), 3288 (Y/C), 3289 (Y/C), 3290 (Y/C), 3291 (Y/C), 3292 (Y/C), 3293 (Y/C), 3294 (Y/C), 3295 (Y/C), 3296 (Y/C), 3297 (Y/C), 3298 (Y/C), 3299 (Y/C), 3300 (Y/C), 3301 (Y/C), 3302 (Y/C), 3303 (Y/C), 3304 (Y/C), 3305 (Y/C), 3306 (Y/C), 3307 (Y/C), 3308 (Y/C), 3309 (Y/C), 3310 (Y/C), 3311 (Y/C), 3312 (Y/C), 3313 (Y/C), 3314 (Y/C), 3315 (Y/C), 3316 (Y/C), 3317 (Y/C), 3318 (Y/C), 3319 (Y/C), 3320 (Y/C), 3321 (Y/C), 3322 (Y/C), 3323 (Y/C), 3324 (Y/C), 3325 (Y/C), 3326 (Y/C), 3327 (Y/C), 3328 (Y/C), 3329 (Y/C), 3330 (Y/C), 3331 (Y/C), 3332 (Y/C), 3333 (Y/C), 3334 (Y/C), 3335 (Y/C), 3336 (Y/C), 3337 (Y/C), 3338 (Y/C), 3339 (Y/C), 3340 (Y/C), 3341 (Y/C), 3342 (Y/C), 3343 (Y/C), 3344 (Y/C), 3345 (Y/C), 3346 (Y/C), 3347 (Y/C), 3348 (Y/C), 3349 (Y/C), 3350 (Y/C), 3351 (Y/C), 3352 (Y/C), 3353 (Y/C), 3354 (Y/C), 3355 (Y/C), 3356 (Y/C), 3357 (Y/C), 3358 (Y/C), 3359 (Y/C), 3360 (Y/C), 3361 (Y/C), 3362 (Y/C), 3363 (Y/C), 3364 (Y/C), 3365 (Y/C), 3366 (Y/C), 3367 (Y/C), 3368 (Y/C), 3369 (Y/C), 3370 (Y/C), 3371 (Y/C), 3372 (Y/C), 3373 (Y/C), 3374 (Y/C), 3375 (Y/C), 3376 (Y/C), 3377 (Y/C), 3378 (Y/C), 3379 (Y/C), 3380 (Y/C), 3381 (Y/C), 3382 (Y/C), 3383 (Y/C), 3384 (Y/C), 3385 (Y/C), 3386 (Y/C), 3387 (Y/C), 3388 (Y/C), 3389 (Y/C), 3390 (Y/C), 3391 (Y/C), 3392 (Y/C), 3393 (Y/C), 3394 (Y/C), 3395 (Y/C), 3396 (Y/C), 3397 (Y/C), 3398 (Y/C), 3399 (Y/C), 3400 (Y/C), 3401 (Y/C), 3402 (Y/C), 3403 (Y/C), 3404 (Y/C), 3405 (Y/C), 3406 (Y/C), 3407 (Y/C), 3408 (Y/C), 3409 (Y/C), 3410 (Y/C), 3411 (Y/C), 3412 (Y/C), 3413 (Y/C), 3414 (Y/C), 3415 (Y/C), 3416 (Y/C), 3417 (Y/C), 3418 (Y/C), 3419 (Y/C), 3420 (Y/C), 3421 (Y/C), 3422 (Y/C), 3423 (Y/C), 3424 (Y/C), 3425 (Y/C), 3426 (Y/C), 3427 (Y/C), 3428 (Y/C), 34


3-3. SYSTEM CONTROL & SERVO BLOCK DIAGRAM








3-6. VIDEO BLOCK DIAGRAM




3-7. SOLENOID BLOCK DIAGRAM




3-8. POWER SUPPLY SCHEMATIC DIAGRAM


CAUTION THE STRIPED FRAME INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT.
PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCTS.



3-9. LOADING SECTION IN MECHANISM DRIVE SCHEMATIC DIAGRAM




NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE THIS DIAGRAM IS STOP MODE. NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.




8: TO SOLENOID SECTION (Page 13)
C: TO LOADING SECTION (Page 26)




3-12. SOLENOID SECTION IN MECHANISM DRIVE SCHEMATIC DIAGRAM




3-13. POWER SECTION IN MAIN SCHEMATIC DIAGRAM



3-14. EDIT/SYSTEM CONTROL & SERVO SECTION IN MAIN, 5P JACK SCHEMATIC DIAGRAMS



IC2203 (M3777VACX): TIMER MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION																		
1	AUDIO. DEF (H)	O	DECODER IC reset signal	26	D.A. REC (H)	O	Linear Audio Rec Timing H Output at timing of BIAS (H) At begining of REC, Set BIAS (H) at 140msec. later of D.A. REC (H) set. At end of REC, release BIAS (H) at 140msec. former of D.A. REC (H) reset 																		
2	FORCE MONI (H)	O	U.K. Multi: Audio Detects Auto/off switch																						
3	AFC (S)	I	AFC S CURVE																						
4	No/M1/B1/M2/Ste	I	Audio mode detection for display on the OSD <table><tr><th>INPUT VOLTAGE</th><th>DISPLAY</th></tr><tr><td>MORE THAN 4.2V</td><td>NO DISPLAY</td></tr><tr><td>3.0 ~ 4.2</td><td>MONO1</td></tr><tr><td>2.0 ~ 3.0</td><td>BILINGUAL</td></tr><tr><td>0.8 ~ 2.0</td><td>MONO 1+2</td></tr><tr><td>LESS THAN 0.8V</td><td>STEREO</td></tr></table>					INPUT VOLTAGE	DISPLAY	MORE THAN 4.2V	NO DISPLAY	3.0 ~ 4.2	MONO1	2.0 ~ 3.0	BILINGUAL	0.8 ~ 2.0	MONO 1+2	LESS THAN 0.8V	STEREO						
INPUT VOLTAGE	DISPLAY																								
MORE THAN 4.2V	NO DISPLAY																								
3.0 ~ 4.2	MONO1																								
2.0 ~ 3.0	BILINGUAL																								
0.8 ~ 2.0	MONO 1+2																								
LESS THAN 0.8V	STEREO																								
5	L6/U6/U4/U2/U2L	I	CYLINDER (HIFI/NORMAL) SELECT <table><tr><th>INPUT VOLTAGE</th><th>CYLINDER</th><th>HIFI/NORMAL</th></tr><tr><td>MORE THAN 4.2V</td><td>LDD 6CH</td><td>HIFI</td></tr><tr><td>3.0 ~ 4.2</td><td>UDD 6CH</td><td>HIFI</td></tr><tr><td>2.0 ~ 3.0</td><td>UDD 2CH (NO LP)</td><td>NORMAL</td></tr><tr><td>0.8 ~ 2.0</td><td>UDD 2CH (LP)</td><td>NORMAL</td></tr><tr><td>LESS THAN 0.8V</td><td>UDD 4CH</td><td>NORMAL</td></tr></table>	INPUT VOLTAGE	CYLINDER	HIFI/NORMAL	MORE THAN 4.2V	LDD 6CH	HIFI	3.0 ~ 4.2	UDD 6CH	HIFI	2.0 ~ 3.0	UDD 2CH (NO LP)	NORMAL	0.8 ~ 2.0	UDD 2CH (LP)	NORMAL	LESS THAN 0.8V	UDD 4CH	NORMAL	27	BIAS (L)	O	Linear Audio BIAS OSC SW At Linear Audio Rec, H/L output at timing of D.A. REC (H)
				INPUT VOLTAGE	CYLINDER	HIFI/NORMAL																			
				MORE THAN 4.2V	LDD 6CH	HIFI																			
				3.0 ~ 4.2	UDD 6CH	HIFI																			
2.0 ~ 3.0	UDD 2CH (NO LP)	NORMAL																							
0.8 ~ 2.0	UDD 2CH (LP)	NORMAL																							
LESS THAN 0.8V	UDD 4CH	NORMAL																							
6	Nor/Ser/T1/T2	I	MODE SELECT <table><tr><th>INPUT VOLTAGE</th><th>MODE</th></tr><tr><td>MORE THAN 4.0V</td><td>NORMAL</td></tr><tr><td>2.5 ~ 4.0</td><td>SERVICE</td></tr><tr><td>1.0 ~ 2.5</td><td>TEST 2</td></tr><tr><td>LESS THAN 1.0V</td><td>TEST 1</td></tr></table>	INPUT VOLTAGE	MODE	MORE THAN 4.0V	NORMAL	2.5 ~ 4.0	SERVICE	1.0 ~ 2.5	TEST 2	LESS THAN 1.0V	TEST 1	28	FM. MUTE (H)	O	Audio Mute Output Power off, Head cleaning, Timer stand-by, VPS/PDC stand-by: H In VV mode, Except std tape run: H Former and later at EE/VV switch								
				INPUT VOLTAGE	MODE																				
				MORE THAN 4.0V	NORMAL																				
				2.5 ~ 4.0	SERVICE																				
1.0 ~ 2.5	TEST 2																								
LESS THAN 1.0V	TEST 1																								
29	PB/TUN/LINE	O	Normal Audio Circuit Select Normal Audio P.B: H Normal Audio Rec/LINE mode: L Normal Audio Rec/TUNER mode: M																						
30	FULL. ERASE (H)	O	FE Head OSC SW																						
7	S-PHOT	I	Tape Supply Photo Sensor Detect	31	POS. SW3	I	Mechanical Position Input																		
				32	POS. SW2	I																			
				33	POS. SW1	I																			
				34	GND	—																			
				35	GND	—	—																		
				36	16M. START (H)	I	16 MHz START Hight																		
				37	5V (D)	I	5V (D)																		
				38	16MHz. IN	I	16 MHz IN																		
				39	16MHz. OUT	O	16 MHz OUT																		
				40	GND (OSC)	I	—																		
8	T-PHOT	I	Tape Take-up Photo Sensor Detect	41	32KHz. IN	O	32 kHz IN																		
9	TRACKING ENVE	O	Auto Tracking/Video Enve Detect Input for CVC	42	32KHz. OUT	I	32 kHz OUT																		
10	ABS. NORM (L)	I	Lower output level Detect of FM audio	43	RESET (L)	O	RESET (L)																		
11	CURRENT. LIMIT	O		44	FIP (L)	I	FIP On/Off Select																		
12	REC CUR	O	REC CURR CTL for REC AI (EE)/Picture VR Value out for P.B. AI (VV)	45	FIP/OSD CS	O	FIP Driver/OSD Micon chip Select At Timing of Data transmission to FIP driver: L At Timing of Data transmission to OSD Micon: H																		
13	ART. V/H/N	O																							
14	REMOCON	I	REMOTE/DIGITAL RINK INPUT																						
15	ROTARY. SW	O	ROTARY SW																						
16	H.A. SW	O	HEAD AMP SW	46	CH CHANGE (H)	O	Varing edge output of channel (H)																		
17	ENVE. SLECT	I	ENVELOPE SELECT	47	CH START (H)	O	Audio Carrier Auto Det start Edge output at Tuner preset																		
18	VIDEO. H. SW	O	VIDEO HEAD SW	48	AAA OFF (H)	O	Output during audio IC auto adj.																		
19	AUDIO. H. SW	O	AUDIO HEAD SW	49	AI MES (H)	O	Output during AI REC measurement (Fix carrier output)																		
20	REC (H)	O	REC/P.B Select of video/Audio Circuit REC Mode: H	50	HALF WAVE (H)	O	Capstan Driver Full Wave/Half Wave select																		
21	D. REC (H)	O	Video Rec Curr Timing (H. SW Sync.)																						
22	C. EMPHA (H)	O	Video/FM Audio Rec. Curr Up (H. SW Sync)	51	P. OFF (H)	O	Output during Power Off H: at Power off, Timer stand-by, etc L: at Head cleaning, Timer confirmation, VPS/PDC stand-by, ACS																		
23	D. FM. REC (H)	O	FM Audio Rec Curr Timing (H. SW Sync.)																						
24	VIDEO. EE (L)	O	Video EE/VV Select (H SW Sync.) EE: L, VV: H																						
25	TRICK (L)	O	Trick Plag Mode Output Except Std tape run in VV: L																						
				52	FF/REW (L)	O	CTL signal Filter/Switch at FF/RES																		
				53	PB AI1 (H)	O	PB AI CONTROL																		
				54	PB AI2 (H)	O	PB AI CONTROL																		
				55	UNLOADING (H)	O	LOADING MOTOR CONTROL																		
				56	LOADING (H)	O																			

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
57	SP ④	O	TAPE RUN SPEED OUTPUT NTSC2H: H PAL3H: H	76	CAP. R/F	O	CAPSTAN REVERSE ④/FORWARD ④
				77	CAP. ET	O	CAPSTAN ERROR TORQUE
				78	CYL. ET	O	CYLINDER ERROR TORQUE
58	SLEEP ④	O	Super Power Save Mode Set Output (L)	79	S. REEL. PULSE	I	Pulse Input from Real Sensor
59	PAL-I/BG/DK	O	Broadcast System Output for video circuit control	80	T. REEL. PULSE	I	Pulse Input from Real Sensor
60	SECAM/PAL	O	Broadcast System Output for video circuit control	81	STAB ④	I	Safety Tab Detect Exist: L, Non: H
61	NTSC ④	O	Broadcast System Output for video circuit control	82	POWER KEY ④	I	Main Power ON/OFF Key Input
62	PAL/MESECAM	O	Broadcast System Output for video circuit control	83	SHORT DN	I	OSC Trouble Detect of REC Mode
63	EDITTRIG ④	I/O	Synchronizing Edit Control	84	C SYNC	I	COLOR SYNC
64	PREROLL ④	I/O	—	85	CAP. FG	I	CAPSTAN FG
65	5P/T2. DATA. OUT	O	Edit 5P/Serial Communication for Test	86	CYL. PFG	I	CYLINDER PG/FG
66	5P/T2. DATA. IN	I	Edit 5P/Serial Communication for Test	87	SECAM24 ④	I	26μ/24μ Head Select Input H: 24μ
67	5P/T2. CLOCK	O	Edit 5P/Serial Communication for Test	88	GND	—	—
68	T-BUS/IC. OUT	O	OSD Micon/FIP Driver Serial Communication	89	OREF	O	REFERENCE OUT
69	T-BUS/IC. IN	I	OSD Micon/FIP Driver Serial Communication	90	IREF	I	REFERENCE IN
70	T-BUS/IC. CLK	O	OSD Micon/FIP Driver Serial Communication	91	CTL. HEAD (-)	I	CONTROL HEAD (-)
71	IIC. CLOCK	O	Tuner/FM Audio IC Serial Communication	92	CTL. HEAD (+)	I	CONTROL HEAD (+)
72	IIC. DATA	I/O	Tuner/FM Audio IC Serial Communication	93	CTL. AMP. SW	O	CONTROL AMP. SW
73	125Hz	O	Int. OSC Output for Main Clock Adj.	94	CTL. AMP. IN	I	CONTROL AMP. IN
74	STANDBY ④	O	Display Output at VTR Stand-by	95	CTL. AMP. REF	I	CONTROL AMP. REFERENCE
75	POWER FAIL ④	I	Power Stoppage Detect.	96	CTL. AMP. GND	—	CONTROL AMP. GND
				97	PB. CTL. OUT	O	PLAYBACK CONTROL OUT
				98	5V (A)	I	5V (A)
				99	5V (AD)	I	5V (AD)
				100	CH END ④	I	Audio Carrier Auto Detect Completion Input at Tuner Preset

IC2205 (M38027V4EE): EDIT MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	P62	O	OSD CLK	33	P17/AD15	O	NC
2	P61	O	OSD DATA	34	P16/AD14	O	NC
3	P60	O	OSD CS	35	P15/AD13	O	INSIDE ④
4	P57/INT3	O	OSD ON ④	36	P14/AD12	O	NC
5	P56/PWM	O	NC	37	P13/AD11	O	NC
6	P55/CNTR1	O	NC	38	P12/AD10	O	NC
7	P54/CNTR0	I	L CLK CNT ④	39	P11/AD9	O	NC
8	P53/Srdy2	O	NC	40	P10/AD8	O	NC
9	P52/SCLK2	I	SYS CLK	41	P07/AD7	I	NTSC ④/PAL ④
10	P51/SOUT2	O	SYS OUT	42	P06/AD6	O	NC
11	P50/SIN2	I	SYS IN	43	P05/AD5	O	NC
12	P47/Srdy1	O	DATA INH	44	P04/AD4	O	NC
13	P46/CLK1	I	CLK INPUT	45	P03/AD3	O	NC
14	P45/TXD	O	DATA OUT	46	P02/AD2	O	NC
15	P44/RXD	I	DATA IN	47	P01/AD1	O	BUS SELECT (B)
16	P43/INT2	O	NC	48	P00/AD0	O	BUS SELECT (A)
17	P42/INT1	O	NC	49	P37	I	CHECK ④
18	CNVss	—	GND	50	P36	O	NC
19	RESET	—	RESET ④	51	P35	O	NC
20	P41/INT0	I	L CLK	52	P34	O	NC
21	P40/INT4	I	5P CLK	53	P33	O	NC
22	Xin	—	OSC IN	54	P32	O	COLOR ADJ ④
23	Xout	—	OSC OUT	55	P31/DA2	I	TINT
24	Vss	—	GND	56	P30/DA1	I	COLOR
25	P27	O	NC (JOG LED ④)	57	Vcc	—	5V
26	P26	O	NC (EDIT21P)	58	Vref	—	5V
27	P25	O	NC (AVVTR ④)	59	AVss	—	GND
28	P24	O	NC (TBC SERCH ④)	60	P67	I	EE DATA IN
29	P23	O	NC (TBC TRICK ④)	61	P66	O	EE DATA OUT
30	P22	O	NC (TBC ON)	62	P65	O	EE CLK
31	P21	O	NC	63	P64	O	EE CS0
32	P20	O	NC (EDIT ④)	64	P63	I	NC

IC2207 (M66010GP): SUB MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	DO	O	Serial Data Output	17	MIX (L)	I	Audio Mixing (L)
2	DI	I	Serial Data Input	18	PB (L)	I	PLAY BACK (L)
3	CLK	I	Serial clock	19	REC (L)	I	REC (L)
4	CS	I	Chip select	20	PR (L)	I	Preroll Connect (L)
5	VCC	I	VCC	21	8M (L)	I	8mm Connect (L)
6	S	I	Power ON (L)	22	RS (L)	I	RS232C Connect (L)
7	GND	—	—	23	DV (L)	I	DV Terminal Connect (L)
8	ED2 (H)	I	TV (H)	24	5P (L)	I	5P Terminal Connect (L)
9	MUSE (L)	I	Muse (L)	25	S TAB (L)	I	Safety Tab SW
10	L2FM (L)	I	L2 Full Mode (L)	26	C LIM	I	CURR. Limit
11	L1FM (L)	I	L1 Full Mode (L)	27	P03	I	Position SW3
12	CAS L/S	I	Cassette Detect L cassette (H)/S cassette (L)	28	P02	I	Position SW2
13	BIL (L)	I	Bilingual (L)	29	P01	I	Position SW1
14	STE (L)	I	Stereo (L)	30	DOWN	I	Tray Down (L)
15	RSTOP (L)	I	Reel Driver destruction detect Input	31	OPEN	I	Tray Open (L)
16	GND	—	—	32	CLOSE	I	Tray Close (L)

IC2208 (M66010GP): SUB MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	DO	O	Serial Data Output	17	NC	—	—
2	DI	I	Serial Data Input	18	NC	—	—
3	CLK	I	Serial Data Clock	19	NC	—	—
4	CS	I	Chip Select	20	NC	—	—
5	VCC	I	VCC	21	RCH (H)	O	R CH (H)
6	S	I	Power On (L)	22	LCH (H)	O	L CH (H)
7	GND	—	—	23	MIX (L)	O	Mix (L)
8	NC	—	—	24	S2 (L)	O	S Output Terminal widetfull (L)
9	NC	—	—	25	A3 (H)	O	Input Select (H)
10	NC	—	—	26	A2 (H)	O	Input Select (H)
11	NC	—	—	27	A1 (H)	O	Input Select (H)
12	NC	—	—	28	LINE (L)	O	Line Input Select (L)
13	NC	—	—	29	WIDE (L)	O	S Output Terminal widetfull (L)
14	NC	—	—	30	TV/VTR (H)	O	TV/VTR (H)
15	NC	—	—	31	P OFF (H)	O	Power off (H)
16	GND	—	—	32	J CLK (L)	O	Jast Clock (L)

EDIT/SYSTEM CONTROL & SERVO ICs DC VOLTAGE CHART (Mini DV : SP MODE)

REF. NO.	IC2201																			
MODE	1	2	3																	
STOP	4.9	5.0	0																	
PLAY	4.9	4.9	■																	
REC	4.9	5.0	0																	
F.F	4.9	4.9	■																	
REW	4.9	4.9	0																	
REF. NO.	IC2202																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	4.8	4.0	4.0	4.0	4.9	0	0	0	5.0	5.0	4.6	4.6	4.6	4.6	4.6	5.0				
PLAY	4.8	4.0	4.0	4.0	4.9	■	0	0	4.9	4.9	4.6	4.6	4.6	4.6	4.9	4.6	4.9			
REC	4.8	4.0	4.0	4.0	4.9	0	■	■	5.0	5.0	4.6	4.6	4.6	4.6	4.9	4.6	5.0			
F.F	4.8	4.0	4.0	4.0	4.9	■	■	■	4.9	4.9	4.6	4.6	4.6	4.6	4.9	4.6	4.9			
REW	4.8	4.0	4.0	4.0	4.9	0	■	■	4.9	4.9	4.6	4.6	4.6	4.6	4.9	4.6	5.0			
REF. NO.	IC2203																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	0	■	2.7	5.0	5.0	4.9	■	■	0	■	■	1.6	4.7	5.1	0	■	0.2	0	0	0
PLAY	0	0	2.7	4.9	4.9	4.9	■	■	0	■	0	1.6	■	5.1	■	■	0.1	0	0	0
REC	0	0	0.1	5.0	4.9	4.9	0	0	0	0	0	1.6	5.0	5.1	0	0	0.2	0	0	■
F.F	0	0	2.8	4.9	4.9	4.9	0	0	0	0	0	1.6	4.7	5.1	0	0	0.2	0	0	■
REW	■	■	2.7	4.9	4.9	4.9	0	0	0	■	0	1.6	4.7	5.1	■	0	0.2	0	0	0
REF. NO.	IC2203																			
MODE	21	22	23	24	25	26	27	■	29	30	31	32	33	34	35	36	37	38	39	40
STOP	0	0	0	0	4.7	0	0	4.7	0	0	0	0	0	0	■	4.7	4.7	2.2	2.1	0
PLAY	0	0	0	0	4.7	0	0	4.7	0	0	0	0	■	■	0	4.7	4.7	2.2	2.1	0
REC	0	0	0	0	4.7	0	0	4.7	0	0	0	0	■	■	0	4.7	4.7	2.2	2.2	0
F.F	0	0	0	0	4.7	0	0	4.7	0	0	0	0	0	0	0	4.7	4.7	2.2	2.1	0
REW	0	0	0	0	4.7	0	0	4.7	0	0	0	0	0	0	0	4.7	4.7	2.2	2.1	0
REF. NO.	IC2203																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	■	59	■
STOP	1.3	1.3	4.7	0	2.4	0	0	0	■	0.5	■	4.7	■	■	0	0	4.7	4.7	0.4	0
PLAY	1.3	1.3	—	0	2.4	0	0	0	0	1.0	0	4.7	0	■	0	0	4.7	4.7	0.5	0
REC	1.3	1.3	—	0	2.3	0	■	■	■	0.3	■	4.7	0	0	0	0	4.7	4.7	0.5	0
F.F	1.3	1.3	1.3	—	2.4	■	■	■	■	0.2	0	4.7	0	0	0	0.2	4.7	4.7	0.2	■
REW	1.3	1.3	4.7	—	2.4	■	■	■	■	0.3	■	4.7	0	■	0	0	4.7	4.7	0.2	0
REF. NO.	IC2203																			
MODE	61	62	63	64	65	66	67	68	■	70	71	72	73	74	75	76	77	78	79	80
STOP	0	0	5.0	0	3.6	4.2	4.5	4.4	4.4	4.4	2.9	2.9	2.4	4.7	5.0	0	0	4.0	■	■
PLAY	■	■	5.0	■	3.6	4.2	4.6	4.4	4.4	4.4	2.9	2.9	2.3	4.7	5.0	■	0	3.9	0	0
REC	■	0	5.0	0	3.6	4.1	4.6	4.4	4.4	4.4	2.9	2.9	2.3	4.7	5.0	0	0	3.9	0	0
F.F	0	0	4.9	■	3.6	4.3	4.5	4.4	4.4	4.4	2.9	2.9	2.3	4.7	5.0	■	0	4.0	0	0
REW	0	0	4.9	0	3.6	4.1	4.5	4.4	4.4	1.2	2.9	2.9	2.3	4.7	5.0	■	0	4.0	0	■
REF. NO.	IC2203																			
MODE	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
STOP	■	0	0	4.2	0	0	■	0	2.5	2.5	0	0	■	2.5	2.5	■	2.5	5.0	5.0	0.2
PLAY	0	0	0	4.2	0	0	0	0	2.5	2.5	0	0	0	2.5	2.5	0	2.5	4.9	4.9	0.8
REC	■	0	0	4.2	0	0	0	0	2.5	2.5	0	0	0	2.4	2.5	0	2.5	5.0	5.0	0.6
F.F	0	0	0	4.2	0	0	0	0	2.5	2.5	0	0	0	2.5	2.5	0	2.5	4.9	4.9	0.3
REW	0	0	0	4.2	0	0	0	0	2.5	2.5	0	0	0	2.5	2.5	■	2.5	4.9	4.9	0.2
REF. NO.	IC2204																			
MODE	1	2	3	4	5	6	7	8												
STOP	5.0	5.0	5.0	5.0	0	0	5.0	5.0												
PLAY	5.0	5.0	5.0	4.9	0	0	4.9	5.0												
REC	5.0	4.9	5.0	4.9	0	0	4.9	5.0												
F.F	4.9	4.9	4.9	4.9	0	■	4.9	4.9												
REW	5.0	4.9	4.9	4.9	0	■	4.9	4.9												
REF. NO.	IC2205																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	4.7	4.6	4.4	0	0	0	4.9	0	4.7	4.8	3.8	0.5	4.0	0.3	4.6	0	■	0	4.5	5.0
PLAY	4.7	4.6	4.4	0	0	0	4.9	0	4.7	4.7	3.9	0.5	4.0	0.3	4.6	0	■	0	4.5	4.9
REC	4.7	4.6	4.4	0	0	0	5.0	0	4.7	4.7	3.9	0.4	4.0	0.3	4.6	0	0.1	■	4.5	5.0
F.F	4.7	4.6	4.4	0	0	0	4.9	0	4.7	4.8	3.9	0.4	4.0	0.3	4.6	0	■	0	4.5	4.9
REW	4.7	4.6	4.4	0	0	0	4.9	0	4.7	4.8	3.7	0.4	4.0	0.3	4.6	0	■	0	4.5	4.9
REF. NO.	IC2205																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	■	39	40
STOP	4.8	2.1	2.3	0	0	0	5.0	5.0	5.0	5.0	0	0	■	■	0	0	■	0	0	0
PLAY	4.8	2.1	2.2	0	0	0	5.0	5.0	5.0	4.9	0	0	0	0	0	0	0	0	0	0
REC	4.8	2.0	2.3	0	0	0	5.0	5.0	5.0	5.0	0	0	■	■	0	0	0	0	0	0
F.F	4.8	2.1	2.3	0	0	0	4.9	4.9	4.9	4.9	0	0	0	0	0	0	0	0	0	0
REW	4.8	2.1	2.3	■	0	0	0.4	4.9	4.9	4.9	0	0	0	0.5	0	0	0	0	0	0


REF. NO.	IC2205																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	5.0	0	0	0	0	0	5.0	5.0	4.9	0	0	0	0	0	2.5	2.5	5.0	5.0	0	5.0
PLAY	4.9	0	0	0	0	0	5.0	4.9	4.9	0	0	0	0	0	2.5	2.5	4.9	5.0	0	4.9
REC	4.9	0	0	0	0	0	5.0	5.0	4.9	0	0	0	0	0	2.5	2.5	4.9	4.9	0	5.0
F.F	4.9	0	0	0	0	0	4.9	4.9	4.9	0	0	0	0	0	2.5	2.5	4.9	4.9	0	5.0
REW	4.9	0	0	0	0	0	5.0	4.9	4.9	0	0	0	0	0	2.5	2.5	5.0	5.0	0	4.9
REF. NO.	IC2205																			
MODE	61	62	63	64																
STOP	5.0	5.0	5.0	0.6																
PLAY	4.9	5.0	4.9	0.6																
REC	5.0	5.0	5.0	0.3																
F.F	4.9	4.9	4.9	1.7																
REW	4.9	4.9	4.9	1.2																
REF. NO.	IC2206																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	0	3.4	3.4	0	3.4	0	3.4	0	3.4	0	0	0	3.4	3.4	0	3.4				
PLAY	0	3.4	3.4	0	1.8	0	3.4	0	3.4	0	0	0	3.4	3.4	0	3.4				
REC	0	3.4	3.4	0	1.8	0	3.4	0	3.4	0	0	0	3.4	3.4	0	3.4				
F.F	0	3.4	3.4	0	1.8	0	3.4	0	3.4	0	0	0	3.4	3.4	0	3.4				
REW	0	3.4	3.4	0	1.8	0	3.4	0	3.4	0	0	0	3.4	3.4	0	3.4				
REF. NO.	IC2207																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	4.3	3.6	4.7	4.4	5.1	5.1	0	0.7	0.7	0.2	0.2	4.9	0.7	0.7	5.1	0	5.1	5.0	0	5.0
PLAY	4.3	3.6	4.7	4.4	5.1	5.1	0	0.7	1.1	1.1	1.0	4.9	1.1	0.9	1.1	0	5.1	1.1	0	5.0
REC	4.3	3.6	4.7	4.5	5.1	5.1	0	1.3	1.2	1.2	1.2	4.9	1.2	1.2	1.2	0	5.1	5.0	0	5.0
F.F	4.3	3.6	4.7	4.5	5.1	5.1	0	2.3	1.1	1.0	1.0	4.9	1.0	1.0	5.1	0	5.1	5.0	0	5.0
REW	4.3	3.6	4.7	4.4	5.1	5.1	0	2.2	2.2	1.2	1.0	4.9	1.1	1.1	5.1	0	5.1	5.0	0	5.0
REF. NO.	IC2207																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32								
STOP	5.0	0	5.0	5.0	0	0	5.0	5.0	0	5.0	5.1	0								
PLAY	5.0	0	5.0	5.0	0	0	5.0	5.0	0	5.0	5.1	0								
REC	5.0	0	5.0	5.0	0	0	5.0	5.0	0	5.0	5.1	0								
F.F	5.0	0	5.0	5.0	0	0	5.0	5.0	1.0	5.0	5.1	0								
REW	5.0	0	6.1	5.0	0	0	5.0	5.0	0	5.0	5.1	0								
REF. NO.	IC2208																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	4.3	3.6	4.7	4.6	5.1	5.1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
PLAY	4.3	3.6	4.7	4.6	5.1	5.1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
REC	4.3	3.6	4.7	4.6	5.1	5.1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
F.F	4.3	3.6	4.7	4.5	5.1	5.1	0	0	0	0	0	0	0	0	0	5.1	0	6.1	5.0	5.0
REW	4.3	3.6	4.7	4.5	5.1	5.1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
REF. NO.	IC2208																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32								
STOP	3.5	3.5	5.1	0.1	0	0	0.2	0	0	0	0.1	0.1								
PLAY	3.5	3.5	5.1	0.1	0	0	0.2	0	0	0	0.1	0.1								
REC	3.5	3.5	5.1	1.2	0	0	1.9	0	0	0	0.1	1.9								
F.F	5.0	0	5.1	0	0	0	0.1	0	0	0	0.1	0								
REW	3.5	3.5	5.1	0	0	0	0	0	0	0	0.1	0								
REF. NO.	IC2209										IC2210									
MODE	1	2	3								1	2	3							
STOP	5.1	5.1	0								4.7	0	4.7							
PLAY	5.1	5.1	0								4.7	0	4.7							
REC	5.1	5.1	0								4.7	0	4.7							
F.F	5.1	5.1	0								4.7	0	4.7							
REW	5.1	5.1	0								4.7	0	4.7							
REF. NO.	IC2211										IC2212									
MODE	1	2	3	4	5	6	7	8			1	2	3	4	5	6	7	8		
STOP	3.4	3.4	3.4	0	0	0	3.4	3.4			3.4	3.4	3.4	0	0	0	3.4	3.4		
PLAY	1.8	2.6	2.6	0	0.8	2.1	3.4	3.4			1.8	3.4	2.1	0	1.3	2.1	3.4	3.4		
REC	1.8	2.6	2.6	0	0.8	2.1	3.4	3.4			1.8	3.4	2.1	0	1.3	2.1	3.4	3.4		
F.F	1.8	2.6	2.6	0	0.8	2.1	3.4	3.4			1.8	3.4	2.1	0	1.3	2.1	3.4	3.4		
REW	1.8	2.6	2.6	0	0.8	2.1	3.4	3.4			1.8	3.4	2.1	0	1.3	2.0	3.4	3.4		
REF. NO.	IC2213										IC2214									
MODE	1	2	3	4	5	6	7	8			1	2	3	4	5	6	7	8		
STOP	0.1	3.4	3.4	0	0	3.4	3.4	3.4			0	3.4	0	0	0	0	0	3.4		
PLAY	0.4	3.4	1.3	0	2.1	3.4	3.4	3.4			1.3	2.6	0	0	0	0.4	0.4	3.4		
REC	0.4	3.4	1.3	0	2.1	3.4	3.4	3.4			1.3	2.6	0	0	0	0.4	0.4	3.4		
F.F	0.4	3.4	1.3	0	2.1	3.4	3.4	3.4			1.3	2.6	0	0	0	0.4	0.4	3.4		
REW	0.4	3.4	1.4	0	2.0	3.4	3.4	3.4			1.3	2.6	0	0	0	0.4	0.4	3.4		

REF. NO.	IC2215										IC2216									
MODE	1	2	3	4	5						1	2	3	4	5					
STOP	0	0.1	0	0	3.4						0	0	0	0	3.4					
PLAY	0	0.4	1.3	0.3	3.4						0	0	0	0	3.4					
REC	0	0.4	0	0.3	3.4						0	0	0	0	1.0					
F.F	0	0.4	0	0.3	3.4						0	0	0	0	3.4					
REW	0	0.3	0	0.3	3.4						0	3.7	0	0	3.4					

EDIT/SYSTEM CONTROL & SERVO TRs DC VOLTAGE CHART (Mini DV : SP MODE)


REF. NO.	Q2201			Q2202			Q2203			Q2204			Q2205			Q2206		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	4.7	0	0	3.8	0.1	0	4.6	0	0	4.8	0	0	4.7	0	0	4.5	0
PLAY	■	4.7	0	0	3.9	0.1	0	4.6	0	0	4.8	0	0	4.7	0	0	4.5	0
REC	0	4.7	0	0	3.8	0.1	0	4.6	0	0	4.8	0	0	4.7	0	0	4.6	0
F.F	0	4.7	0	0	3.8	0.1	0	4.6	0	0	4.8	0	0	4.7	0	0	4.5	0
REW	0	4.7	0	0	3.9	0.1	0	4.6	0	0	4.8	0	0	4.7	0	0	4.5	0
REF. NO.	Q2207																	
MODE	E	C	B															
STOP	0	4.2	0.1															
PLAY	■	4.1	0.1															
REC	■	4.2	0.1															
F.F	0	4.2	0.1															
REW	0	4.2	0.1															
REF. NO.	QR2201			QR2202			QR2203			QR2204			QR2205			QR2206		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	0	3.5	0	5.1	0	0	0	3.4	0	0.1	2.8	0	0	4.0	0	0	4.5
PLAY	0	0	3.5	0	5.1	0	0	0	3.4	0	0.1	2.9	0	■	4.0	■	4.5	■
REC	0	0	3.5	0	5.1	0	0	0	3.4	0	0.2	2.8	0	■	4.0	0	0	4.5
F.F	0	0	3.5	0	5.1	0	■	■	3.4	0	0.1	2.9	0	■	4.0	■	0	4.5
REW	0	0	3.5	0	5.1	0	0	0	3.4	0	0.1	2.9	0	0	4.0	■	■	4.5
REF. NO.	QR2207			QR2208			QR2209			QR2210			QR2211			QR2212		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	0	3.5	0	0	3.5	0	4.5	1.0	0	3.6	1.1	■	4.5	0.9	0	0	3.3
PLAY	0	0	3.5	■	0	3.5	0	4.5	1.0	■	3.6	1.0	■	4.5	0.9	■	■	3.3
REC	0	0	3.5	0	0	3.5	0	4.6	1.0	0	3.6	1.1	■	4.5	0.9	0	■	3.3
F.F	0	0	3.5	0	0	3.5	0	4.5	1.0	0	3.6	1.0	0	4.5	0.9	0	0	3.3
REW	0	0	3.5	0	0	3.5	0	4.5	1.0	■	3.6	1.1	■	4.5	0.9	0	0	3.3
REF. NO.	QR2213			QR2214			QR2215			QR2216			QR2217			QR2218		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	■	4.4	0.5	0	0	3.7	0	4.6	0.4	0	5.1	0	■	5.1	■	0	5.0	0
PLAY	■	4.4	0.5	0	0	3.7	0	4.5	0.4	0	0	3.7	0	0	3.7	0	5.0	0
REC	0	4.4	0.5	0	0	3.7	0	4.6	0.4	0	0	3.7	0	0	3.7	0	5.1	0
F.F	0	4.4	0.5	0	0	3.7	0	4.5	0.4	0	0	3.7	0	■	3.7	0	5.0	■
REW	■	4.4	0.5	0	0	3.7	0	4.6	0.4	0	0	3.7	0	■	3.7	0	5.0	0
REF. NO.	QR2219			QR2220			QR2221			QR2222								
MODE	E	C	B	E	C	B	E	C	B	E	C	B						
STOP	0	0	4.7	■	0	3.2	0	0.1	3.1	0	■	3.5						
PLAY	0	0	4.7	0	0	3.2	0	0.1	3.1	0	0	3.5						
REC	■	0	4.7	0	0	3.2	0	0.1	3.1	■	0	3.5						
F.F	0	0	4.7	0	0	3.2	0	0.1	3.2	0	■	3.5						
REW	0	0	4.7	0	0	3.2	0	0.1	3.1	■	0	3.5						

3-15. AUDIO/VIDEO SECTION IN MAIN SCHEMATIC DIAGRAM




NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.
WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST


3-16. RF SECTION IN MAIN SCHEMATIC DIAGRAM



➔ : VIDEO MAIN SIGNAL PATH IN REC MODE
➞ : VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE



➡ : VIDEO MAIN SIGNAL PATH IN REC MODE
 ➡ : VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL. (MINI DV:SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL. (MINI DV:SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

23

24

25

26

27

28

29

30


31

32


IC30013 (SABC161RIL16): SUB MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	DCLCH	I	AD converter, not used	53	OSD \oplus	O	H=any OSD character displayed, L=no OSD character displayed
2	DCRCH	I	AD converter, not used	54	AV1 PB \oplus	O	Pin8 of I/O control \rightarrow PB \oplus
3	JOG2	I	Jog dial 2 input	55	PROG \oplus	O	I/O control to switch IIC bus for LW-programmer. H: IIC bus is connected to AV2. L: IIC bus is not connected to AV2.
4	—	I	Hi-Z	56	VB	O	I/O control: The selection of VCR IN VA/VB:LL:tuner VA/VB:HL:AV1 VA/VB:LH:AV2 VA/VB:HH:AV3 or SAT Normal Audio Input select for ZN/ZT
5	Vss	—	GND	57	VA	O	Same as Pin56
6	XTAL1	I	Oscillator amplifier input, 16MHz	58	A0	O	A0 address line
7	XTAL2	O	Oscillator amplifier output, 16MHz	59	A1	O	A1 address line
8	Vcc	I	5V	60	A2	O	A2 address line
9	IIC SCL0	O	IIC clock line to CTX IC	61	A3	O	A3 address line
10	IIC SDA0	O	IIC data line to CTX IC	62	A4	O	A4 address line
11	COMB \oplus	O	Comb filter ON \oplus , OFF \ominus	63	A5	O	A5 address line
12	SAT IR	O	Infrared code for SAT receivers	64	A6	O	A6 address line
13	SHUTTLE4	I	Shuttle input 4	65	A7	O	A7 address line
14	SHUTTLE3	I	Shuttle input 3	66	Vss	—	GND
15	SHUTTLE2	I	Shuttle input 2	67	Vcc	I	5V
16	SHUTTLE1	I	Shuttle input 1	68	A8	O	A8 address line
17	LSN	O	Timer bus listen line	69	A9	O	A9 address line
18	TLK	I	Timer bus talk line	70	A10	O	A10 address line
19	SCL0 (spare)	O	NC	71	A11	O	A11 address line
20	SDA0 (spare)	O	NC	72	A12	O	A12 address line
21	RESET \oplus	O	Reset signal for Compact Text (0=normal, 1=Reset)	73	A13	O	A13 address line
22	CLK	I	Timer bus clock line	74	A14	O	A14 address line
23	B/W \ominus	O	L and High Impedance; L-B/W selected in FUNCTION menu	75	A15	O	A15 address line
24	Vss	—	GND	76	Vss	—	GND
25	Vcc	I	5V	77	Vcc	I	5V
26	A16	O	A16 address line	78	/RST	I	Reset Input (LOW level=reset active)
27	A17	O	A17 address line	79	/RSTOUT	O	for battery back up circuit
28	A18	O	A18 address line	80	/NMI	I	Non maskable interrupt, connected to Vcc
29	—	I	Pin is active for 4M EPROM	81	/CE	O	Chip enable for external EPROM (0=EPROM enabled)
30	—	O	NC (used for ROM Monitor input)	82	/Y	O	Chip select for SRAM
31	—	O	NC (used for ROM Monitor input)	83	FSCREEN \oplus	O	Fullscreen high signal, (0=no OSD fullscreen, 1=OSD fullscreen)
32	S/M \ominus	O	Croma Mix for SECAM/MESECAM box	84	AV2 OUT A	O	AV2 output selector A
33	/RD	O	External memory read strobe (for EPROM and SRAM)	85	BWBOX \ominus	O	force B/W OSD box for SECAM, (0=force B/W boxes, 1=colour boxes)
34	/WR	O	External memory write strobe (for SRAM)	86	IIC SDA1	O	IIC bus data line 1 (except EEPROM)
35	/READY	I	Ready input, not used	87	IIC SCL1	O	IIC bus clock line 1
36	ALE	O	Address latch enable output, not used	88	IIC SDA2	O	IIC bus clock line 2 (for EEPROM)
37	/EA	—	External access enable pin, connected to GND	89	P50 IN	I	Project50 input
38	Vss	—	GND	90	P50 OUT	O	Project 50 output
39	Vcc	I	5V	91	YC/CVBS	I	S VIDEO \ominus INPUT
40	D0	I	D0 data line	92	AV2 OUT B	O	AV2 output selector B
41	D1	I	D1 data line	93	JOG1	I	Jog dial 1 input
42	D2	I	D2 data line	94	CSTBUS	I	Chip select signal for timer bus (1=OSD ucon selected, 0=FIP selectyed)
43	D3	I	D3 data line	95	—	O	NC (used for ROM Monitor input)
44	D4	I	D4 data line	96	TV \oplus	O	TV High: for I/O logic
45	D5	I	D5 data line	97	VAREF	I	Reference voltage for A/D converter, not used
46	D6	I	D6 data line	98	VAGND	—	GND for A/D converter, not used
47	D7	I	D7 data line	99	P50 in	I	Reserved for Project50 in
48	Vss	—	GND	100	CPB \oplus	I	PB \oplus signal of AV2 is inputted. This logic will be used for I/O control.
49	Vcc	I	5V				
50	SAT \oplus	O	I/O control: The selection of SAT tuner or AV3. H: SAT tuner L: AV3 in This logic is valid, if AV3 is selected by VA/VB				
51	CS EE	O	Write enable for EEPROM. (1=READ only 0=Write enabled)				
52	RGB OFF \oplus	O	I/O control				


3-18. HEAD AMP SCHEMATIC DIAGRAM



3-19. FRONT (L) SCHEMATIC DIAGRAM




3-20. FRONT (R) SCHEMATIC DIAGRAM



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE. THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE. WITH PAL COLOUR SIGNAL. (MINI DV: SP MODE) - LINE IN SIGNAL LEVEL... -10dB 1kHz. WITH PAL COLOUR SIGNAL. (MINI DV: SP MODE) - LINE IN SIGNAL LEVEL... -10dB 1kHz.


3-21. LSI/SYSTEM CONTROL & SERVO SECTION IN DIGITAL SCHEMATIC DIAGRAM



NOTE: DO NOT USE ANY PART NUMBER SHOWN IN THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

→ :CAPSTAN SERVO SPEED LOOP → :CYLINDER SERVO SPEED LOOP → :T-REEL SERVO SPEED LOOP → :S-REEL SERVO SPEED LOOP
 → :CAPSTAN SERVO PHASE LOOP → :CYLINDER SERVO PHASE LOOP → :T-REEL SERVO PHASE LOOP → :S-REEL SERVO PHASE LOOP

VIDEO 1 SECTION (Page 175)
 VIDEO 2 SECTION (Page 176)



14 15 16 17 18 19 20 21 22 23 24 25

IC2001(M31020VLED) : LSI MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	VSS	—		60	CYL PG	I	Cylinder PG
2	HLDA	O	Ext-Bus Hold Acknowledge/BST TCK (CLK)	61	SPA	I	SPA
3	HOLD	I	Ext-Bus Hold Request	62	AFRP	I	AFRP
4	RESET	I	Reset	63	MCVS	I	MCVS
5	MOD0	I	Single Chip Mode = Vss Vss	64	FRP	I	Frame reference pulse
6	MOD1	I	Memory Extend Mode = Vss Vcc	65	VSS	—	
7	VCC	—		66	VCC	—	
8	VSS	—		67	NC	O	—
9	VCC	—		68	COM RST	O	RS232C RESET
10	NC	O	—	69	COM CLK	I	RS232C CLK IN
11	NC	O	—	70	COM DATA OUT	O	RS232C SERIAL-DATA OUT
12	NC	O	—	71	COM DATA IN	I	RS232C SERIAL-DATA IN
13	NC	O	—	72	RDY CTS	I	from SYSCON ACK
14	NC	O	—	73	CPU CLK	O	to SYSCON CLK
15	NC	O	—	74	CPU DATA OUT	O	to SYSCON DATA
16	L TEST	I	EVR TEST MODE (L)	75	CPU DATA IN	I	from SYSCON DATA
17	SYNC OFF	O	L: Sync Gate Off H: Sync Gate On	76	NC	O	—
18	VSS	—		77	YC CLOCK	O	YC MICON Serial Clock
19	OSC VCC	—		78	L YC DO	O	YC MICON Data out
20	X IN	I	27MHz	79	L YC DI	I	YC MICON Data in
21	X OUT	O	27MHz	80	NC	O	—
22	OSC VSS	—		81	DSC CLK	O	CAS & DVIO Serial Clock
23	VSS	—		82	DSC D0	O	CAS & DVIO Serial Data Out
24	VCC	—		83	DSC D1	I	CAS & DVIO Serial Data In
25	A MUT	O	AUDIO MUTE	84	VCC	—	
26	PG GATE ON [Ⓢ]	O	PG GATE Control	85	VSS	—	
27	NC	O	—	86	SSP	I	Sector Start Pulse
28	NC	O	—	87	NC	O	—
29	SYS VIDEO EE	I	SYSCON EE/VV	88	DIF INT	I	Digital Interface IF
30	PG RESET [Ⓢ]	O	PG RESET	89	CPU WUPI 2	O	—
31	VIDEO EE [Ⓢ]	O	I/O Pack EE/VV Select	90	NC	O	—
32	NC	O	—	91	NMI	I	Pull-up
33	EEMUTE	O	EE MUTE	92	NC	O	—
34	COMRDY	O	232C MICON RDY	93	NC	O	—
35	YC CS	O	YC MICON CS	94	V PLL	O	Video PLL
36	CPU ACK 0-2	O	—	95	FS PLL	O	FS PLL (ATF ERR for Linear arrangement)
37	CTL 27M	O	27MHz Freq. Select	96	NC3(SPEED CTL)	I	CYL PG Amp Control (FF/REW 100 Times or more)
38	NC	O	—	97	NC2(VSYNC)	I	REC V Countermeasure
39	NC	O	—	98	NC1	O	Spare
40	NC	O	—	99	EE CLK	O	EEprom & DAC Clock
41	VCC	—		100	EE DI	I	EEprom & DAC Data In
42	VSS	—		101	VSS	—	
43	VCC	—		102	VCC	—	
44	CPU ACK0-1	I	from SYSCON ACK	103	EE DO	O	EEprom & DAC Data Out
45	CPU WUP0-1	O	to SYSCON REQ	104	EE CS	O	EEprom Chip Select
46	RST LSI	O	DVIO, CAS, EDA Reset	105	GA STP	O	L: Active H: Not Active
47	L SCKL	I	for FLASH CLK	106	DAC LD	O	DAC Load
48	L SDA	I	for FLASH DATA IN	107	DCS STP1	O	DVIO Serial Strobe Pulse
49	RST DIF	O	DIF LSI Reset	108	DCS STP2	O	CAS Serial Strobe Pulse
50	L OE	I	for FLASH WRITE OE	109	NC	O	—
51	NC	O	—	110	NC	O	—
52	VCC	—		111	NC	O	—
53	VSS	—		112	NC	O	—
54	NC	O	—	113	AVSS	—	
55	NC	O	—	114	NC	I	Connect to GND (0Ω)
56	TSR	I	Track Start Reference	115	NC	I	Connect to GND (0Ω)
57	HID	I	HSW	116	NC	I	Connect to GND (0Ω)
58	NC	O	—	117	NC	I	Connect to GND (0Ω)
59	CYL FG	I	Cylinder FG	118	NC	I	Connect to GND (0Ω)

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
119	NC	I	Connect to GND (0Ω)	138	BHW	O	—
120	NC	I	Connect to GND (0Ω)	139	DT15	I/O	EXT-Memory Address/Data Bus
121	NC	I	Connect to GND (0Ω)	140	ADDT14	I/O	EXT-Memory Address/Data Bus
122	NC	I	Connect to GND (0Ω)	141	ADDT13	I/O	EXT-Memory Address/Data Bus
123	NC	I	Connect to GND (0Ω)	142	ADDT12	I/O	EXT-Memory Address/Data Bus
124	NC	I	Connect to GND (0Ω)	143	ADDT11	I/O	EXT-Memory Address/Data Bus
125	NC	I	Connect to GND (0Ω)	144	ADDT10	I/O	EXT-Memory Address/Data Bus
126	NC	I	Connect to GND (0Ω)	145	ADDT9	I/O	EXT-Memory Address/Data Bus
127	AVREF	—		146	ADDT8	I/O	EXT-Memory Address/Data Bus
128	AVCC	—		147	ADDT7	I/O	EXT-Memory Address/Data Bus
129	VCC2	—		148	ADDT6	I/O	EXT-Memory Address/Data Bus
130	VSS	—		149	ADDT5	I/O	EXT-Memory Address/Data Bus
131		O	—	150	ADDT4	I/O	EXT-Memory Address/Data Bus
132	BCLK	O		151	ADDT3	I/O	EXT-Memory Address/Data Bus
133	D0	I	Data Complete for Ext-Memory mode	152	ADDT2	I/O	EXT-Memory Address/Data Bus
134	R/W	O	—	153	ADDT1	I/O	EXT-Memory Address/Data Bus
135	ALE	O	Address Latch Enable for Ext-Memory mode	154	ADDT0	I/O	EXT-Memory Address/Data Bus
136	RD	O	Read Strobe for Ext-Memory mode	155	VSS	—	
137	BLW	O	Byte Low Write for Ext-Memory mode	156	VCC2	—	

IC2005 (D784037GK508) : RS-232C INTERFACE MICROCOMPUTER

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	EVR SCK	O	Serial Clock Signal for SYNC Serial Communication (To Camera Micom)	46	TEST	—	GND
2	EVR SBO	O	Serial Data Signal for SYNC Serial Communication (To Camera Micom)	47	CGCS	O	CG CS
				48	CGPCL	O	CG PCL
5	VTR T	O	SYNC Serial Communication Enable Signal for Camera Micom	49	P12	—	(N.C.)
7	RESET	I	Reset Signal	50	UARTI	I	RS-232C Data
8	VDD	—	VDD (+3V)	51	UARTO	O	RS-232C Data
9	X2	O	Oscillator (14.7456MHz)	52	PCOE	O	RS-232C Driver Output Enable
10	X1	I	Oscillator (14.7456MHz)	53	BACK RST	—	(N.C.)
11	GND	—	GND	54	TEST0	I	VTR Test Signal (H: Normal, L: Test Mode)
12	S TITLE L	O	Sound Effect Control Signal	55	VDD	—	VDD (+3V)
13	LR CONT	O	LCD Driver Control (L/R Invert)	56	PC RST	I	Reset Signal Detect (AD Input)
14	UD CONT	O	LCD Driver Control (U/D Invert)	60	STBY	I	RS-232C Cable Connect Confirm
15	LCD P SAVE	—	(N.C.)	61	BACK DET	—	GND
17	INSEL	—	(N.C.)	64	AVDD	—	Voltage for AD Converter (+3V)
18	TALLY	O	TALLY LED Control	65	AVREF1	—	Reference Voltage for AD Converter (+3V)
19	A LINE H	—	(N.C.)	66	AVSS	—	GND for AD Converter
20	T PH AD2	O	Take μ	67	ANO0	—	(N.C.)
21	T PH AD1	O	Take μ	68	ANO1	—	(N.C.)
22	S PH AD2	O	Supply Tape Sensor	69	AVREF2	—	GND
23	S PH AD1	O	Supply Tape Sensor	70	AVREF3	—	GND
24	EYE P SAVE	—	(N.C.)	71	P20	—	GND
25	LCD WIDE	O	LCD Driver Wide Select	72	CAM T	I	Camera Service/232C Micom Select Signal (H: 232C, L: Camera Service)
26	SPK ON H	O	Speaker ON	73	FRP	I	Frame SYNC Signal
27	WIDNSW H	O	Noise Silent	76	SCK	I	Serial Clock Signal for SYNC Serial Communication (To VTR Micom)
28	VTR LED	O	VTR Mode LED	77	COM RDY	I	SYNC Serial Communication Enable Signal for VTR Micom
29	CAM LED	O	CAMERA Mode LED	78	EVR SDI	I	Serial Data Input for SYNC Serial Communication (To Camera Micom)
30	VCO H	O	VCO Test Mode [Ⓢ]	79	SDI	I	Serial Data for SYNC Serial Communication (To VTR Micom)
31	LCD BL CONT	O	LCD Back Light Control Signal	80	SDO	O	Serial Data for SYNC Serial Communication (To VTR Micom)
32	BL BRIGHT H	O	Back Light Bright Control Signal				
33	EVF BL CONT	O	EVF Back Light Control Signal				
34	EVF ON	O	EVF ON				
35	LCD ON	O	LCD ON				
44	CLKOUT	—	(N.C.)				
45	GND	—	GND				

IC6001 (M31020VLEC) : SYSTEM CONTROL MICROPROCESSOR

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	GND	—		55	CAP.FG	I	CAPSTAN 2 PHASE FG
2	—	O	Low FIX	56	TSR	I	HID PHASE REF. SIGNAL
3	—	O	Low FIX	57	HID	I	HEAD SELECT SW
4	RESET	I	RESET INPUT	58	CAP.FG2	I	CAPSTAN FG 2
5	MOD0	I	SIGNAL CHIP MODE SELECT	59	T.FG1	I	T REEL FG 1
6	MOD1	I	SIGNAL CHIP MODE SELECT	60	S.FG1	I	S REEL FG 1
7	VDD	—	VDD	61	SPA	I	
8	GND	—	GND	62	—	O	FIX Low OUTPUT
9	VDD	—	VDD	63	—	O	FIX Low OUTPUT
10	VIDEO.EEⓈ	O	EE/VV SELECT OUTPUT (EE: L)	64	FRP	I	FRAME REF. SIGNAL
11	A.MUTⓈ	O	AUDIO MUTE Ⓢ	65	GND	—	GND
12	ERASEⓈ	O	ERASE ON Ⓢ/OFF	66	VDD	—	POWER
13	PHOTO.SNS	O	TAPE SENSOR LED (ON: L)	67	(CPU WUP0-2)	O	SYS CTL μ-PROCESSOR ↔ LSI (COMMUNICATION)
14	RASTAB	O	S TAB OUTPUT	68	CPU ACK0-1	O	SYS CTL μ-PROCESSOR ↔ LSI (COMMUNICATION)
15	MIX.VVⓈ	O	MIX OUTPUT (VV MODE): L	69	SLPR.CLOCK	O	SERIAL/PARALLEL CONVERSION EXPANSION IC
16	EE.MONIⓈ	O	EE MONITOR OUT: L	70	SLPR. DATA. OUT	O	SERIAL/PARALLEL CONVERSION EXPANSION IC
17	—	O	FIX LOW OUTPUT	71	SLPR. DATA. IN	I	SERIAL/PARALLEL CONVERSION EXPANSION IC
18	GND	—	GND	72	CPU RDY/CTS	O	SYS CTL μ-PROCESSOR ↔ LSI COMMUNICATION
19	VDD	—	OSC POWER	73	CPU CLOCK	I	SYS CTL μ-PROCESSOR ↔ LSI SERIAL SLAVE CLOCK
20	27MHz. IN	I	27MHz INPUT	74	CPU DATA OUT	O	SYS CTL μ-PROCESSOR ↔ LSI SERIAL DATA OUTPUT
21	27MHz. OUT	O	27MHz OUTPUT	75	CPU DATA IN	I	SYS CTL μ-PROCESSOR ↔ LSI SERIAL DATA INPUT
22	GND	—	OSC GND	76	(CPU ACK1-2)	O	SYS CTL μ-PROCESSOR ↔ LSI COMMUNICATION
23	GND	—	GND	77	EDIT.CLOCK	O	SYS CTL μ-PROCESSOR ↔ EDIT MICON SERIAL MASTER CLOCK
24	VDD	—	POWER	78	EDIT. DATA. OUT	O	SYS CTL μ-PROCESSOR ↔ EDIT MICON SERIAL DATA OUTPUT
25	FRONT SW	I	FRONT DOOR OPEN DETECT INPUT (OPEN: L, CLOSE/NO DOOR: H)	79	EDIT. DATA. IN	I	SYS CTL μ-PROCESSOR ↔ EDIT MICON SERIAL DATA INPUT
26	MP ADUB	O	FIX Low OUTPUT	80	—	O	FIX Low OUTPUT
27	—	O	FIX Low OUTPUT	81	SIRIAL.CLOCK	O	TIMER ↔ SYS CTL μ-PROCESSOR MASTER CLOCK
28	PINCH ONⓈ	O	PINCH SOLENOID CONTROL OUTPUT	82	S. DATA. OUT	O	TIMER ↔ SYS CTL μ-PROCESSOR SIRIAL DATA OUTPUT
29	—	O	FIX Low OUTPUT	83	S. DATA. IN	I	TIMER ↔ SYS CTL μ-PROCESSOR SIRIAL DATA INPUT
30	—	O	FIX Low OUTPUT	84	VDD	—	POWER
31	—	O	FIX Low OUTPUT	85	GND	—	GND
32	TRAY VCHANGE	O	TRAY MOTOR VOLTAGE CONTROL OUTPUT	86	S. DIR	I	S REEL ROTATION DIRECTION DET.
33	S SOL ONⓈ	O	S REEL SOLENOID CONTROL OUTPUT	87	T. DIR	I	T REEL ROTATION DIRECTION DET.
34	T SOL ONⓈ	O	T REEL SOLENOID CONTROL OUTPUT	88	CAP. DIR	I	CAPSTAN ROTATION DIRECTION DET.
35	PINE RSTⓈ	O	RESET High OUTPUT	89	CPU WUPI-1	O	SYS CTL μ-PROCESSOR ↔ LSI PROCESSOR COMMUNICATION
36	—	O	FIX LOW OUTPUT	90	SSP	I	SECTOR START PULSE INPUT
37	S.ONⓈ	O	S REEL ON/OFF CONTROL	91	—	I	
38	T.ONⓈ	O	T REEL ON/OFF CONTROL	92	CYL. ET	O	CYLINDER TORQUE OUTPUT (12bit PWM)
39	S.RF	O	S REEL ROTATION DIRECTION CONTROL	93	CAP. ET	O	CAPSTAN TORQUE OUTPUT (12bit PWM)
40	T.RF	O	T REEL ROTATION DIRECTION CONTROL	94	T. ET	O	T REEL TORQUE OUTPUT (12bit PWM)
41	VDD	—	POWER	95	S. ET	O	S REEL TORQUE OUTPUT (14bit PWM)
42	GND	—	GND	96	DRV. CLK	O	CYLINDER DRIVER CLOCK
43	VDD	—	POWER				
44	MIC.ONⓈ	O	POWER FOR MIC				
45	CS0	O	SERIAL/PARALLEL CONVERSION IC CHIP SELECT SIGNAL				
46	CS1	O	SERIAL/PARALLEL CONVERSION IC CHIP SELECT SIGNAL				
47	CS2	O	SERIAL/PARALLEL CONVERSION IC CHIP SELECT SIGNAL				
48	CS3	O	SERIAL/PARALLEL CONVERSION IC CHIP SELECT SIGNAL				
49	CAP.T.LIM	O	CAP TORQUE LIMIT				
50	CYL.ONⓈ	O	CYL DRIVING: Low				
51	CAP.R/S/F	O	CAPSTAN ROTATION DIRECTION CONTROL				
52	VDD	—	POWER				
53	GND	—	GND				
54	CYL.FG	I	CYLINDER FG				

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
97	MIC. DATA	I/O	MIC SERIAL DATA	127	VDD	—	REF. POWER FOR ANALOG
98	MIC. CLK	O	MIC SERIAL CLOCK	128	VDD	—	ANALOG POWER
99	TM1 OKⓈ	O	TIMER SERIAL CLOCK (500μ sec.)	129	VDD	—	POWER FOR BUS
100	SMAIN OKⓈ	O	SYS. CTL MAIN ROUTIN (20msec.)	130	GND	—	GND
101	GND	—	GND	131	VSYNCⓈ	I	V SYNC INPUT (SYNC EXIST: L)
102	VDD	—	POWER	132	—	O	
103	S. FG1	I	S REEL FG 1	133	—	I	GND (VIA 47k Resistor)
104	S. FG2	I	S REEL FG 2	134	MIC INⓈ	I	MIC INPUT (MIC IN: H)
105	T. FG1	I	T REEL FG 1	135	—	O	FIX Low OUTPUT
106	T. FG2	I	T REEL FG 2	136	—	O	FIX Low OUTPUT
107	CAP. FG1	I	CAPSTAN FG 1	137	—	O	FIX Low OUTPUT
108	CAP. FG2	I	CAPSTAN FG 2	138	—	O	FIX Low OUTPUT
109	LOADⓈ	O	LOADING MOTOR FORWARD OUTPUT	139	—	O	
110	UNLOADⓈ	O	LOADING MOTOR REVERSE OUTPUT	140	—	O	FIX Low OUTPUT
111	TRAY LOADⓈ	O	TRAY MOTOR FORWARD OUTPUT	141	—	O	FIX Low OUTPUT
112	TRAY UNLDⓈ	O	TRAY MOTOR REVERSE OUTPUT	142	—	O	FIX Low OUTPUT
113	GND	—	GND	143	—	O	FIX Low OUTPUT
114	TEN V REF	I	INPUT	144	—	O	FIX Low OUTPUT
115	NTSCⓈ	I	NTSC = LOW/PAL = HIGH	145	—	O	FIX Low OUTPUT
116	S. TEST	I	EVR ADJ INPUT	146	—	O	FIX Low OUTPUT
117	—	I	VIA RESISTOR GND	147	—	O	FIX Low OUTPUT
118	—	I	VIA RESISTOR GND	148	—	O	FIX Low OUTPUT
119	—	I	VIA RESISTOR GND	149	—	O	FIX Low OUTPUT
120	TENSION	I	TAPE TENSION A/D INPUT	150	—	O	FIX Low OUTPUT
121	S. PHOTO	I	S PHOTO SENSOR INPUT (BLACK TAPE: L)	151	—	O	FIX Low OUTPUT
122	T. PHOTO	I	T PHOTO SENSOR INPUT (BLACK TAPE: L)	152	—	O	FIX Low OUTPUT
123	DEW. SNS	I	DEW SENSOR INPUT	153	—	O	FIX Low OUTPUT
124	MIC. AD3	I	A/D INPUT 3 FOR MIC	154	—	O	FIX Low OUTPUT
125	MIC. AD2	I	A/D INPUT 2 FOR MIC	155	GND	—	GND
126	MIC. AD1	I	A/D INPUT 1 FOR MIC	156	VDD 2	—	GND

LSI/SYSTEM CONTROL & SERVO ICs DC VOLTAGE CHART (Mini DV : SP MODE)

REF. NO.	IC2001																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	0	3.6	3.6	2.7	0	3.6	3.6	0	3.6	0	0	0	0	0	0	3.6	3.6	0	3.6	1.7
PLAY	0	3.6	3.6	2.7	0	3.6	3.6	0	3.6	0	0	0	0	0	0	3.6	3.6	0	3.6	1.7
REC	0	3.6	3.6	2.7	0	3.6	3.6	0	3.6	0	0	0	0	0	0	3.6	3.6	0	3.6	1.7
F.F	0	3.6	3.6	2.7	0	3.6	3.6	3.6	3.6	0	0	0	0	0	0	3.6	3.6	0	3.6	1.7
REW	0	3.6	3.6	2.6	0	3.6	3.6	0	3.6	0	0	0	0	0	0	3.6	3.6	0	3.6	1.7
REF. NO.	IC2001																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
STOP	1.7	0	0	3.6	0	0	0	0	0	0	0	0	0	3.6	3.3	0	0	0	0	0
PLAY	1.8	0	0	3.6	0	0	0	0	0	3.6	0	3.6	0	3.6	3.3	0	3.6	0	0	0
REC	1.7	0	0	3.6	0	0	0	0	0	0	0	0	0	3.6	3.3	0	0	0	0	0
F.F	1.8	0	0	3.6	0	0	0	0	0	0	0	0	0	3.6	3.3	0	0	0	0	0
REW	1.8	0	0	3.5	0	3.6	0	0	0	0	0	0	0	3.6	3.3	0	0	0	0	0
REF. NO.	IC2001																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	3.6	0	3.6	0	0	3.6	3.6	3.6	3.6	3.6	0	3.6	0	0	1.5	1.5	0	1.7	0.2	0.2
PLAY	3.6	0	3.6	0	0	3.6	3.6	3.6	3.6	3.6	0	3.6	0	0	1.5	1.5	0	1.7	0.2	0.2
REC	3.6	0	3.6	0	0	3.6	3.6	3.6	3.6	3.6	0	3.6	0	0	1.5	1.5	0	1.7	0.2	0.2
F.F	3.6	0	3.6	0	0	3.6	3.6	3.6	3.6	3.6	0	3.6	0	0	1.5	1.5	0	1.7	0.2	0.2
REW	3.6	0.7	3.6	0	0	3.6	3.6	3.6	3.6	3.6	0	3.6	0	0	1.5	1.5	0	1.6	0.2	0.2
REF. NO.	IC2001																			
MODE	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
STOP	0	1.5	1.5	1.5	0	3.6	0	3.6	3.5	3.3	0.1	3.6	3.6	3.6	1.8	0	3.6	3.5	2.8	0
PLAY	0	1.5	1.5	1.5	0	3.6	0	3.6	3.5	3.3	0.1	3.6	3.6	3.6	1.5	0	3.6	3.5	2.8	0
REC	0	1.5	1.5	1.5	0	3.6	0	3.6	3.5	3.3	0.1	3.6	3.6	3.6	1.8	0	3.6	3.5	2.8	0
F.F	0	1.5	1.5	1.5	0	3.6	0	3.6	3.5	3.3	0.1	3.6	3.6	3.6	1.8	0	3.6	3.5	2.8	0
REW	0	1.5	1.5	1.5	0	3.6	0	3.6	3.5	3.3	0.1	3.6	3.6	3.6	1.8	0	3.6	3.5	2.8	0.9
REF. NO.	IC2001																			
MODE	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
STOP	3.6	2.9	2.9	3.6	0	0	0	3.6	0	0	3.6	0	0	1.1	0	1.0	0	3.6	3.6	1.6
PLAY	3.6	3.0	2.9	3.6	0	0	0	3.6	0	0	3.6	0	0	1.1	0	1.0	0	3.6	3.6	1.1
REC	3.6	3.2	2.9	3.6	0	0	0	3.6	0	0	3.6	0	0	1.1	0	0.9	0	3.6	3.6	1.8
F.F	3.6	3.1	2.9	3.5	0	0	0	3.6	0	0	3.6	0	0	1.1	0	1.0	1.0	3.6	3.6	1.8
REW	3.6	3.3	2.9	3.6	0	0	0	3.6	0	0	3.6	0	0	1.1	0	1.0	3.6	3.6	3.6	1.8
REF. NO.	IC2001																			
MODE	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120
STOP	0	3.6	3.6	0	0	0	2.7	3.6	0	0	0	0	0	1.5	1.5	1.5	0	0	0	0
PLAY	0	3.6	3.6	0	0	0	2.7	3.4	0	0	0	0	0	1.1	1.1	1.1	0	0	0	0
REC	0	3.6	3.6	0	0	0	2.7	3.4	0	0	0	0	0	1.7	1.8	1.7	0	0	0	0
F.F	0	3.6	3.6	0	0	0	2.7	3.5	0	0	0	0	0	1.8	1.8	1.8	0	0	0	0
REW	0	3.6	3.6	0	0	0	2.7	3.4	0	0	0	0	0	1.4	1.4	1.5	0	0	0	0
REF. NO.	IC2001																			
MODE	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140
STOP	0	0	0	0	0	0	3.6	3.6	2.2	0	0	0.7	0	0	0	2.2	2.1	2.2	0.1	0
PLAY	0	0	0	0	0	0	3.6	3.6	2.2	0	0	0.7	0	0	0	2.1	2.2	2.2	0.1	0.1
REC	0	0	0	0	0	0	3.6	3.6	2.2	0	0	0.7	0	0	0	2.2	2.1	2.1	0.1	0.1
F.F	0	0	0	0	0	0	3.6	3.6	2.2	0	0	0.7	0	0	0	2.2	0	0	0.6	0
REW	0	0	0	0	0	0	3.6	3.6	3.6	0	0	0.7	0	0	0	2.2	2.2	2.2	0.1	0
REF. NO.	IC2001																			
MODE	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156				
STOP	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2.2				
PLAY	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	2.2				
REC	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	2.2				
F.F	2.2	2.2	2.2	2.2	2.2	2.2	0	2.2	2.2	0	0	0	0	0	0	2.2				
REW	0.1	0	0	0.1	0.1	0.1	0.1	0	0.1	0.1	0	0	0	0	0	2.2				
REF. NO.	IC2002																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	9.5	2.4	9.2	0.7	1.0	-2.2	3.2	0	3.2	3.2	0	0	9.5	-9.5	3.2	3.2	-9.5	0.8	0	4.0
PLAY	9.5	2.5	9.3	-0.7	1.0	-2.2	3.3	0	3.3	3.3	0	0	9.5	-9.5	3.3	3.3	-9.5	0.8	0	4.0
REC	9.5	2.5	9.3	-0.7	1.0	-2.2	3.3	0	3.3	3.3	0	0	9.5	-9.5	3.3	3.3	-9.5	0.8	0	4.0
F.F	9.5	2.5	9.3	-0.7	1.0	-2.2	3.3	0	3.3	3.3	0	0	9.5	-9.5	3.3	3.3	-9.5	0.8	0	4.0
REW	9.5	2.5	9.3	-0.7	1.0	-2.2	3.3	0	3.3	3.3	0	0	9.5	-9.5	3.3	3.3	-9.5	0.8	0	4.0
REF. NO.	IC2004																			
MODE	1	2	3	4	5	6	7	8												
STOP	0	3.6	3.6	1.7	0	0	0.8	3.7												
PLAY	0	3.6	3.6	1.6	0	0	0.8	3.7												
REC	0	3.6	3.6	1.7	0	0	0.8	3.6												
F.F	0	3.6	3.6	1.7	0	0	0.9	3.7												
REW	0	3.6	3.6	1.7	0	0	0.8	3.7												


REF. NO.	IC2005																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	3.0	0.8	0	0	3.7	0	3.6	3.7	1.8	1.6	0	0	0	3.7	3.7	0	0	3.7	0	0
PLAY	3.0	0.8	0	0	3.7	0	3.6	3.7	1.8	1.7	0	0	0	3.7	3.7	0	0	3.7	0	0
REC	3.0	0.8	0	0	3.6	0	3.6	3.6	1.8	1.5	0	0	0	3.6	3.6	0	0	3.6	0	0
F.F	3.0	0.8	0	0	3.7	0	3.6	3.7	1.8	1.5	0	0	0	3.7	3.7	0	0	3.7	0	0
REW	3.0	0.8	0	0	3.7	0	3.6	3.7	1.8	1.5	0	0	0	3.7	3.7	0	0	3.7	0	0
REF. NO.	IC2005																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
STOP	0	0	0	0	0	3.7	0	3.7	3.7	0	0	3.7	3.7	3.7	0	0	0	0	0	0
PLAY	0	0	0	0	0	3.7	0	3.7	3.7	0	0	3.7	3.7	3.7	0	0	0	0	0	0
REC	0	0	0	0	0	3.6	0	3.6	3.6	0	0	3.6	3.6	3.6	0	0	0	0	0	0
F.F	0	0	0	0	0	3.7	0	3.7	3.7	0	0	3.7	3.7	3.6	0	0	0	0	0	0
REW	0	0	0	0	0	3.7	0	3.7	3.7	0	0	3.7	3.7	3.7	0	0	0	0	0	0
REF. NO.	IC2005																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	0	0	0	0	0	0	0	3.7	0	3.4	3.7	3.7	0	3.6	3.7	3.3	0	0	0	2.1
PLAY	0.1	0	0	0	0	0	0	3.7	0	3.4	3.7	3.7	0	3.6	3.7	3.3	0	0.1	0	2.1
REC	0	0	0	0	0	0	0	3.6	0	3.4	3.6	3.6	0	3.6	3.6	3.3	0	0	0	2.1
F.F	0	0	0	0	0	0	0	3.7	0	3.4	3.7	3.7	0	3.6	3.7	3.3	0	0	0	2.1
REW	0	0	0	0	0	0	0	3.7	0	3.4	3.7	3.7	0	3.6	3.7	3.3	0	0	0	2.1
REF. NO.	IC2005																			
MODE	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
STOP	0	0	0	3.7	3.7	0	0	0	0	0	0	0	1.5	0	0	3.5	3.6	0	3.3	0.1
PLAY	0	0	0	3.7	3.7	0	0	0	0	0	0	0.1	1.5	0	0	3.5	3.6	0	3.3	0.1
REC	0	0	0	3.6	3.6	0	0	0	0	0	0	1.5	0	0	0	3.5	3.6	0	3.3	0.1
F.F	0	0	0	3.7	3.7	0	0	0	0	0	0	1.5	0	0	0	3.5	3.6	0	3.3	0.1
REW	0	0	0	3.7	3.7	0	0	0	0	0	0	1.5	0	0	0	3.5	3.6	0	3.3	0.1
REF. NO.	IC2006																			
MODE	1	2	3	4	5															
STOP	3.7	0	1.2	3.3	5.2															
PLAY	3.7	0	1.2	3.3	5.1															
REC	3.7	0	1.2	3.3	5.1															
F.F	3.7	0	1.2	3.3	5.1															
REW	3.7	0	1.2	3.3	5.1															
REF. NO.	IC5001																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	0	0	0	2.7	0	0	3.6	0	3.6	0	0	0	0	3.6	3.6	3.6	0	0	3.6	1.8
PLAY	0	0	0	2.7	0	0	3.6	0	3.6	0	0	0	0	3.6	3.6	3.6	0	0	3.6	1.8
REC	0	0	0	2.6	0	0	3.6	0	3.6	0	0	0	0	3.6	3.6	3.6	0	0	3.6	1.8
F.F	0	0	0	2.7	0	0	3.6	0	3.6	0	0	0	0	3.6	3.6	3.6	0	0	3.6	1.8
REW	0	0	0	2.6	0	0	3.6	0	3.6	0	0	0	0	3.6	3.6	3.6	0	0	3.6	1.8
REF. NO.	IC5001																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
STOP	1.8	0	0	3.6	0.1	0	0	0	0	0	0	3.6	0	0	0	0	0	0	3.6	0
PLAY	1.7	0	0	3.6	0.1	0	0	3.6	0	0	0	3.6	0	0	0	0	0	3.6	3.6	0
REC	1.8	0	0	3.6	0.1	0	0	3.6	0	0	0	3.6	0	0	0	0	0	3.6	3.6	0
F.F	1.2	0	0	3.6	0.1	0	0	0	0	0	0	3.6	0	0	0	0	0	3.6	3.6	0
REW	1.7	0	0	3.6	0.1	0	0	0	0	0	0	3.6	0	0	0	0	0	3.6	3.6	0
REF. NO.	IC5001																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	3.6	0	3.6	3.6	0	0	0	0	3.6	3.6	1.8	3.6	0	3.4	0	1.5	0	0	3.3	3.3
PLAY	3.6	0	3.6	3.6	0.5	0.4	0.4	0.4	3.6	0	0	3.6	0	0	1.7	1.8	1.5	1.6	1.7	1.7
REC	3.6	0	3.6	3.6	0.4	0.3	0.4	0.4	3.6	0	0	3.6	0	1.7	1.8	1.5	1.5	1.6	1.7	1.7
F.F	3.6	0	3.6	3.6	0.4	0.4	0.4	0.4	3.6	1.8	1.8	3.6	0	1.7	0	1.5	1.5	0	1.6	1.6
REW	3.6	0	3.6	3.6	3.6	0.3	0.4	0.4	3.6	1.8	1.8	3.6	0	1.7	0	1.5	1.5	0	1.6	1.6
REF. NO.	IC5001																			
MODE	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
STOP	0	0	0	1.5	0	3.6	0	0	3.6	0	3.7	3.6	3.6	3.6	3.6	0	3.6	3.6	3.7	0
PLAY	0	0	0	1.5	0	3.6	0	0	3.3	1.0	3.3	3.6	3.6	1.5	3.6	0	3.3	2.9	3.6	0
REC	0	0	0	1.5	1.5	3.6	0	0	3.3	1.0	3.2	3.6	3.6	1.8	3.6	0	3.3	2.8	3.6	0
F.F	0	0	0	1.5	0	3.6	0	0	3.3	3.3	3.3	3.6	3.6	3.6	3.6	0	2.8	2.8	3.6	0
REW	0	0	0	1.5	0	3.6	0	0	3.3	1.0	3.3	3.6	1.1	3.6	2.6	0	3.3	2.8	3.6	0
REF. NO.	IC5001																			
MODE	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
STOP	3.6	3.6	3.7	3.6	0	3.7	3.7	3.7	3.7	0	0	0	3.6	1.8	0	1.8	3.7	3.7	0	3.6
PLAY	3.1	3.0	3.5	3.6	0	0	0	3.7	0	0	0	1.9	1.6	0.3	0.1	1.8	3.7	3.7	0.1	1.8
REC	3.1	3.0	3.5	3.6	0	0	0	3.6	3.6	0	0	1.9	1.8	0.2	0.1	1.8	3.6	3.7	3.7	1.8
F.F	3.1	3.1	3.5	3.6	0	0	0	0	0	0	0	1.9	1.8	0.7	0	1.8	3.6	3.7	0.1	1.8
REW	3.1	3.0	3.5	3.6	0	3.7	3.7	3.7	0	0	0	1.9	1.8	0	0.4	1.8	3.7	3.7	0.1	1.8

REF. NO.	IC6001																			
MODE	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120
STOP	■	0	3.6	3.3	■	3.3	0	0	0	0	0	0	■	1.8	3.6	3.6	0	■	0	3.3
PLAY	0	3.6	1.6	1.7	1.6	1.6	1.6	1.6	0	0	0	■	■	1.8	3.6	3.6	0	0	0	2.7
REC	0	3.6	1.7	1.6	1.6	1.7	1.6	1.6	0	■	0	0	■	1.8	3.6	3.6	0	■	0	2.7
F.F	■	3.6	1.6	1.6	1.6	1.6	0	3.3	0	0	0	0	0	1.8	3.6	3.6	0	0	0	2.1
REW	0	3.6	1.6	1.6	1.6	1.6	2.9	3.3	0	0	0	0	0	1.8	3.6	3.6	0	0	■	1.0
REF. NO.	IC6001																			
MODE	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140
STOP	0	0	0	3.7	3.7	3.7	3.6	3.6	3.6	0	0	2.5	2.2	0	3.0	3.6	3.6	3.6	1.7	1.7
PLAY	0.1	0.1	0.1	3.7	3.7	3.7	3.6	3.6	3.6	■	0	2.3	0	■	0	3.6	3.6	3.6	1.6	1.6
REC	■	0	0	3.7	3.7	3.7	3.6	3.6	3.6	■	0	2.2	0	0	■	3.6	3.6	3.6	1.7	1.7
F.F	0.1	0	0	3.7	3.7	3.7	3.6	3.6	3.6	0	0	2.2	0	0	0	3.6	3.6	3.6	1.6	1.6
REW	0.1	0.1	0	3.7	3.7	3.7	3.6	3.6	3.6	0	0	2.2	0	■	0	3.6	3.6	3.6	1.7	1.6
REF. NO.	IC6001																			
MODE	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156				
STOP	1.7	1.6	1.6	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	■	3.6				
PLAY	1.5	1.6	1.5	1.5	1.5	1.5	1.5	1.5	1.6	1.5	1.5	1.5	1.5	1.6	1.6	0				
REC	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	0	3.6				
F.F	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.7	1.6	1.7	1.7	1.7	1.6	0	3.6				
REW	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	■	3.6				
REF. NO.	IC6002																			
MODE	1	2	3	4	5															
STOP	2.7	3.6	0	0	3.4															
PLAY	2.7	3.6	0	0	3.4															
REC	2.7	3.6	0	0	3.4															
F.F	2.7	3.6	0	0.9	3.4															
REW	2.7	3.6	■	0.9	3.4															
REF. NO.	IC6003																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14						
STOP	3.7	■	0	0	3.3	0	0	■	3.3	0	3.3	0	3.7	3.7						
PLAY	0	3.7	1.7	0	1.6	0	0	0	1.6	■	1.6	3.7	■	3.7						
REC	0	3.7	1.6	0	1.6	0	0	0	1.6	■	1.6	3.7	■	3.7						
F.F	0	3.7	1.5	0	1.5	0	0	0	1.5	0	1.6	3.7	■	3.7						
REW	3.7	0	1.5	0	1.5	0	0	0	1.6	0	1.6	■	3.7	3.7						
REF. NO.	IC6004										IC6005									
MODE	1	2	3	4	5	6	7	8			1	2	3	4	5					
STOP	0	0	■	0	0	3.6	3.7	3.7			0	0	■	■	3.7					
PLAY	1.6	1.6	■	■	3.7	3.7	3.7	3.7			1.6	1.6	0	1.8	3.7					
REC	1.6	1.6	0	0	3.7	3.7	3.7	3.7			1.6	1.6	0	1.8	3.7					
F.F	3.3	0	3.7	0	■	3.7	3.7	3.7			■	0	■	■	3.7					
REW	0	3.3	0	0	3.7	3.7	3.7	3.7			■	3.3	■	■	3.7					
REF. NO.	IC6006										IC6007									
MODE	1	2	3	4	5	6	7	8			1	2	3	4	5					
STOP	1.8	1.8	1.8	0	0	0	■	3.6												
PLAY	1.8	1.8	1.8	0	0	0	0	3.6												
REC	1.8	1.8	1.8	0	0	0	0	3.6												
F.F	1.8	1.8	1.8	■	0	0	0	3.6												
REW	1.8	1.8	1.8	0	0	0	0	3.6												


LSI/SYSTEM CONTROL & SERVO TRs DC VOLTAGE CHART (Mini DV : SP MODE)

REF. NO.	Q6001																	
MODE	E	C	B															
STOP	3.7	3.7	3.6															
PLAY	3.7	3.7	3.6															
REC	3.7	3.7	3.6															
F.F	3.7	3.7	3.6															
REW	3.6	3.7	3.6															
REF. NO.	QR2001			QR6001														
MODE	E	C	B	F	G	B												
STOP	3.7	0	3.6	0	3.4	0												
PLAY	3.7	0	3.6	■	3.4	0												
REC	3.7	0	3.6	0	3.4	0												
F.F	3.7	0	3.6	0	3.4	0												
REW	3.7	0	3.6	■	3.4	0												


IC3004
M52387FP




IC3005
BH7086KV





3-22. VIDEO 1 SECTION IN DIGITAL SCHEMATIC DIAGRAM







3-23. VIDEO 2 SECTION IN DIGITAL, DV JACK SCHEMATIC DIAGRAMS








3-24. EDITING CONTROLLER SCHEMATIC DIAGRAM




3-25. IR, FRONT LED SCHEMATIC DIAGRAMS




IC7503 (M66010GP): SUB MICON

PIN. NO.	SIGNAL NAME	I/O	EXPLANATION	PIN. NO.	SIGNAL NAME	I/O	EXPLANATION
1	DO	O	Serial Data	17	EDIT	O	LED ON Edit
2	DI	I	Serial Data	18	V INS	O	LED ON Video Insert
3	CLK	I	Serial Clock	19	A DUB	O	LED ON Audio Dubbing
4	CS	I	I/O Chip Select	20	POWER	O	LED ON Power
5	VCC	I		21	A INS	O	LED ON Audio Insert
6	—	I		22	T REC	O	LED ON Timer Rec
7	GND	—		23	TAPE	O	LED ON Cassette In
8	ST2	O	LED ON Data Stereo 2	24	STAND BY	O	LED ON Stand By
9	ST1	O	LED ON Data Stereo 1	25	ST2 MONI	O	LED ON Monitor Stereo 2
10	12bit	O	LED ON 12 Bit	26	ST1 MONI	O	LED ON Monitor Stereo 1
11	16bit	O	LED ON 16 Bit	27	REM LED	O	LED ON
12	DIG OUT	O	LED ON DV Output	28	—	O	
13	DIG IN	O	LED ON DV Input	29	—	—	
14	CAS L	O	LED Normal Cassette	30	—	—	
15	CAS S	O	LED On Mini Cassette	31	—	—	
16	GND	—		32	—	—	



3-26. TIMER, MODULAR SCHEMATIC DIAGRAMS




3-27. AUDIO SCHEMATIC DIAGRAM




3-28. NICAM DECODER SCHEMATIC DIAGRAM



3-29. INPUT/OUTPUT, REAR JACK SCHEMATIC DIAGRAMS




■➡ : AUDIO MAIN SIGNAL PATH IN REC MODE
 □➡ : AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE




NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

3-30. TV DEMODULATOR SCHEMATIC DIAGRAM




3-31. POWER SUPPLY C.B.A. (VEP01814A)

CAUTION THE STRIPED FRAME INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT. PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCTS.




3-34. MAIN C.B.A. (VEP06C40B: NV-DV10000B) (VEP06C40A: NV-DV10000EC)




3-35. FRONT (L) C.B.A. (VEP04695B)

MAIN C.B.A.						
Transistor		QR2210	D-3	IP		
Q1001	B-3	QR2211	D-3	IP1001	B-2	
Q1002	B-2	QR2212	D-3	IP1002	D-2	
Q1003	F-1	QR2213	D-4	IP1003	B-2	
Q1004	E-1	QR2214	E-5	IP1004	B-2	
Q1005	D-1	QR2215	E-5	IP1005	F-1	
Q1008	F-1	QR2216	E-4	IP1006	E-2	
Q1009	C-2	QR2217	E-4	IP1007	D-2	
Q1010	D-2	QR2218	E-4	IP1008	C-3	
Q1011	B-2	QR2220	B-5	IP1009	F-1	
Q1012	F-1	QR2221	C-6	IP1011	A-2	
Q1017	C-1	QR2222	C-1	IP7601	F-8	
Q1018	C-2	QR3601	F-4	Test Point		
Q1020	A-3	QR3602	F-4			
Q1023	B-3	QR3603	F-4			
Q1024	C-3	QR3604	F-4			
Q1025	A-2	QR3605	F-4			
Q1026	A-2	QR4701	E-6			
Q1027	A-3	QR4702	E-6			
Q1028	C-3	QR4703	D-6	TL2202	B-7	
Q1029	B-3	QR4704	E-8	TL2203	A-6	
Q1030	A-2	QR4706	D-7	TL3601	C-4	
Q2201	B-6	QR7601	D-8	TL3602	C-4	
Q2202	C-6	Integrated Circuit		TL8001	A-4	
Q2203	B-6			TP2201	A-7	
Q2204	B-5	IC1001	B-3	TP3701	B-7	
Q2205	D-3	IC1003	E-2	TP3702	B-9	
Q2206	C-5	IC1004	A-2	Connector		
Q2207	C-5	IC1005	F-2			
Q2208	E-5	IC1006	C-3	P3701	C-1	
Q3601	C-5	IC1007	C-2	P4001	C-1	
Q4001	D-8	IC1008	F-5	P6201	B-7	
Q4002	D-8	IC1009	C-1	P6401	B-8	
Q4003	C-7	IC2201	A-8	P6701	E-5	
Q4004	D-7	IC2202	C-6	P6703	E-3	
Q4005	D-7	IC2203	B-5	P6707	B-1	
Q4701	E-6	IC2204	B-6	P7901	A-8	
Q4702	E-6	IC2205	B-6	P7902	C-1	
Q7601	D-8	IC2206	E-5	PK7301	C-8	
Q7604	B-8	IC2207	D-5	PK7302	B-8	
Q7605	B-8	IC2208	D-5	PP3401	F-5	
Q7606	B-8	IC2209	B-4	PP3402	F-6	
Transistor & Resistor		IC2210	B-5	PP3403	F-7	
		IC2211	E-4	PP3404	F-5	
		IC2212	E-4	PP3501	F-5	
		IC2213	E-5	PP3502	F-3	
		IC2214	E-4	PP3503	F-2	
		IC2215	E-4	PP3610	E-4	
		IC2216	E-4	PP4002	C-7	
		IC3601	F-6	PP4003	D-7	
		IC3602	F-2	PP6706	E-1	
		IC3603	C-4	TU7601	E-8	
		IC4001	F-7			
		IC4002	F-7			
		IC4003	F-7			
		IC4004	E-8			
		IC4701	E-6			
		IC4702	D-6			
		IC7651	F-8			
		IC7905	C-8			
IC7906	B-8					






3-36. FRONT (R) C.B.A. (VEP04696B)



3-37. HEAD AMP C.B.A. (VEP05351A)


NOTE: MULTILAYER C.B.A.
THIS C.B.A. IS MULTILAYER C.B.A. THIS CIRCUIT BOARD SHOWS COMPONENT LAYOUT-PATTERN FOR COMPONENT SIDE AND FOIL SIDE. LAYOUT-PATTERNS ARE SINILE PATTERN FOR EACH SIDE THAT MAKE EASY TO SIGHT THE COMPONENT LAYOUT.





ANALOG Y/C C.B.A.											
Transistor		Q30025	A-6	Transistor & Resistor		IC30018	B-3	VR30003	A-8		
Q30001	A-2	Q30026	A-6	QR30001	B-2	IC30019	A-1	VR30004	B-10		
Q30002	A-2	Q30027	A-7	QR30003	A-4	Test Point		Connector			
Q30003	B-9	Q30028	B-3	QR30004	A-7						
Q30004	B-9	Q30030	A-3	QR30005	B-1	TL30006	B-2	PS30001	A-2		
Q30005	B-8	Q30031	A-8	QR30006	A-2	TP30001	A-3	PS30002	A-4		
Q30006	B-8	Q30032	A-8	Integrated Circuit		TP30002	B-2	PS30003	A-5		
Q30007	B-3	Q30033	A-7			TP30003	B-1				
Q30008	B-3	Q30034	A-7	IC30001	B-3	TP30004	A-3				
Q30009	B-8	Q30035	A-7	IC30002	A-3	TP30005	B-3				
Q30010	B-2	Q30036	A-9	IC30003	A-3	TP30007	A-4				
Q30011	B-10	Q30037	A-1	IC30004	A-2	TP30008	A-4				
Q30012	B-2	Q30038	A-10	IC30005	B-1	TP30009	A-4				
Q30013	B-9	Q30039	A-10	IC30006	A-1	TP30010	A-4				
Q30014	B-9	Q30040	A-10	IC30007	A-1	TP30011	B-1				
Q30015	A-9	Q30042	A-8	IC30008	B-9	TP30012	A-3				
Q30016	B-1	Q30043	A-10	IC30009	A-3	TP30013	B-1				
Q30017	A-9	Q30044	A-2	IC30010	B-1	TP30014	B-4				
Q30018	B-1	Q30045	A-8	IC30011	B-1	Adjustment					
Q30019	A-10	Q30046	A-3	IC30012	A-5						
Q30020	B-10	Q30047	A-3	IC30013	B-6	VC30001	B-10				
Q30021	B-10	Q30048	A-8	IC30014	B-6	VC30002	A-7				
Q30022	B-10	Q30049	A-9	IC30015	B-5	VC30003	B-9				
Q30023	B-10			IC30016	B-3	VR30001	A-8				
Q30024	B-10			IC30017	B-4	VR30002	B-2				

ADDRESS INFORMATION




3-39. DIGITAL C.B.A. (VEP03E55A)

Transistor		Diode		Test Point		TL32		TL3208		TL6014		X3001		L4501		C2011		C3003		C3030		C3066		C3082		C3109		C3217		C3242		C3282		B-9	
Q3001	A-4	IC3002	B-7	D2001	A-9	TL1	A-1	TL3209	B-2	TL6015	B-10	X3003	B-4	L4502	B-7	C2012	A-10	C3004	A-7	C3031	A-7	C3057	A-6	C3093	B-6	C3110	A-5	C3218	B-3	C3243	B-8	C3283	B-2		
Q3002	A-4	IC3003	B-4	D2003	B-9	TL4	A-9	TL3210	B-2	TL6016	B-10	X3004	A-4	LB2002	A-9	C2013	A-10	C3005	B-7	C3032	A-7	C3058	A-6	C3094	B-5	C3111	A-4	C3219	B-8	C3244	B-2	C3301	A-10		
Q3003	A-7	IC3004	B-6	D2004	B-9	TL5	A-9	TL3211	B-2	TL6017	B-10	X6001	A-1	LB2003	A-10	C2014	B-3	C3006	A-7	C3033	B-7	C3059	B-7	C3085	B-5	C3112	B-7	C3220	B-8	C3245	B-2	C3302	A-10		
Q3004	A-5	IC3005	B-8	D2005	B-9	TL9	B-9	TL3212	B-2	TL6018	B-10	Coil		LB2004	A-3	C2015	B-3	C3007	B-4	C3034	A-7	C3060	A-5	C3086	A-4	C3113	B-7	C3221	B-2	C3246	B-2	C3303	A-10		
Q3005	A-5	IC3006	A-7	D2006	A-3	TL10	A-1	TL3214	B-2	TL6020	B-10			LB3001	A-5	C2016	A-2	C3008	B-4	C3035	B-5	C3061	A-5	C3087	A-6	C3114	B-7	C3222	B-3	C3247	B-2	C3304	A-10		
Q3006	A-5	IC3007	A-4	D2007	B-9	TL11	A-1	TL3216	B-2	TL6021	B-10	L2001	A-9	LB3002	A-6	C2017	A-2	C3010	B-7	C3036	B-5	C3062	B-4	C3090	B-4	C3115	B-7	C3223	B-3	C3248	B-2	C3305	A-10		
Q3007	A-7	IC3008	B-7	D2008	A-2	TL12	A-1	TL3217	B-2	TL6024	B-10	L2002	B-9	LB3004	A-3	C2018	A-9	C3011	B-4	C3037	B-6	C3063	A-4	C3091	A-7	C3116	A-7	C3224	B-2	C3249	B-9	C3306	A-10		
Q3008	A-7	IC3009	A-4	D2009	A-10	TL13	A-2	TL3218	B-2	TL6025	B-10	L3001	A-4	LB3006	A-7	C2019	A-9	C3012	B-4	C3038	B-6	C3064	A-4	C3092	A-7	C3117	A-7	C3225	B-2	C3250	B-2	C3307	A-10		
Q3201	B-2	IC3201	A-3	D2011	B-10	TL14	A-2	TL3219	B-2	TL6026	B-10	L3002	A-4	LB3701	B-5	C2020	A-9	C3013	B-4	C3039	B-6	C3065	A-4	C3093	A-5	C3201	A-4	C3226	B-9	C3251	B-3	C3308	A-10		
Q6001	B-1	IC3202	A-8	D2012	B-10	TL16	B-2	TL3220	B-2	TL6029	B-10	L3003	A-7	LB3702	B-6	C2021	B-3	C3014	B-7	C3040	B-6	C3067	A-6	C3094	A-5	C3202	B-7	C3227	B-8	C3252	B-3	C3309	A-10		
Transistor & Resistor		IC3203	B-9	D2013	A-10	TL17	B-2	TL3221	B-2	TL6030	B-10	L3004	A-5	LB3703	B-6	C2022	A-3	C3015	B-4	C3041	B-5	C3068	A-4	C3095	A-6	C3203	B-4	C3228	B-9	C3253	B-3	C3310	A-10		
		IC3204	B-6	D2014	B-2	TL18	A-2	TL3222	B-2	TL6031	B-10	L3005	A-4	LB6004	A-6	C2023	A-3	C3016	B-4	C3042	A-5	C3069	A-4	C3096	A-6	C3204	B-3	C3229	B-9	C3254	B-3	C3311	A-10		
QR2001		IC3205	B-3	D2015	B-2	TL19	A-2	TL3223	B-2	TL6032	B-10	L3006	A-5	Capacitor		C2024	B-9	C3017	B-7	C3043	A-4	C3070	A-4	C3097	B-6	C3205	B-7	C3230	B-8	C3255	B-2	C3312	A-9		
		IC3206	B-2	D2016	A-5	TL20	B-9	TL3224	B-2	TL6033	B-10	L3007	A-7			C2025	A-3	C3018	A-4	C3044	A-4	C3071	A-4	C3098	B-7	C3206	B-8	C3231	B-9	C3256	B-2	C3313	A-9		
QR2002	A-9	IC3207	B-2	D3002	A-5	TL21	B-2	TL3225	B-2	Connector		L3008	B-5	C2026	B-3	C2027	B-10	C3019	A-4	C3045	A-4	C3072	A-4	C3099	B-4	C3207	B-3	C3232	A-3	C3257	B-8	C3314	A-9		
QR2003	A-9	IC3701	B-5	D3003	B-7	TL22	B-2	TL3226	B-2			L3009	B-5	C2027	B-10	C2028	B-9	C3020	B-4	C3046	A-4	C3073	B-7	C3100	B-4	C3208	B-8	C3233	B-2	C3258	A-4	C3315	A-9		
QR6001	B-1	IC4201	B-7	D3004	B-3	TL23	B-2	TL3227	B-2	FP3201	B-2	L3010	A-5	C2028	B-9	C2029	A-9	C3021	A-7	C3047	A-4	C3074	B-7	C3101	B-5	C3209	B-3	C3234	B-9	C3259	A-3	C3316	A-9		
Integrated Circuit		IC4210	B-3	D4501	B-7	TL24	B-2	TL3228	B-2	P3701	B-5	L3201	B-7	C2029	A-9	C2030	A-9	C3022	A-7	C3048	A-4	C3075	B-4	C3102	A-6	C3210	B-3	C3235	B-9	C3260	B-8	C3317	A-9		
		IC4501	B-4	D6002	B-10	TL25	B-2	TL3229	B-2	PS3001	A-8	L3202	B-9	C2030	A-9	C2031	B-2	C3023	A-4	C3049	A-6	C3076	B-5	C3103	A-4	C3211	B-3	C3236	B-2	C3261	B-8	C3318	A-9		
IC2001	A-2	IC6001	B-10	D6003	B-10	TL26	B-9	TL3230	B-9	PS3002	B-4	L3203	B-7	C2031	B-2	C2032	A-9	C3024	A-4	C3050	A-4	C3077	B-5	C3104	A-7	C3212	B-6	C3237	B-9	C3262	B-3	C3319	A-9		
IC2002	A-2	IC6002	B-1	D6004	B-10	TL27	A-2	TL3231	B-9	TL6005	B-9	L3204	B-7	C2032	A-9	C2033	B-2	C3025	A-7	C3051	A-4	C3078	B-4	C3105	B-7	C3213	B-3	C3238	B-3	C3263	B-8	C3320	A-9		
IC2004	A-10	IC6003	B-1	D6005	B-10	TL28	A-2	TL3232	B-9	TL6006	B-9	L3205	B-8	C2033	B-2	C2034	A-6	C3026	B-5	C3052	A-6	C3079	B-4	C3106	B-4	C3214	B-3	C3239	B-8	C3267	B-2	C3321	A-9		
IC2005	A-8	IC6004	B-1	D6007	B-1	TL29	B-1	TL3233	B-9	TL6007	B-1	L3206	B-8	C2034	A-6	C3001	A-4	C3027	A-6	C3053	A-4	C3080	B-4	C3107	B-4	C3215	B-3	C3240	B-3	C3268	B-2	C3322	A-9		
IC2006	A-3	IC6005	B-1	D6008	B-1	TL30	A-2	TL3234	B-9	TL6008	B-10	L3207	B-9	C2035	B-2	C3002	A-4	C3028	A-6	C3054	A-4	C3081	A-4	C3108	A-6	C3216	B-8	C3241	B-3	C3269	B-9	C3323	A-9		
IC3001	B-4	IC6006	A-1			TL31	B-1	TL3235	B-3	TL6009	B-10	L4201	B-4																						


ADDRESS INFORMATION

NOTE: MULTILAYER C.B.A.
THIS C.B.A. IS Multi-Layer C.B.A. THIS CIRCUIT BOARD SHOWS COMPONENT LAYOUT-PATTERN FOR COMPONENT SIDE AND FOIL SIDE. LAYOUT-PATTERNS ARE SINGLE PATTERN FOR EACH SIDE THAT MAKE EASY TO SIGHT THE COMPONENT LAYOUT.



AV DIGITAL C.B.A.																																					
C3324	A-9	C3351	A-8	C3380	A-7	C4203	B-7	C6002	B-1	C6030	B-1	R2018	A-9	R2045	A-8	R2082	B-3	R3006	B-4	R3041	A-6	R3070	B-6	R3101	A-7	R3213	B-3	R3240	B-2	R3302	A-10	R3724	B-6	R4217	B-8		
C3325	A-9	C3352	A-8	C3701	B-6	C4206	B-8	C6003	B-1	C6033	B-1	R2017	A-9	R2047	A-8	R2084	B-3	R3009	B-5	R3042	A-5	R3072	B-6	R3102	B-7	R3214	B-8	R3241	B-2	R3303	A-10	R3725	B-5	R4218	B-3		
C3326	A-8	C3353	A-8	C3702	B-6	C4207	B-4	C6004	B-1	C6034	B-10	R2018	A-9	R2048	A-8	R2085	A-2	R3010	A-7	R3043	B-6	R3073	B-6	R3117	A-6	R3215	B-8	R3242	B-8	R3304	A-9	R3728	B-5	R4219	B-6		
C3327	A-9	C3354	A-8	C3703	B-5	C4211	B-7	C6005	B-10	C6035	B-1	R2019	A-2	R2049	A-7	R2086	A-9	R3011	A-6	R3044	B-7	R3074	A-6	R3120	B-4	R3217	B-3	R3243	B-9	R3305	A-9	R3729	B-5	R4220	B-8		
C3328	A-9	C3355	A-8	C3704	B-5	C4212	B-7	C6006	B-1	C6036	B-1	R2020	A-2	R2050	A-8	R2087	A-2	R3012	A-6	R3046	B-7	R3075	B-5	R3121	B-4	R3218	B-2	R3245	A-3	R3306	A-9	R3730	B-5	R4221	B-8		
C3329	A-9	C3356	A-8	C3705	B-5	C4213	B-7	C6007	B-1	C6041	B-1	R2021	A-1	R2052	A-8	R2088	A-9	R3013	A-6	R3047	B-7	R3077	B-4	R3122	B-4	R3219	B-3	R3246	B-3	R3307	A-8	R3731	B-5	R4222	B-4		
C3330	A-9	C3357	A-8	C3706	B-6	C4214	B-8	C6008	B-1	C6043	B-1	R2022	A-1	R2055	A-1	R2090	A-9	R3014	B-6	R3048	B-4	R3079	B-7	R3123	B-7	R3220	B-2	R3249	B-3	R3308	A-8	R3732	B-6	R4223	B-7		
C3331	A-9	C3360	A-8	C3707	B-6	C4215	B-3	C6009	B-1	C6044	A-10	R2023	A-1	R2056	A-8	R2092	B-1	R3016	A-6	R3049	B-7	R3080	B-6	R3128	A-5	R3221	B-3	R3256	B-9	R3309	A-8	R3733	B-6	R4224	B-7		
C3332	A-9	C3361	A-8	C3710	B-8	C4217	B-8	C6010	B-1	C6045	A-1	R2024	A-1	R2057	A-9	R2099	B-2	R3017	A-7	R3050	B-6	R3081	B-6	R3129	A-5	R3222	B-2	R3257	B-8	R3310	A-9	R3735	B-6	R4225	B-3		
C3333	A-9	C3362	A-8	C3711	B-6	C4218	B-8	C6011	B-1	C6046	B-1	R2025	A-1	R2058	A-1	R2100	B-2	R3018	A-7	R3051	B-6	R3082	B-4	R3130	A-7	R3223	B-2	R3258	B-9	R3312	A-7	R3736	B-5	R4226	B-3		
C3335	A-9	C3363	A-8	C3712	B-6	C4219	B-8	C6012	B-1	Resistor		R2026	A-1	R2059	A-1	R2101	B-2	R3019	A-4	R3052	B-6	R3083	B-4	R3131	A-7	R3224	B-2	R3259	B-9	R3701	B-8	R3737	B-5	R4227	B-4		
C3337	A-9	C3364	A-8	C3713	B-6	C4220	B-4	C6015	B-1	Resistor		R2027	A-1	R2060	A-8	R2102	B-2	R3020	A-4	R3053	B-4	R3084	B-4	R3132	A-7	R3225	B-2	R3260	B-9	R3702	B-6	R3739	B-6	R4228	B-3		
C3338	A-2	C3365	A-8	C3714	B-6	C4221	B-4	C6017	B-1	R2001	A-9	R2028	A-9	R2061	B-9	R2104	B-9	R3021	A-7	R3054	B-4	R3085	B-4	R3133	A-7	R3226	B-9	R3261	B-9	R3703	B-6	R3740	B-6	R4229	B-7		
C3339	A-8	C3367	A-8	C3715	B-6	C4222	B-3	C6018	B-1	R2002	A-9	R2029	A-1	R2062	B-10	R2105	B-9	R3022	B-6	R3057	B-5	R3086	B-7	R3201	B-8	R3227	B-2	R3262	B-9	R3709	B-5	R4203	B-7	R4230	B-7		
C3340	A-2	C3368	A-8	C3716	B-6	C4223	B-3	C6019	B-1	R2003	B-9	R2030	A-1	R2063	A-7	R2106	B-2	R3023	B-8	R3058	B-5	R3088	A-4	R3202	B-3	R3228	B-9	R3263	B-2	R3710	B-5	R4204	B-7	R4231	B-7		
C3341	A-8	C3369	A-7	C3717	B-6	C4224	B-7	C6020	B-1	R2006	A-2	R2031	A-1	R2064	A-7	R2111	A-1	R3024	B-6	R3059	A-8	R3089	A-6	R3203	B-2	R3229	B-8	R3264	B-9	R3711	B-6	R4205	B-7	R4232	B-7		
C3342	A-8	C3370	A-7	C3718	B-6	C4225	B-7	C6021	B-1	R2007	A-2	R2032	B-9	R2065	A-1	R2112	A-1	R3026	B-4	R3060	A-6	R3090	A-5	R3204	B-9	R3230	B-8	R3265	B-9	R3715	B-6	R4206	B-7	R4233	B-4		
C3343	A-8	C3371	A-7	C3719	B-6	C4501	B-4	C6022	B-1	R2008	A-2	R2033	B-9	R2068	A-9	R2113	A-9	R3027	B-6	R3061	A-6	R3091	A-8	R3205	B-2	R3232	B-9	R3266	B-9	R3716	B-8	R4207	B-8	R6001	B-1		
C3344	A-8	C3372	A-7	C3720	B-5	C4502	B-4	C6023	B-1	R2009	A-2	R2034	A-9	R2073	A-8	R2115	A-7	R3028	B-6	R3063	B-4	R3092	A-4	R3206	B-9	R3233	B-2	R3267	A-3	R3717	B-6	R4208	B-6	R6003	B-10		
C3345	A-8	C3374	A-7	C3721	B-5	C4503	B-4	C6024	B-10	R2010	A-9	R2035	A-9	R2074	B-3	R2118	A-10	R3034	A-6	R3064	B-4	R3094	A-4	R3207	B-9	R3234	B-2	R3268	B-9	R3718	B-6	R4209	B-8	R6006	B-10		
C3346	A-8	C3375	A-7	C3722	B-5	C4504	B-4	C6025	B-1	R2011	A-9	R2036	A-9	R2076	B-3	R2119	A-9	R3035	A-8	R3065	B-6	R3095	B-6	R3208	B-9	R3235	B-8	R3269	B-6	R3719	B-6	R4210	B-4	R6008	B-10		
C3347	A-8	C3376	A-6	C3723	B-6	C4505	B-4	C6026	B-1	R2012	A-2	R2038	A-9	R2077	B-3	R3001	B-4	R3036	A-7	R3066	B-7	R3097	A-7	R3209	B-9	R3236	B-8	R3270	B-6	R3720	B-6	R4213	B-7	R6009	B-9		
C3348	A-8	C3377	A-6	C3724	B-6	C4506	B-4	C6027	B-1	R2013	A-2	R2039	B-9	R2079	A-2	R3003	B-4	R3037	A-6	R3067	A-4	R3098	A-5	R3210	B-9	R3237	B-2	R3271	B-8	R3721	B-6	R4214	B-7	R6010	B-10		
C3349	A-8	C3378	A-7	C3725	B-6	C4515	B-4	C6028	B-1	R2014	A-2	R2040	A-9	R2080	B-9	R3004	A-4	R3038	A-7	R3068	A-5	R3099	A-5	R3211	B-9	R3238	B-3	R3272	B-6	R3722	B-6	R4215	B-8	R6011	B-1		
C3350	A-8	C3379	A-7	C3726	B-6	C6001	B-10	C6029	B-1	R2015	A-9	R2042	B-9	R2081	A-3	R3005	B-4	R3039	A-7	R3069	A-5	R3100	A-5	R3212	B-9	R3239	B-3	R3301	A-1	R3723	B-6	R4216	B-8	R6012	B-10		


ADDRESS INFORMATION




AV DIGITAL C.B.A. (3)															
R6014	B-10	R6027	A-8	R6042	B-10	R6051	B-1	R6060	B-10	R6070	B-1	R6085	A-9	R6097	B-10
R6015	B-10	R6028	A-8	R6043	B-10	R6052	B-1	R6061	B-10	R6071	A-10	R6087	B-10	R6098	A-10
R6016	B-10	R6029	B-10	R6044	B-10	R6053	B-10	R6063	A-10	R6072	A-1	R6089	A-8	R6099	B-10
R6017	B-10	R6034	A-9	R6045	B-10	R6054	B-1	R6064	A-10	R6073	B-1	R6090	B-1	R6100	A-9
R6018	B-10	R6035	A-9	R6046	B-1	R6055	B-1	R6065	A-10	R6074	A-9	R6091	B-1	R6101	B-10
R6019	B-10	R6036	B-10	R6047	B-1	R6056	B-1	R6066	B-1	R6075	A-9	R6092	B-10	R6102	B-1
R6024	B-10	R6037	B-10	R6048	B-1	R6057	B-1	R6067	B-10	R6076	B-10	R6093	B-10	R6103	B-1
R6025	A-8	R6038	B-10	R6049	B-1	R6058	A-9	R6068	B-1	R6077	A-9	R6095	A-10	R6104	B-1
R6026	A-8	R6039	A-9	R6050	B-1	R6059	A-9	R6069	B-1	R6078	A-9	R6096	A-8	R6105	B-10

ADDRESS INFORMATION


3-40. MOTOR DRIVE C.B.A. (VEP06C89A)




3-41. MODULAR C.B.A. (VEP07966A)




3-42. IR C.B.A. (VEP07968B)




3-43. FRONT LED C.B.A. (VEP07965A)



3-44. 5P JACK C.B.A. (VEP03E18A)




3-45. EDITING CONTROLLER C.B.A. (UR57VPB623)




TIMER C.B.A.			
Transistor & Resistor		Integrated Circuit	
QR7501	B-1	IC7501	A-6
QR7502	B-1	IC7502	B-8
QR7503	B-2	IC7503	B-2
QR7504	B-2	IC7504	A-4
QR7505	B-2	IC7505	B-8
QR7506	B-1	Adjustment	VR4004 B-2
QR7507	B-8		
QR7508	B-8		
QR7509	B-2	Connector	P7501 B-1 P7502 B-8 P7503 A-7 P7504 A-3
QR7510	B-2		
QR7511	B-1		
QR7512	B-2		
QR7513	B-2		
QR7514	B-2		
QR7515	A-4		
QR7516	A-4		
QR7517	A-4		
QR7518	A-5		
QR7519	A-5		
QR7520	A-3		
QR7521	A-3		
QR7522	A-3		
QR7523	A-2		


ADDRESS INFORMATION

3-46. TIMER C.B.A. (VEP07977A)



3-47. MECHANISM DRIVE C.B.A. (VEP02557B)







MECHANISM DRIVE C.B.A.			
Transistor		IC2715	D-9
Q2701	E-5	IC6301	C-7
Q2703	D-8	IC6302	C-8
Q2704	D-8	IC6303	B-8
Q6301	C-8	IC6304	A-8
Q6302	C-8	IC6305	A-7
Q6303	C-8	IC6306	A-8
Q6304	B-8	IC6501	E-5
Q6305	B-8	IC6502	A-2
Q6306	B-8	IC6503	E-12
Q6307	C-7	IC6504	E-12
Q6308	C-8	IC6505	E-12
Q6502	D-10	IC6506	A-11
Q6503	B-11	IC6507	D-11
Q6504	E-1	IC6508	D-10
Q6505	B-11	IC6509	D-11
Transistor & Resistor		IC6510	D-11
QR2701	E-8	IC6511	E-10
QR6301	C-8	IC6512	A-10
QR6302	C-8	IC6513	D-10
QR6303	B-8	IC6514	A-3
QR6304	A-7	Test Point	
QR6305	B-8	TL2701	D-1
QR6306	A-8	TL2702	D-1
QR6307	B-8	TP2701	D-1
QR6308	B-8	TP2702	D-1
QR6309	B-8	TP2703	D-1
QR6314	C-7	TP2704	D-1
QR6315	C-8	TP6501	D-1
QR6316	B-7	TP6502	E-2
QR6317	C-8	TP6503	E-2
QR6318	C-4	TP6404	E-3
QR6501	E-8	TP6505	E-5
QR6502	D-10	Adjustment	
QR6503	A-10	VR2701	E-1
QR6504	B-11	VR2702	E-1
QR6505	B-10	VR6501	E-1
QR6506	A-10	VR6502	E-1
QR6507	A-10	Connector	
QR6508	E-6	P2701	B-8
QR6511	B-2	P2702	B-10
QR6514	A-10	P2703	C-9
QR6515	A-10	P2704	D-8
QR6516	E-8	P2705	E-6
QR6517	E-5	P6301	B-11
Integrated Circuit		P6302	C-7
IC2701	D-11	P6303	C-7
IC2702	D-11	P6501	D-7
IC2703	A-4	P6502	C-1
IC2704	B-2	P6503	E-11
IC2705	E-12	P6504	E-4
IC2706	E-8	P6505	E-3
IC2707	D-8	P6506	E-11
IC2708	C-10	P6507	C-11
IC2709	C-4	P6508	C-11
IC2710	C-4	P6509	B-7
IC2711	C-4	P6510	C-7
IC2712	C-4	P6514	D-7
IC2713	D-12	P6520	B-11
IC2714	D-8		

ADDRESS INFORMATION

AUDIO C.B.A.									
Transistor		Q4310	B-8	Integrated Circuit		IC4310	D-8		
Q4301	B-5	Q4311	C-2	IC4301	B-4	IC4311	D-8		
Q4302	C-2	Q4312	D-2	IC4302	B-9	IC4312	C-2		
Q4303	B-3	Q4313	C-1	IC4303	B-6	IC4313	D-3		
Q4304	B-2	Q4314	D-9	IC4304	B-6	IC4314	D-2		
Q4305	B-2	Q4315	D-10	IC4305	C-3	IC4315	C-8		
Q4306	B-2	Transistor & Resistor		IC4306	D-6	IC4316	C-4		
Q4307	C-2	QR4301	B-1	IC4307	D-9	Connector			
Q4308	B-9	QR4302	B-1	IC4308	C-6	PS4301	A-4		
Q4309	B-3	QR4303	D-1	IC4309	E-3	PS4302	A-3		


ADDRESS INFORMATION



3-49. INPUT/OUTPUT C.B.A. (VEP03E28A)

INPUT/OUTPUT C.B.A.						
Transistor		Transistor & Resistor		IC3904		Connector
Q3901	A-3	QR3901	A-3	IC3904	B-4	
Q3902	B-4	QR3902	B-3	IC4901	B-2	P3901
Q3903	B-4	QR3903	B-3	Test Point	B-1	PP3901
Q3904	A-4	QR3904	B-4			PS3901
Q3905	A-4	Integrated Circuit	B-2	TP3002	B-2	PS3902
Q3906	A-4			TP3021	B-2	PS3903
Q3907	A-4			TP3030	B-2	PS3904
Q3908	A-5	IC3901	B-2	TP3031	B-2	
	A-5	IC3902	B-5	TP3032	B-2	
		IC3903	A-4	TP3901	B-1	

ADDRESS INFORMATION



5

4

3


2

1

B

A


**3-50. NICAM DECODER PACK C.B.A. (VEP07973A: NV-DV10000B)
(VEP07973B: NV-DV10000EC)**



NICAM DECODER PACK C.B.A.	
Integrated Circuit	
IC7301	B-2
IC7302	A-2
Test Point	
TL7301	A-2
TL7303	B-2
TL7304	B-2
Connector	
PK7301	A-1
PK7302	A-2

ADDRESS INFORMATION

**3-51. TV DEMODULATOR PACK C.B.A. (VEP07801AQ: NV-DV10000B)
(VEP07801AR: NV-DV10000EC)**




TV DEMODULATOR PACK C.B.A.	
Transistor	
Q0701	B-1
Q0702	B-1
Integrated Circuit	
IC0701	B-2
Test Point	
TL0703	B-2
Adjustment	
T0703	A-2
T0704	A-3
T0711	C-1
VR0701	C-1
Connector	
PK0701	C-2
PP0701	C-3

ADDRESS INFORMATION

SECTION 4 EXPLODED VIEWS & PARTS LIST

4-1. EXPLODED VIEW & MECHANICAL REPLACEMENT PARTS LIST


● CASING PARTS SECTION




Notes: 1. *Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark Δ have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name ■ Description	Pcs	Remarks
1	EUR571503	EDITING CONTROLLER	1	
2	VOK2447	SIDE PANEL (L)	1	
3	VOK2448	SIDE PANEL (R)	1	
4	VOM1493	TOP PANEL	1	
5	VG04455	MODULAR CAP	1	
6	VSP1082	FRONT SW ASS'Y	1	
7	VG02807	FLEXIBLE CABLE HOLDER	1	
8	VJF0498	CLAMPER	1	
9	VKW2399	IR WINDOW	1	
11	VXA6019	DOOR ANGLE (L) ASS'Y	1	
12	VXA6019	DOOR ANGLE (R) ASS'Y	1	
13	VXA6045	DAMPER ANGLE (L) ASS'Y	1	
14	VXA6045	DAMPER ANGLE (R) ASS'Y	1	
15	VYF2579	DOOR (L) ASS'Y	1	
16	VGP4571	DOOR PANEL	1	
17	VGU7567	LOCK BUTTON (L)	1	
18	VGU7568	LOCK BUTTON (R)	1	
19	VMB3186	LOCK LEVER SPRING (L)	1	
	VMB3187	LOCK LEVER SPRING (R)	1	
21	VM00837	RUBBER BUSH (A)	2	
22	VML3269	LOCK LEVER (L)	1	
23	VML3270	LOCK LEVER (R)	1	
24	VMT0212	CUSHION RUBBER	2	
25	VWJ1199	FLAT CABLE (8P)	1	P7752-P7504
26	VYF2577	DOOR (C) ASS'Y	1	
27	VYF2569	DOOR (R) ASS'Y	1	A9-DV2700E
27	VYF2570	DOOR (R) ASS'Y	1	A9-DV2700B
28	VYF7098	FRONT PANEL (1) ASS'Y	1	
31	VRF0087	PAPER FAN MOTOR ASS'Y	1	
32	VKF3003	REAR COVER	1	
33	VKA0301	CERAMIC LEG	8	
34	VMG1031	LEG SHEET A	2	
35	VMG1049	LEG SHEET B	3	
36	VKU0528	BOTTOM PLATE	1	
37	VKA0310	LEG (F)	2	
38	VKA0311	LEG (R)	2	
39	VMC1085	EARTH SPRING	1	
40	VMZ2721	SHIELD SHEET	1	
41	VSC4795	SHIELD PLATE	1	
42	VSC4756	SHIELD PLATE (B3)	1	
43	VSC4757	SHIELD PLATE (B4)	1	
44	VSC4691	SHIELD PLATE	1	
45	VXA6178	TOP ANGLE ASS'Y	1	
48	VJH0979	ANTENNA JACK PLATE	1	
49	VMC1213	ANTENNA EARTH SPRING	1	
50	VEEC024	WIRE CABLE (14P)	1	P2705-P2502
51	VEEC026	WIRE CABLE (6P)	1	P3701-P7851
52	VEEC025	WIRE CABLE (4P)	1	P3781-P6601
53	VMC1374	REDUCTION SPRING	1	
54	VXU1478	DOOR BUTTON ASS'Y	1	
55	VMZ2868	BARRIER (C)	1	
56	VMZ2869	BARRIER (D)	1	
57	VSO0667	FERRITE CORE	1	
58	VMT0442	SPONGE MAT	1	
59	VJR3	WIRE CLAMPER	2	
B1	XQN26+AG6FZ	SCREW	7	
B2	XTN26+6GFZ	SCREW	4	
B3	XTN26+8GR	SCREW	8	
B4	XTB3+16GFZ	SCREW	4	
B5	XTV3+8GFZ	SCREW	1	
	XTN3+12TR	SCREW	4	
B7	XSN2+6	SCREW	1	
	XTV3+20GR	SCREW	2	
	XTV3+8G	SCREW	8	
B10	XTV3+10GR	SCREW	8	
B11	XTV3+6GFZ	SCREW	4	
B12	XTV3+8GFZ	SCREW	6	


● CHASSIS PARTS SECTION (1)



Note: 1. *Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
100	YEM0638	S-REEL MOTOR (1) ASS'Y	1	<ND>
101	YEM0638	T-REEL MOTOR (1) ASS'Y	1	<ND>
102	VMS8462	OUTER SHAFT	2	
103	VMS5924	REEL INNER RAIL	2	
104	VXA6005	SLIDE ROD (1) ASS'Y	1	
105	VXA6006	REEL RELEASE ANGLE ASS'Y	1	
106	VXL2589	S BASE DRIVE ARM ASS'Y	1	
107	VXL2590	T BASE DRIVE ARM ASS'Y	1	
B100	VHD0995	SCREW	8	
B101	XQN2+CF3	SCREW	2	
B102	XSB26+4FX	SCREW	3	
W100	VMX1079	CUT WASHER	2	
W101	VMX1394	CUT WASHER	2	

● CHASSIS PARTS SECTION (2)





2. IMPORTANT SAFETY NOTICE

any of these components, use only the same type.

[illegible]

① SUB CHASSIS PARTS SECTION




Note: 1. *Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
300	VMD3010	TRAY STOPPER A	1	
301	VMD2853	MIC STOPPER	1	
302	VML3262	COMMUNICATION ARM	1	
303	VML3263	TRAY CONNECTION ROD	1	
304	VXA5575	S-BRAKE SOLENOID BASE	1	
305	VXA5887	T-BRAKE SOLENOID BASE	1	
306	VSJ0218	BRAKE SOLENOID	2	<M>
307	VXA6012	MIC CONNECTOR (1) ASS'Y	1	
308	VXL2777	MIC DRIVE ARM (1) ASS'Y	1	
309	VXL2780	MIC SUBLINK ARM (1) ASS'Y	1	
310	VEK6235	PHOTO SENSOR HOLDER (1)	2	
311	VXK1352	SUB CHASSIS (2) ASS'Y	1	
312	VXP1842	LOCK GEAR (1) ASS'Y	1	
313	VSC4689	SHIELD CASE B	1	
B300	XQN2+CF3	SCREW	10	
B301	XQN2+A1.5	SCREW	4	
B302	XQN2+CF4	SCREW	1	
B303	XYN26+J5	SCREW	4	


[illegible]

● CASSETTE TRAY PARTS SECTION



Note: 1. *Be sure to make your orders of replacement parts according to this list.


2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.


Ref. No.	Part No.	Part Name & Description	Qty	Remarks
401	VGP4573	TRAY FRONT PANEL	1	
402	VDG1263	SYNCHRO. DRIVE GEAR	1	
403	VMD2845	REAR GUIDE	1	
404	VMD2846	FRONT GUIDE	1	
405	VXA5980	CASSETTE HOLDER ASS'Y	1	
406	VXA5991	S RACK ASS'Y	1	
407	VXA5992	T RACK ASS'Y	1	
408	VDG1260	PINION GEAR	2	
409	VDP1687	ROLLER	4	
410	VMD2847	FRONT PROJECTION	1	
411	VXA6023	SIDE PLATE (S)	1	
412	VXA6024	SIDE PLATE (T)	1	
413	VMA9797	CASSETTE COVER	1	
414	VMD2848	TOP GUIDE	2	
415	VML3288	COVER OPEN LEVER	1	
416	VXA5989	BOOSTER (1) ASS'Y	1	
417	VXA6000	TRAY DRIVE SHAFT ASS'Y	1	
418	VDG1264	WORM GEAR	1	
419	VDG1265	WORM FOIL GEAR	1	
420	VEE08B3	MOTOR WIRE CABLE	1	
421	VEW0644	TRAY MOTOR	1	
422	VMD2850	GEAR BOX	1	
B400	XTB28+SJFZ	SCREW	2	
B401	XSN2+3R	SCREW	4	
B402	XTB2+35FFY	SCREW	2	

[illegible]

6 PACKING PARTS SECTION



2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]

4-2. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. Be sure to make your orders of replacement parts according to this list.
 2. IMPORTANT SAFETY NOTICE: Components identified with the mark Δ have the special characteristics for safety. When replacing any of these components, use only the same type.
 3. Unless otherwise specified, All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICROFARADS (μ F), P=100F.
 4. The P.C. Board units marked with \blacksquare show below the main assembled parts.
 5. The marking (RTL) indicates the retention time is limited for this item.
 After the discontinuation of this assembly in production, it will no longer be available.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
\blacksquare	VEP06C40A	MAIN C. B. A.	1	(RTL) AG-DV2700E
\blacksquare	VEP06C40B	MAIN C. B. A.	1	(RTL) AG-DV2700B
\blacksquare	VEP03E27A	ANALOG C. B. A.	1	(RTL) INCLUDED IN VEP06E40A/B
\blacksquare	VEP03E28A	INPUT/OUTPUT C. B. A.	1	(RTL) INCLUDED IN VEP06E40A/B
\blacksquare	VEP03E28A	REAR JACK C. B. A.	1	(RTL) INCLUDED IN VEP03E28A/B
\blacksquare	VEP07801AR	TV DEMODULATOR PACK C. B. A.	1	(RTL) AG-DV2700E INCLUDED IN VEP06E40A
\blacksquare	VEP07801AQ	TV DEMODULATOR PACK C. B. A.	1	(RTL) AG-DV2700B INCLUDED IN VEP06E40B
\blacksquare	VEP07973B	NICAM DECODER C. B. A.	1	(RTL) AG-DV2700E INCLUDED IN VEP06E40A
\blacksquare	VEP07973A	NICAM DECODER C. B. A.	1	(RTL) AG-DV2700B INCLUDED IN VEP06E40B
\blacksquare	VEP06C89A	MOTOR DRIVE C. B. A.	1	(RTL) INCLUDED IN VEP06E40A/B
\blacksquare	VEP03E55A	DIGITAL C. B. A.	1	(RTL) INCLUDED IN VEP06E40A/B
\blacksquare	VEP04869B	AUDIO C. B. A.	1	(RTL) INCLUDED IN VEP06E40A/B
\blacksquare	VEP05351A	HEAD AMP C. B. A.	1	(RTL)
\blacksquare	VEP02557B	MECHANISM DRIVE C. B. A.	1	(RTL)
\blacksquare	VEP07877A	TIMER C. B. A.	1	(RTL)
\blacksquare	VEP04895A	FRONT (L) C. B. A.	1	(RTL)
\blacksquare	VEP04898D	FRONT (R) C. B. A.	1	(RTL)
\blacksquare	VEP07966A	MODULAR C. B. A.	1	(RTL)
\blacksquare	VEP07965A	FRONT LED C. B. A.	1	(RTL)
\blacksquare	VEP07968B	IR C. B. A.	1	(RTL)
\blacksquare	VEP03E18A	SP JACK C. B. A.	1	(RTL)
\blacksquare	VEP07967A	DV JACK C. B. A.	1	(RTL)
\blacksquare	VEP01B14A	POWER SUPPLY C. B. A.	1	(RTL)
	ENG4728961	TUNER	1	AG-DV2700E
	ENG4728961	TUNER	1	AG-DV2700B
F1101	XBA2C18TH15	FUSE	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
\blacksquare	VEP06C40A	MAIN C. B. A.	1	(RTL) AG-DV2700E
\blacksquare	VEP06C40B	MAIN C. B. A.	1	(RTL) AG-DV2700B
\blacksquare	VEP03E27A	ANALOG C. B. A.	1	(RTL) INCLUDED IN VEP06C40A/B
\blacksquare	VEP03E28A	INPUT/OUTPUT C. B. A.	1	(RTL) INCLUDED IN VEP06C40A/B
\blacksquare	VEP03E28A	REAR JACK C. B. A.	1	(RTL) INCLUDED IN VEP03E28A
\blacksquare	VEP07801AR	TV MODULATOR PACK C. B. A.	1	(RTL) INCLUDED IN VEP06C40A
\blacksquare	VEP07801AQ	TV MODULATOR PACK C. B. A.	1	(RTL) INCLUDED IN VEP06C40B
\blacksquare	VEP07973B	NICAM DECODER C. B. A.	1	(RTL) INCLUDED IN VEP06C40A
\blacksquare	VEP07973A	NICAM DECODER C. B. A.	1	(RTL) INCLUDED IN VEP06C40B
\blacksquare	VEP06C89A	MOTOR DRIVE C. B. A.	1	(RTL) INCLUDED IN VEP06C40A/B
\blacksquare	VEP03E55A	DIGITAL C. B. A.	1	(RTL) INCLUDED IN VEP06C40A/B
\blacksquare	VEP04869B	AUDIO C. B. A.	1	(RTL) INCLUDED IN VEP06C40A/B
C0701-03	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	3	
C0704	ECUX1H331JCV	C. CAPACITOR CH 50V 330P	1	
C0705	ECUX1H181JCV	C. CAPACITOR CH 50V 180P	1	
C0706	ECEA1HKA0R1	E. CAPACITOR 50V 0.1U	1	
C0707, 08	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	2	
C0709	ECUX1H120JCV	C. CAPACITOR CH 50V 12P	1	
C0710	ECUX1H470JCV	C. CAPACITOR CH 50V 47P	1	
C0711	ECEA1CKA220	E. CAPACITOR 16V 22U	1	
C0712	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C0714	EC081H473JF	P. CAPACITOR 50V 0.047U	1	
C0715	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C0716	ECEA1CKA470	E. CAPACITOR 16V 47U	1	
C0717	ECUX1H270JCV	C. CAPACITOR CH 50V 27P	1	
C0718	ECEA1HKS47	E. CAPACITOR 50V 0.47U	1	
C0719	ECUX1H180JCV	C. CAPACITOR CH 50V 18P	1	
C0720	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C0722	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C0723	ECEA1HKA0R1	E. CAPACITOR 50V 0.1U	1	
C0724	EC081H473JF	P. CAPACITOR 50V 0.047U	1	
C0726	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C0729	ECEA1CKA100	E. CAPACITOR 16V 10U	1	
C0730	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C0732	ECUX1H103ZFV	C. CAPACITOR CH 50V 0.01U	1	
C1001	ECEA0JKS101	E. CAPACITOR 8.3V 100U	1	
C1002	ECEA1AKS470	E. CAPACITOR 10V 47U	1	
C1003	ECEA0JKS101	E. CAPACITOR 8.3V 100U	1	
C1004	ECEA1AKS470	E. CAPACITOR 10V 47U	1	
C1006	ECEA1AKS221	E. CAPACITOR 10V 220U	1	
C1010	ECEA1HKA010	E. CAPACITOR 50V 1U	1	
C1011, 12	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	2	
C1013	ECUX1H473KBN	C. CAPACITOR CH 50V 0.047U	1	
C1014	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C1018	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C1019	ECEA1HKS010	E. CAPACITOR 50V 0.1U	1	
C1019	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C1022	ECEA1HKS010	E. CAPACITOR 50V 1U	1	
C1023	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C1024	ECEA1CKS470	E. CAPACITOR 16V 47U	1	
C1025	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C1026	ECUX1H682KBN	C. CAPACITOR CH 50V 6800P	1	
C1027	ECEA1CKS100	E. CAPACITOR 16V 10U	1	
C1028	ECA1CM332	E. CAPACITOR 16V 3300U	1	
C1029	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C1030	ECA1CM332	E. CAPACITOR 16V 3300U	1	
C1031	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C1032	ECA1CM332	E. CAPACITOR 16V 3300U	1	
C1033, 34	ECEA1HKS010	E. CAPACITOR 50V 1U	2	
C1035-40	ECEA0JKS101	E. CAPACITOR 8.3V 100U	6	
C1041	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C1042	ECEA1HKS010	E. CAPACITOR 50V 1U	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C1043	ECEA0JKS101	E. CAPACITOR 6.3V 100U	1		C2528, 29	ECUX1H682KBN	C. CAPACITOR CH 50V 8800P	2	
C1045	ECEA0JKS101	E. CAPACITOR 6.3V 100U	1		C2530, 31	ECEA1CKA101	E. CAPACITOR 16V 100U	2	
C1047, 48	ECEA0JKS101	E. CAPACITOR 6.3V 100U	2		C3001	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1049	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C3002	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C1050, 51	ECEA1CKS101	E. CAPACITOR 16V 100U	2		C3003	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C1054, 55	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	2		C3004, 05	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	2	
C1056	ECEA1CKS470	E. CAPACITOR 16V 47U	1		C3006	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C1057	ECUM1H103KBN	C. CAPACITOR 50V 0.01U	1		C3007, 08	ECUX1C105ZFN	C. CAPACITOR 16V 1U	2	
C1058	ECEA1EKS330	E. CAPACITOR 25V 33U	1		C3010-12	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	3	
C1059	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1		C3013	ECUX1H103ZFN	C. CAPACITOR 50V 0.01U	1	
C1060	ECEA0JKS470	E. CAPACITOR 6.3V 47U	1		C3014	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C1061	ECEA1CKS101	E. CAPACITOR 16V 100U	1		C3015	ECST1CY335Z	T. CAPACITOR CH 16V 3.3U	1	
C1062	ECEA1EKS330	E. CAPACITOR 25V 33U	1		C3016	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C1063	ECEA0JKS101	E. CAPACITOR 6.3V 100U	1		C3017	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C1064	ECUM1H104ZFN	C. CAPACITOR 50V 0.1U	1		C3018	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2002-04	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	3		C3019	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C2005, 06	ECUX1H120JCV	C. CAPACITOR CH 50V 12P	2		C3020	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C2007-09	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	3		C3021	ECST1CY335Z	T. CAPACITOR CH 16V 3.3U	1	
C2010	ECST0JD107Z	T. CAPACITOR CH6.3V 10U	1		C3023	ECUX1H681JCV	C. CAPACITOR 50V 880P	1	
C2011-13	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	3		C3024	ECUX1H152KBN	C. CAPACITOR CH 50V 1500P	1	
C2014, 15	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2		C3025	ECUX1H270JCV	C. CAPACITOR CH 50V 27P	1	
C2016, 17	ECST1VX335Z	T. CAPACITOR CH 35V 3.3U	2		C3026	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1	
C2018	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1		C3027	ECUX1H150JCV	C. CAPACITOR 50V 15P	1	
C2019	ECUX1H102KBN	C. CAPACITOR CH 50V 1000P	1		C3028-30	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	3	
C2020	ECST0JY106Z	T. CAPACITOR CH6.3V 22U	1		C3031	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C2021	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3032	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C2022	ECUX1H102KBN	C. CAPACITOR CH 50V 1000P	1		C3033	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2023	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3034	ECUX1E27KBN	C. CAPACITOR 25V 0.027U	1	
C2024	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3035	ECUX1H103ZFN	C. CAPACITOR 50V 0.01U	1	
C2025	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C3036	ECUX1H1000CV	C. CAPACITOR CH 50V 10P	1	
C2026	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3037	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C2027-30	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4		C3038, 39	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	2	
C2031-33	ECST1VX335Z	T. CAPACITOR CH 35V 3.3U	3		C3040, 41	ECUX1C105ZFN	C. CAPACITOR 16V 1U	2	
C2201, 02	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C3042	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2203	ECEA0JKS330	E. CAPACITOR 6.3V 33U	1		C3043, 44	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C2204	ECEA0JKS470	E. CAPACITOR 6.3V 47U	1		C3045-48	ECUX1C104KBN	C. CAPACITOR CH 16V 0.1U	4	
C2205	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3049-54	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	6	
C2207, 08	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C3056	ECUX1C104KBN	C. CAPACITOR CH 16V 0.1U	1	
C2209	ECUM1H120JCV	C. CAPACITOR CH 50V 12P	1		C3057	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2210	ECUX1H200JCV	C. CAPACITOR CH 50V 20P	1		C3058	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2211, 12	ECUM1H080CGN	C. CAPACITOR CH 50V 8P	2		C3060	ECUX1H270JCV	C. CAPACITOR CH 50V 27P	1	
C2213	ECUM1H151JCV	C. CAPACITOR CH 50V 150P	1		C3061	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1	
C2214	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3062-65	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4	
C2215	ECUM1H102KBN	C. CAPACITOR 50V 1000P	1		C3067	ECST0JY226Z	T. CAPACITOR CH6.3V 22U	1	
C2216	ECUM1H222KBN	C. CAPACITOR 50V 2200P	1		C3068-72	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	5	
C2217	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3073-77	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	5	
C2218	ECEA0JKS101	E. CAPACITOR 6.3V 100U	1		C3078, 79	ECUX1H0700CV	C. CAPACITOR CH 50V 7P	2	
C2222	ECEA0JKS470	E. CAPACITOR 6.3V 47U	1		C3080	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2223	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C3081	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C2225, 26	ECUM1H104ZFN	C. CAPACITOR 50V 0.1U	2		C3082	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	1	
C2227	VCE0073	CAPACITOR (N) UNIT	1		C3083	ECUX1C474KBN	C. CAPACITOR CH 18V 0.47U	1	
C2228	ECEA1AKS221	E. CAPACITOR 10V 220U	1		C3084	ECUX1C224ZFN	C. CAPACITOR CH 16V 0.22U	1	
C2229	ECUM1H104ZFN	C. CAPACITOR 50V 0.1U	1		C3085	ECUX1H473ZFN	C. CAPACITOR CH 50V 0.47U	1	
C2231	ECUM1H103ZFN	C. CAPACITOR 50V 0.01U	1		C3086, 87	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C2233	ECUM1H103ZFN	C. CAPACITOR 50V 0.01U	1		C3090, 91	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C2234	ECUM1H560JCV	C. CAPACITOR CH 50V 56P	1		C3092	ECUX1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C2235	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1		C3093-96	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	4	
C2236-41	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	6		C3097, 98	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C2501	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C3099-02	ECUX1C104KBN	C. CAPACITOR 16V 0.1U	4	
C2502, 03	ECEA1CKA101	E. CAPACITOR 16V 100U	2		C3103	ECUX1H103ZFN	C. CAPACITOR 50V 0.01U	1	
C2505, 06	ECEA1CKA101	E. CAPACITOR 16V 100U	2		C3104-07	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	4	
C2507, 08	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C3108	ECUX1C224ZFN	C. CAPACITOR CH 16V 0.22U	1	
C2509	ECEA1CKA101	E. CAPACITOR 16V 100U	1		C3109, 10	ECUX1H150JCV	C. CAPACITOR CH 50V 15P	2	
C2510	ECUX1H682KBN	C. CAPACITOR CH 50V 8800P	1		C3111, 12	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C2511	ECEA1CKA101	E. CAPACITOR 16V 100U	1		C3113-15	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	3	
C2512, 13	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C3116, 17	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	2	
C2514	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3201, 02	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C2515	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1		C3203, 04	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C2519, 20	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C3205	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C2521	ECEA1CKA101	E. CAPACITOR 16V 100U	1		C3206	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C2522	ECUM1H104ZFN	C. CAPACITOR 50V 0.1U	1		C3207	ECUX1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C2523, 24	ECUM1H103ZFN	C. CAPACITOR 50V 0.01U	2		C3208	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C2525	ECUX1H682KBN	C. CAPACITOR CH 50V 8800P	1		C3209, 10	ECUX1H103KBN	C. CAPACITOR CH 50V 0.01U	2	
C2526	ECEA1CKA101	E. CAPACITOR 16V 100U	1		C3211-13	ECUX1C104KBN	C. CAPACITOR CH 16V 0.1U	3	
C2527	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C3214	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C3215	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3382	ECUX1E102KBQ	C. CAPACITOR ■ 25V 1000P	1	
C3216-18	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	3		C3383-85	ECUX1H101JQJ	C. CAPACITOR ■ 50V 100P	3	
C3219	ECUX1E273KBV	C. CAPACITOR CH 25V 0.027U	1		C3387-70	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	4	
C3220	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3371, 72	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	2	
C3221	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1		C3374-78	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	5	
C3222	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3379	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1	
C3223	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1		C3380	ECST0JX476Z	T. CAPACITOR CH6.3V 47U	1	
C3224	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3601	ECUM1H104ZFN	C. CAPACITOR ■ 50V 0.1U	1	
C3225, 26	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	2		C3602	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C3227	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3603	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C3228	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1		C3604	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C3229	ECUX1H331JCV	C. CAPACITOR CH 50V 330P	1		C3605	ECA0JW221	E. CAPACITOR 6.3V 220U	1	
C3230	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3606	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C3231	ECUX1H152KBV	C. CAPACITOR CH 50V 1500P	1		C3607	ECEA10KS100	E. CAPACITOR 16V 10U	1	
C3232	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3608	ECA0JW331	E. CAPACITOR 6.3V 330U	1	
C3233	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1		C3609	ECEA10KS100	E. CAPACITOR 16V 10U	1	
C3234, 35	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	2		C3610	ECA0JW331	E. CAPACITOR 6.3V 330U	1	
C3236	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1		C3611	ECEA1HKS010	E. CAPACITOR 50V 1U	1	
C3237, 38	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	2		C3614, 15	ECEA1HKS010	E. CAPACITOR 50V 1U	2	
C3239	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3616	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C3240	ECUX1H103ZFN	C. CAPACITOR ■ 50V 0.01U	1		C3617	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C3241, 42	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	2		C3618, 19	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C3243	ECUX1H103ZFN	C. CAPACITOR ■ 50V ■ 0.01U	1		C3620	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	1	
C3244	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3621	ECOP1392JZ	CAPACITOR (O) UNIT	1	
C3245	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3622	ECUM1H152KBN	C. CAPACITOR CH 50V 1500P	1	
C3246	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	1		C3623	ECEA0JKA330	■ CAPACITOR 6.3V 33U	1	
C3247	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3624	ECEA10KA100	E. CAPACITOR 16V 10U	1	
C3248, 49	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	2		C3625	ECEA1HKG68	E. CAPACITOR 50V 0.08U	1	
C3250	ECUX0J225KBN	C. CAPACITOR CH6.3V 2.2U	1		C3626	ECUX1H561JCN	C. CAPACITOR CH 50V 560P	1	
C3251-53	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	3		C3627	ECEA1AKS221	■ CAPACITOR 10V 220U	1	
C3254	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C3628	ECEA1EKS4R7	■ CAPACITOR 25V 4.7U	1	
C3255, 56	ECUX1H103KBV	C. CAPACITOR ■ 50V ■ 0.01U	2		C3629	ECUM1H471JCN	C. CAPACITOR CH 50V 470P	1	
C3257	ECST0JX476Z	T. CAPACITOR CH6.3V 47U	1		C3630	ECUM1C334KBW	C. CAPACITOR CH 16V 0.33U	1	
C3258	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C3631	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C3259	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3632	ECOP1H683JL	P. CAPACITOR 50V 0.068U	1	
C3260	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C3633	ECUM1H152KBN	C. CAPACITOR CH 50V 1500P	1	
C3261	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3634	ECEA1HKS010	E. CAPACITOR 50V 1U	1	
C3262	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3701, 02	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C3263	ECUX1H270JCV	C. CAPACITOR CH 50V 27P	1		C3703	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1	
C3267	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C3704-06	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	3	
C3280	ECST0J0107Z	T. CAPACITOR CH6.3V 100U	1		C3707	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1	
C3281	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1		C3710-12	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	3	
C3282	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C3713	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C3283	ECST0JX476Z	T. CAPACITOR CH6.3V 47U	1		C3714	ECUX1H271JCV	C. CAPACITOR CH 50V 270P	1	
C3284	ECUX1H100CV	C. CAPACITOR ■ 50V 10P	1		C3715-18	ECUM1C104ZFN	C. CAPACITOR CH 50V 0.1U	4	
C3301	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	1		C3719-21	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	3	
C3302	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C3722-25	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4	
C3303, 04	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	2		C3726	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C3305	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C3901	ECEA10KA100	E. CAPACITOR 16V 10U	1	
C3306-10	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	5		C3902	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C3311	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C3903	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C3312	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	1		C3904	ECUX1C105ZFN	C. CAPACITOR ■ 16V 1U	1	
C3313-16	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	4		C3905	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C3317	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	1		C3908	ECEA10KA100	E. CAPACITOR 16V 10U	1	
C3318	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C3907	ECEA0JKA470	■ CAPACITOR 6.3V 47U	1	
C3319	ECUX1H470JQJ	C. CAPACITOR CH 50V 47P	1		C3908	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C3320	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	1		C3909	ECEA10KA470	■ CAPACITOR 16V 47U	1	
C3321	ECUX1H470JQJ	C. CAPACITOR CH 50V 47P	1		C4001	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C3322-27	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	6		C4002	ECEA1EKS4R7	E. CAPACITOR 25V 4.7U	1	
C3328	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	1		C4003	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	1	
C3329, 30	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	2		C4004	ECEA10KS101	E. CAPACITOR 16V 100U	1	
C3331	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C4005	VCEA1CAW220	E. CAPACITOR 16V 22U	1	
C3332, 33	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	■		C4006	ECUX1H223KBN	C. CAPACITOR ■ 50V 0.22U	1	
C3335	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	1		C4007	VCEA1CAW220	E. CAPACITOR 16V 22U	1	
C3337	ECUX1H101JQJ	C. CAPACITOR ■ 50V 100P	1		C4008	ECNRH223JZ	CAPACITOR (P) UNIT	1	
C3338	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C4009, 10	VCEA1CAS102	E. CAPACITOR 18V 1000U	2	
C3339	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	1		C4011	ECNRH223JZ	CAPACITOR (P) UNIT	1	
C3340	ECUX1E102KBQ	C. CAPACITOR ■ 25V 1000P	1		C4012	VCEA1CAW220	E. CAPACITOR 18V 22U	1	
C3341, 42	ECUX0J104KBQ	C. CAPACITOR CH6.3V 0.1U	2		C4203	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1	
C3343-50	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	8		C4206	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1	
C3351	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	1		C4207	ECUX1H152KBV	C. CAPACITOR CH 50V 1500P	1	
C3352, 53	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	2		C4211	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1	
C3354-56	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	3		C4212	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C3357	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1		C4213	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C3380, 81	ECUX1H101JQJ	C. CAPACITOR CH 50V 100P	2		C4214	ECUX1H330JCV	C. CAPACITOR ■ 50V 33P	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C4215	ECUX1H152KBY	C. CAPACITOR CH 50V 1500P	1		C4701	ECEA1CKS100	E. CAPACITOR 16V 100U	1	
C4217	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C4702, 03	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C4218	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C4704, ■	ECEA1CKS100	E. CAPACITOR 16V 100U	2	
C4219	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C4706	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C4220, 21	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	2		C4707	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4222, ■	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	2		C4708-11	VCEA1CAW100	E. CAPACITOR 18V 100U	4	
C4224, 25	ECUX1H152KBY	C. CAPACITOR CH 50V 1500P	2		C4801-04	ECUM1H471JCN	C. CAPACITOR CH 50V 470P	4	
C4302	VCEA1AAE101	E. CAPACITOR 10V 100U	1		C4805	ECEA1AKA470	E. CAPACITOR 10V 47U	1	
C4303	ECHR1H103JZ	P. CAPACITOR 50V 0.01U	1		C4806	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4304	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C4807-14	ECUM1H471JCN	C. CAPACITOR ■ 50V 470P	8	
C4305	VCEA0JAE221	E. CAPACITOR 6.3V 220U	1		C8001	ECUX1C274KBN	C. CAPACITOR ■ 16V 0.27U	1	
C4306	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C8002	ECST0JD107Z	T. CAPACITOR CH6.3V 100U	1	
C4307	VCEA0JAE221	E. CAPACITOR 6.3V 220U	1		C8003	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C4308	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C8004	ECUX1H120JCV	C. CAPACITOR ■ 50V 12P	1	
C4309	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	1		C8005	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C4310	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C8006, 07	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	2	
C4311	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C8008	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C4312	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	1		C8009, 10	ECUX1H103KBY	C. CAPACITOR CH 50V 0.01U	2	
C4313	ECEA1CKA100	E. CAPACITOR 16V 100U	1		C8011, 12	ECUX1E223KBY	C. CAPACITOR CH 25V 0.023U	■	
C4314	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	1		C8015	ECUX1H103ZFY	C. CAPACITOR ■ 50V 0.01U	1	
C4315	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C8017, 18	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C4316	VCEA1CAE100	E. CAPACITOR 16V 100U	1		C8018	ECST0JD107Z	T. CAPACITOR CH6.3V 100U	1	
C4317	ECEA1CKA100	E. CAPACITOR 16V 100U	1		C8020	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C4318	ECUM1E683KBN	C. CAPACITOR CH 25V ■ 063U	1		C8021	ECUX1H120JCV	C. CAPACITOR CH 50V 12P	1	
C4319	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C8022-25	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	4	
C4320	VCEA0JAE470	E. CAPACITOR 6.3V 47U	1		C8026	ECST0JD107Z	T. CAPACITOR CH6.3V 100U	1	
C4321	ECHR1H103JZ	P. CAPACITOR 50V 0.01U	1		C8027	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C4322	ECUM1E683KBN	C. CAPACITOR CH 25V 0.083U	1		C8028-30	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	3	
C4323	VCEA1CAE100	E. CAPACITOR 16V 100U	1		C8033, 34	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	2	
C4324	ECUM1E683KBN	C. CAPACITOR CH 25V 0.083U	1		C8035	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C4325, 26	VCEA1HAE2R2	E. CAPACITOR 50V 2.2U	2		C8036	ECUX1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C4327	VCEA0JAE470	E. CAPACITOR 6.3V 47U	1		C8041	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	1	
C4328	ECHR1H103JZ	P. CAPACITOR 50V 0.01U	1		C8043	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	1	
C4329, 30	VCEA1HAE2R2	E. CAPACITOR 50V 2.2U	2		C8044	ECST0JX228Z	T. CAPACITOR CH6.3V 22U	1	
C4331	ECUM1E683KBN	C. CAPACITOR CH 25V 0.083U	1		C8045, 48	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	2	
C4332, 33	VCEA1CAE100	E. CAPACITOR 16V 100U	2		C7301	ECUX1H103ZFY	C. CAPACITOR CH 50V 0.01U	1	
C4334	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7302	VCEA0JAW101	E. CAPACITOR 6.3V 100U	1	
C4335, 36	VCEA1HAE2R2	E. CAPACITOR 50V 2.2U	2		C7303	ECUX1H103ZFY	C. CAPACITOR CH 50V 0.01U	1	
C4337	ECEA1CKA100	E. CAPACITOR 16V 100U	1		C7304	VCEA0JAW101	E. CAPACITOR 6.3V 100U	1	
C4338	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1		C7307	ECUX1H470JCV	C. CAPACITOR CH 50V 47P	1	
C4339	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7308	ECEA1HKA2R2	E. CAPACITOR 50V 2.2U	1	
C4340, 41	VCEA1HAE2R2	E. CAPACITOR 50V 2.2U	2		C7311	ERJ3GEYOR00	■ RESISTOR ■ 1/16W	0	1
C4342-44	VCEA1CAE100	■ CAPACITOR 16V 100U	3		C7312, 13	ECUM1C104ZFN	C. CAPACITOR ■ 18V 0.1U	2	
C4345, 46	ECUM1H104ZFN	C. CAPACITOR ■ 50V 0.1U	2		C7315	ECUX1E104KBN	C. CAPACITOR CH 25V 0.1U	1	
C4347, 48	ECEA1CKA100	E. CAPACITOR 16V 100U	2		C7316	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C4349	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7317	VCEA1CAW100	E. CAPACITOR 18V 100U	1	
C4350	VCEA1CAE100	E. CAPACITOR 16V 100U	1		C7318	VCEA0JAW470	E. CAPACITOR 6.3V 47U	1	
C4351	ECUM1H104ZFN	C. CAPACITOR ■ 50V 0.1U	1		C7319, ■	VCEA1CAW100	E. CAPACITOR 18V 100U	2	
C4352	ECEA1CKA101	E. CAPACITOR 16V 100U	1		C7321	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C4353	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7322, 23	ECUX1H103KBY	C. CAPACITOR CH 50V 0.01U	2	
C4354	ECEA1HKA010	E. CAPACITOR 50V 1U	1		C7324-26	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	3	
C4355	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7327	ECUM1C334KBN	C. CAPACITOR CH 16V 0.33U	1	
C4356	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7328	ECUX1E333KBN	C. CAPACITOR ■ 16V 0.033U	1	
C4357	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7329	ECUX1H120JCV	C. CAPACITOR ■ 50V 12P	1	
C4358	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7330	ECUX1H380JCV	C. CAPACITOR CH 50V 38P	1	
C4359	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7801	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C4360	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7802	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4361, 62	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2		C7804	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4363	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7807	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4364	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7808	ECEA1HKA100	■ CAPACITOR 50V 100U	1	
C4365, 66	ECEA1CKA100	E. CAPACITOR 16V 100U	2		C7810	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4367	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C7811	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	1	
C4368	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7814	ECEA1HKA010	E. CAPACITOR 50V 1U	1	
C4371	ECUM1H330JCN	C. CAPACITOR ■ 50V 33P	1		C7815, 16	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	2	
C4372	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C7851	ECEA1CKA100	E. CAPACITOR 16V 100U	1	
C4373, 74	ECUX1H330JCV	C. CAPACITOR ■ 50V 33P	2		C7852, 53	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2	
C4377	ECEA1CKA100	E. CAPACITOR 16V 100U	1		C7854	ECEA1CKS100	E. CAPACITOR 16V 100U	1	
C4378	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1		C7909	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4379-81	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	3		C7910	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C4382	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1		C7911	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4384, ■	ECUX1C383KBY	C. CAPACITOR CH 16V 0.038U	2		C30001, 02	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	2	
C4501, ■	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	2		C30003	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C4503-05	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	3		C30004, 05	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	2	
C4506	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C30006	ECQB1H153JF	P. CAPACITOR 50V 0.015U	1	
C4515	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1		C30007	ECUM1H471JCN	C. CAPACITOR CH 50V 470P	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C30008	ECUM1H332KBN	C. CAPACITOR CH 50V 330P	1		C30100	EEVH0J101	E. CAPACITOR 6.3V 100U	1	
C30009	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C30101	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C30010	EEVH0J101	E. CAPACITOR 6.3V 100U	1		C30102	ECUM1H101JCN	C. CAPACITOR ■ 50V 100P	1	
C30011	EEVH1H3R3	E. CAPACITOR 50V 3.3U	1		C30103	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C30012, 13	EEVH1C100	E. CAPACITOR 16V 10U	2		C30104	ECUM1H270JCN	C. CAPACITOR CH 50V 27P	1	
C30014	EEVH1H4R7	E. CAPACITOR 50V 4.7U	1		C30105	ECUX1H200JCN	C. CAPACITOR CH 50V 20P	1	
C30015	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C30106	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C30016	ECUM1H471JCN	C. CAPACITOR CH 50V 470P	1		C30107	EEVH0J101	E. CAPACITOR 6.3V 100U	1	
C30018	EEVH1C100	■ CAPACITOR 16V 10U	1		C30108	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C30019	ECUM1H104ZFN	C. CAPACITOR ■ 50V 0.1U	1		C30109	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C30020	EEVH0J101	E. CAPACITOR 6.3V 100U	1		C30110	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C30021	EEVH0J470	E. CAPACITOR 6.3V 47U	1		C30111	EEVH0J470	E. CAPACITOR 6.3V 47U	1	
C30022	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C30113	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	1	
C30023	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C30114	EEVHP1H1R0	E. CAPACITOR 50V 1U	1	
C30024	EEVH0J470	E. CAPACITOR 6.3V 47U	1		C30116	ECUX1H103ZFN	C. CAPACITOR ■ 50V 0.01U	1	
C30025	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C30117-19	EEVH1E4R7	E. CAPACITOR 25V 4.7U	3	
C30026	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1		C30120	ECUM1H121JCN	C. CAPACITOR CH 50V 120P	1	
C30027	ECUX1H560JCV	C. CAPACITOR ■ 50V 56P	1		C30122	EEVH0J470	E. CAPACITOR 6.3V 47U	1	
C30028	EEVH0J220	E. CAPACITOR 6.3V 22U	1		C30123	EEVH0J220	E. CAPACITOR 6.3V 22U	1	
C30029, 30	ECUX1H560JCV	C. CAPACITOR CH 50V 56P	2		C30124	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C30031, 32	ECUX1H220JCV	C. CAPACITOR ■ 50V 22P	2		C30125	ECUM1H271JCN	C. CAPACITOR CH 50V 270P	1	
C30033	ECUX1H560JCV	C. CAPACITOR CH 50V 56P	1		C30126	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	1	
C30034	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1		C30127	ECUX1H120JCV	C. CAPACITOR CH 50V 12P	1	
C30035	EEVH0J220	E. CAPACITOR 6.3V 22U	1		C30128	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C30036	EEVH0J101	E. CAPACITOR 6.3V 100U	1		C30130	EEVH1H1R0	E. CAPACITOR 50V 1U	1	
C30037	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		C30131	ECUM1H103KBN	C. CAPACITOR CH 50V ■ 0.1U	1	
C30038-40	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	3		C30132	EEVH0J470	E. CAPACITOR 6.3V 47U	1	
C30041	ECUX1H103ZFN	C. CAPACITOR ■ 50V ■ 0.1U	1		C30133	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C30042	ECUX1H181JCV	C. CAPACITOR CH 50V 180P	1		C30134	EEVH0J220	E. CAPACITOR 6.3V 22U	1	
C30043	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C30135	ECUM1H331JCN	C. CAPACITOR CH 50V 330P	1	
C30044	ECUM1H121JCN	C. CAPACITOR CH 50V 120P	1		C30138	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C30045, 46	EEVH1C100	E. CAPACITOR 16V 10U	2		C30137	EEVH1H1R0	■ CAPACITOR 50V 1U	1	
C30047, 48	ECUM1C104ZFN	C. CAPACITOR CH 16V ■ 1U	2		C30138	EEVHP1H1R0	E. CAPACITOR 50V 1U	1	
C30049	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C30138-41	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	3	
C30050	EEVHP1HR47	E. CAPACITOR 50V 47U	1		C30142	ECUX1H390JCV	C. CAPACITOR CH 50V 39P	1	
C30051	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1		C30143	ECUM1H390JCN	C. CAPACITOR CH 50V 39P	1	
C30052	EEVH1C100	E. CAPACITOR 16V 10U	1		C30145	EEVH0J101	E. CAPACITOR 6.3V 100U	1	
C30053, 54	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	2		C30146	EEVH0J470	E. CAPACITOR 6.3V 47U	1	
C30055	EEVH0J220	E. CAPACITOR 6.3V 22U	1		C30147, 48	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	2	
C30056	EEVH1C100	E. CAPACITOR 16V 10U	1		C30149	EEVHP1A100	E. CAPACITOR 10V 10U	1	
C30057	ECUX1H561JCV	C. CAPACITOR CH 50V 560P	1		C30150	ECUM1C104ZFN	C. CAPACITOR CH 16V ■ 1U	1	
C30058	ECUX1H361JCV	C. CAPACITOR CH 50V 360P	1		C30151	EEVHP1A100	E. CAPACITOR 10V 10U	1	
C30059	EEVH0J470	E. CAPACITOR 6.3V 47U	1		C30152	ECUM1C104ZFN	C. CAPACITOR ■ 16V 0.1U	1	
C30060	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		C30155	ECUM1H820JCN	C. CAPACITOR CH 50V 82P	1	
C30061	ECUX1H560JCV	C. CAPACITOR CH 50V 56P	1		C30156	ECUX1H101JCV	C. CAPACITOR CH 50V 100P	1	
C30063	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		C30157	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C30064	EEVH1H4R7	E. CAPACITOR 50V 4.7U	1		C30158	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1	
C30065	EEVH1H2R2	E. CAPACITOR 50V 2.2U	1		C30160	ECUX1H390JCV	C. CAPACITOR CH 50V 39P	1	
C30066	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1		C30161, 62	ECUM1H103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C30067	ECUM1H101JCN	C. CAPACITOR CH 50V 100P	1		C30165	EEVH0J470	E. CAPACITOR 6.3V 47U	1	
C30068	EEVH0J101	E. CAPACITOR 6.3V 100U	1		C30168	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C30069	ECUX1A105ZFN	C. CAPACITOR CH 10V 1U	1		C30167	ECUM1H221JCN	C. CAPACITOR CH 50V 220P	1	
C30070	ECUM1H270JCN	C. CAPACITOR ■ 50V 27P	1		C30168	ECUM1H820JCN	C. CAPACITOR CH 50V 82P	1	
C30071	ECUM1H220JCN	C. CAPACITOR CH 50V 22P	1		C30168	ECUM1H181JCN	C. CAPACITOR CH 50V 180P	1	
C30072	EEVH0J470	E. CAPACITOR 6.3V 47U	1		C30190	ECUM1H120JCN	C. CAPACITOR CH 50V 12P	1	
C30073	ECUX1H103ZFN	C. CAPACITOR ■ 50V 0.01U	1						
C30075	ECUM1H120JCN	C. CAPACITOR CH 50V 12P	1		D1001	MA185	DIODE	1	
C30076	EEVH1H1R0	E. CAPACITOR 50V 1U	1		D1002	MA4051-L	DIODE	1	
C30077	ECUX1H561JCV	C. CAPACITOR CH 50V 560P	1		D1003	MA165	DIODE	1	
C30078	ECUX1H561JCN	C. CAPACITOR CH 50V 560P	1		D1004	MA4051-L	DIODE	1	
C30079	EEVH1H3R3	E. CAPACITOR 50V 3.3U	1		D1005	MA165	DIODE	1	
C30080	ECUX1H392KBN	C. CAPACITOR CH 50V 3900P	1		D1006, 09	MA165	DIODE	2	
C30081	EEVH0J101	E. CAPACITOR 6.3V 100U	1		D1010	11E81	DIODE	1	
C30083	EEVH1C100	■ CAPACITOR 16V 10U	1		D1011	21D004	DIODE	1	
C30084	EEVH0J101	E. CAPACITOR 6.3V 100U	1		D1013	MA4120-M	DIODE	1	
C30085	ECUM1H103ZFN	C. CAPACITOR ■ 50V 0.01U	1		D1014	MA165	DIODE	1	
C30086	ECUX1H103ZFN	C. CAPACITOR CH 50V 0.01U	1		D1017	MA4062L	DIODE	1	
C30087	ECUX1H221JCV	C. CAPACITOR CH 50V 220P	1		D1020	MA4082-L	DIODE	1	
C30088	ECUM1H221JCN	C. CAPACITOR CH 50V 220P	1		D1021	MA4200M	DIODE	1	
C30089, 90	ECUM1H104ZFN	C. CAPACITOR CH 50V ■ 1U	2		D1022	MA4051-M	DIODE	1	
C30091	EEVH1H2R2	E. CAPACITOR 50V 2.2U	1		D1023, 24	MA165	DIODE	2	
C30092	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		D1025	MA723	DIODE	1	
C30093, 94	ECUM1H080CCN	C. CAPACITOR CH 50V 8P	2		D1026	MA165	DIODE	1	
C30095-98	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4		D1027, 28	MA4024-L	DIODE	■	
C30099	ECUM1H104ZFN	C. CAPACITOR CH 50V 0.1U	1		D2001	MA728	DIODE	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
D2003-05	1SS355	DIODE	3		IC2210	PST7028-T	IC	1	
D2008-14	MA728	DIODE	9		IC2211-13	TC7W74F	IC	3	
D2201-02	MA165	DIODE	2		IC2214	TC7W08F	IC	1	
D2203-05	MA723	DIODE	3		IC2215	TC7SH32F	IC	1	
D2206	MA720	DIODE	1		IC2216	TC7S08F	IC	1	
D2207	MA723	DIODE	1		IC2502	TL1453CHS	IC	1	
D2208	MA165	DIODE	1		IC3001	T9P90EF	IC	1	
D2209	MA720	DIODE	1		IC3002	MN47V07AF	IC	1	
D2210	MA165	DIODE	1		IC3003	MN67373	IC	1	
D2211	MA720	DIODE	1		IC3004	M52387FP	IC	1	
D2501	AK04	DIODE	1		IC3005	8H708KV	IC	1	
D2503	AK04	DIODE	1		IC3006	M52884AFP	IC	1	
D2505	AK04	DIODE	1		IC3007	TC7SH00FU	IC	1	
D2507	AK04	DIODE	1		IC3008	T200852F0001	IC	1	
D3002	MA728	DIODE	1		IC3009	TC7SH08FU	IC	1	
D3003	MA151K	DIODE	1		IC3010	RN5RZ308A	IC	1	
D3201	MA142WA	DIODE	1		IC3201	M65500FP	IC	1	
D3601	MA721WK	DIODE	1		IC3202	UPD42342608B	IC	1	
D3602	MA721WA	DIODE	1		IC3203	AN3741FAP-AV	IC	1	
D3803	MA720	DIODE	1		IC3204	AD90578RS	IC	1	
D3804	MA151WA	DIODE	1		IC3205	TC7SH08FU	IC	1	
D3901-03	MA165	DIODE	3		IC3207	M623706P	IC	1	
D3904, 05	MA4058-W	DIODE	2		IC3601	UPD40538G	IC	1	
D3906	MA165	DIODE	1		IC3802	AN3581S	IC	1	
D4002, 03	MA165	DIODE	2		IC3803	AN3296S	IC	1	
D4301	MA151K	DIODE	1		IC3701	TSB13LV11PBW	IC	1	
D4302	MA153	DIODE	1		IC3901	MC14053BF	IC	1	
D4501	MA721	DIODE	1		IC3902	MC14052BF	IC	1	
D4701	MA720	DIODE	1		IC3903	MC14051BF	IC	1	
D4702	MA151WK	DIODE	1		IC3904	PQ20VB2E	IC	1	
D6002-05	1SS355	DIODE	4		IC4001, 02	UPD4051BG	IC	2	
D6007, 08	1SS355	DIODE	2		IC4003	BU4053BCF	IC	1	
D7302	BB135	DIODE	1		IC4004	NJM4558M	IC	1	
D7601	MA4300	DIODE	1		IC4201	NJM2112V	IC	1	
D7602, 03	MA165	DIODE	2		IC4210	NJM2115V	IC	1	
D7653	MA723	DIODE	1		IC4301	NJM79L05A	IC	1	
D30001	MA151K	DIODE	1		IC4302	NJM4558M	IC	1	
D30002	MA8027-H	DIODE	1		IC4303	UPC78L05J	IC	1	
D30003	MA28W	DIODE	1		IC4304, 05	NJM4558M	IC	2	
D30004	MA142K	DIODE	1		IC4306	M62409FP	IC	1	
D30005	MA151K	DIODE	1		IC4307	NJM4558M	IC	1	
D30006	MA8033-L	DIODE	1		IC4308	M62409FP	IC	1	
D30007	MA142K	DIODE	1		IC4309	BU4052BCF	IC	1	
D30008	MA151K	DIODE	1		IC4310, 11	NJM4558M	IC	2	
D30009	MA721	DIODE	1		IC4312	NJM4565DD	IC	1	
D30010	MA151K	DIODE	1		IC4313, 14	BU4052BCF	IC	2	
					IC4315	NJM4558M	IC	1	
FL7301	VLF0633	FILTER	1		IC4319	HA17431PA	IC	1	
FL7801	ELB4HO20	FILTER	1		IC4501	AK4520A-VF	IC	1	
FL30001	ELB4Y029B	FILTER	1		IC4701	D78011FGC584	IC	1	
FL30002	VLF1367	FILTER	1		IC4702	PST5910	IC	1	
					IC4801	MC14052BF	IC	1	
FP3201	VJS3251	CONNECTOR (FEMALE)	1		IC9001	M31020VLEC	IC	1	
					IC8002	RN5VD29EA	IC	1	
IC00701	LA7576	IC	1		IC8003	MC14013BF	IC	1	
IC1001	UPC1093J	IC	1		IC8004	TC7W74FU	IC	1	
IC1003	NJM4565MD	IC	1		IC8005	TC7S86FU	IC	1	
IC1004	NJM2904M	IC	1		IC8006	TC75N54FU	IC	1	
IC1005	RN5RG22AA	IC	1		IC7301	TDA9874H	IC	1	
IC1006, 07	NJM4565MD	IC	2		IC7302	PST7043	IC	1	
IC1008	RN5RZ508A	IC	1		IC7651	RN5RZ508A	IC	1	
IC1009	PQ20VB2E	IC	1		IC7905	PST7043	IC	1	
IC2001	M31020VLED	IC	1		IC7906	M34510W2CRE2	IC	1	
IC2002	UPD4721GS	IC	1		IC30001	MC14053BF	IC	1	
IC2004	S29L331AFS	IC	1		IC30002	NJM2903M	IC	1	
IC2005	D784037GK508	IC	1		IC30003	TCHC4538AF	IC	1	
IC2006	MM1320ENRE	IC	1		IC30004	AN3916	IC	1	
IC2201	S80743AL	IC	1		IC30005	TCHC4538AF	IC	1	
IC2202	BU40528CF	IC	1		IC30006	NJM2255D	IC	1	
IC2203	M37777VACX	IC	1		IC30007	MC14053BF	IC	1	
IC2204	M6M80041P	IC	1		IC30008	TC9090AF	IC	1	
IC2205	M38027V4EM	IC	1		IC30009	MM1093PFB	IC	1	
IC2206	TCHC4538AF	IC	1		IC30010	M890C89WVAS	IC	1	
IC2207, 08	M86010SP	IC	2		IC30011	MM1108XFF	IC	1	
IC2209	S80743AL	IC	1		IC30012	M24C16-WBNG	IC	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
IC30013	SAB0161RIL16	IC	1		L30032	VLQ0163J101	COIL 100UH	1	
IC30014	S80743AL	IC	1		LB0601-03	VLP0145	COIL	3	
IC30015	M27C2001FBBA	IC	1		LB2002-04	VLP0364	COIL	3	
IC30016	SDA5273-2CS	IC	1		LB2201	VLP0085	COIL	1	
IC30017	M52380FP	IC	1		LB2202	ERJ6GEY0R00	M. RESISTOR CH 1/10W	0 1	
IC30018	NJM2513M	IC	1		LB2203-06	VLP0085	COIL	4	
IC30019	MC14053BF	IC	1		LB2501.02	VLP0083	COIL	2	
△ IP1001-09	VSF0015A06	IC PROTECTOR	9		LB3001.02	VLP0364	CHIP INDUCTOR	2	
△ IP1011	VSF0015A025	IC PROTECTOR	1		LB3004	VLP0364	CHIP INDUCTOR	1	
△ IP7601	VSF0015A025	IC PROTECTOR	1		LB3006	ERJ6GEY0R00	M. RESISTOR 1/10W	0 1	
					LB3701-04	VLP0364	CHIP INDUCTOR	4	
JK0802	VJJ0242	REMOTE CONTROL JACK	1		LB4901-08	VLP0147	COIL	1	
JK0903	VJJ0577	JACK	1		LB6004	VLP0364	CHIP INDUCTOR	1	
JK3901.02	VJS1470	CONNECTOR (FEMALE)	2		LB7301-04	VLP0150	COIL	4	
					LB7601	VLP0125	COIL	1	
K0702	ERJ3GEY0R00	M. RESISTOR CH 1/16W	0 1		LB30001-05	ERJ6GEY0R00	M. RESISTOR CH 1/10W	0 5	
K0704-06	ERJ3GEY0R00	M. RESISTOR 1/16W	0 3		LB30008.07	VLP0196	COIL	2	
K2001	ERJ3GEY0R00	M. RESISTOR 1/16W	0 1		LB30008-23	ERJ6GEY0R00	M. RESISTOR CH 1/10W	0 18	
K2503.04	ERJ6GEY0R00	M. RESISTOR CH 1/10W	2		LB30024	VLP0147	COIL	1	
K3903	ERJ6GEY0R00	M. RESISTOR CH 1/10W	1		LB30025-28	ERJ3GEY0R00	M. RESISTOR CH 1/16W	0 4	
K7301.02	ERJ6GEY0R00	M. RESISTOR CH 1/10W	2		LB30028-36	VLP0147	COIL	8	
K7304	ERJ6GEY0R00	M. RESISTOR CH 1/10W	1						
K7904	ERJ6GEY0R00	M. RESISTOR CH 1/10W	0 1		P1102	VJS1239T	CONNECTOR (FEMALE)	1	
K7909-11	ERJ6GEY0R00	M. RESISTOR CH 1/10W	3		P2502	VJP1831T	CONNECTOR (MALE)	1	
K30006	ERJ3GEY0R00	M. RESISTOR CH 1/16W	0 1		P3701	VJP1229T	CONNECTOR (MALE)	1	
K30010	ERJ3GEY0R00	M. RESISTOR CH 1/10W	0 1		P3701	VJP3125B008	CONNECTOR (MALE) 6P	1	
					P3901	VJP1242T	CONNECTOR (MALE)	1	
L0701	VLQ0163JR12	COIL 0.12UH	1		P4001	VJS3537A0208	CONNECTOR (FEMALE)	1	
L0705	VLQ0163J5R8	COIL 5.6UH	1		P6201	VJP1231T	CONNECTOR (MALE) 4P	1	
L0708	VLQEL05S150K	COIL	1		P6401	VJS3537A022	CONNECTOR (FEMALE)	1	
L1001	ELEKN390KA	COIL 39UH	1		P6701	VJS3537A032	CONNECTOR (FEMALE)	1	
L2001.02	ELJPA100KF	COIL 10UH	2		P6703	VJS3537A026	CONNECTOR (FEMALE)	1	
L2501-04	VLQ0614K331	COIL 330UH	4		P6707	VJP1239T	CONNECTOR (MALE)	1	
L3001-04	ELJPA100KF	COIL 10UH	4		P6707	VJS1239T	CONNECTOR (FEMALE)	1	
L3005	VLQ0426J150	COIL 15UH	1		P7901	VJS3537A019	CONNECTOR (FEMALE)	1	
L3006-08	ELJPA100KF	COIL 10UH	3		P7902	VJS3537A017	CONNECTOR (FEMALE)	1	
L3009	VLQ0426J120	COIL 12UH	1						
L3010	VLQ0426J150	COIL 15UH	1		PK0701	VJR0816E010W	CONNECTOR	1	
L3201.02	ELJPA100KF	COIL 10UH	2		PK7301	VJR0777B007W	PIN	1	
L3204.05	ELJPA100KF	COIL 10UH	2		PK7302	VJR0777B005W	PIN	1	
L3208	ELJPA220K8	COIL 22UH	1						
L3210	ELJPA100KF	COIL 10UH	1		PP0701	VJP3589E0048	CONNECTOR (MALE)	1	
L3601	VLQ0599J680	COIL 68UH	1		PP3401	VJP3573E012	CONNECTOR (MALE)	1	
L3602	VLQ0599J330	COIL 33UH	1		PP3402.03	VJP3573E020	CONNECTOR (MALE)	2	
L3603	VLQ0599J680	COIL 68UH	1		PP3404	VJP3573E008	CONNECTOR (MALE)	1	
L3604	VLQ0599J330	COIL 33UH	1		PP3501.02	VJP3573E020	CONNECTOR (MALE)	2	
L3605	VLQ0398	COIL	1		PP3503	VJP3573E012	CONNECTOR (MALE)	1	
L3901.02	VLQ0599J680	COIL 68UH	2		PP3610	VJP3994	CONNECTOR (MALE)	1	
L4201	VLQ0426J6R8	COIL 8.9UH	1		PP3901	VJP3042B0009W	CONNECTOR (MALE)	1	
L4501.02	ELJPA100KF	COIL 10UH	2		PP4002.03	VJP3186A018W	CONNECTOR (MALE)	2	
L4701.02	VLQ0599J100	COIL 10UH	2		PP6706	VJP3042A020W	CONNECTOR (MALE)	1	
L7301	VLQ0599J3R3	COIL 3.3UH	1						
L7302	VLQ0599J1R0	COIL 1UH	1		PS0601	VJS3042F009W	CONNECTOR (FEMALE)	1	
L7601	VLQ0599J330	COIL 33UH	1		PS2501	VJS3042F020W	CONNECTOR (FEMALE)	1	
L7602	VLQ0599J2R7	COIL 2.7UH	1		PS3001	VJS3994	CONNECTOR (FEMALE)	1	
L7805	VLQEL05S330	COIL 33UH	1		PS3002	VJP3884B060	CONNECTOR (MALE)	1	
L7811	VLQ0599J100	COIL 10UH	1		PS3901	VJS3573F012	CONNECTOR (FEMALE)	1	
L30001-03	ELJPA330KF	COIL 33UH	3		PS3902.03	VJS3573F020	CONNECTOR (FEMALE)	2	
L30004	VLQ0163J560	COIL 56UH	1		PS3904	VJS3573F008	CONNECTOR (FEMALE)	1	
L30005	VLQ0163J220	COIL 22UH	1		PS4301.02	VJS3186B018	CONNECTOR (FEMALE)	2	
L30006-09	VLQ0163J330	COIL 33UH	4		PS30001.02	VJS3573F020	CONNECTOR (FEMALE)	2	
L30010-14	ELJPA330KF	COIL 33UH	5		PS30003	VJS3573F012	CONNECTOR (FEMALE)	1	
L30015	VLQ0163J220	COIL 22UH	1						
L30017	VLQ0163J220	COIL 22UH	1		Q0701	MSD601-S	TRANSISTOR	1	
L30018-20	ELJPA330KF	COIL 33UH	3		Q0702	MSB709-R	TRANSISTOR	1	
L30021	ELJPA150KF	COIL 15UH	1		Q1001-06	2SD1996	TRANSISTOR	5	
L30022.23	ELJPA330KF	COIL 33UH	2		Q1008	2SB956	TRANSISTOR	1	
L30024	VLQ0163J100	COIL 10UH	1		Q1009	2SB848A	TRANSISTOR	1	
L30025	ELJPA330KF	COIL 33UH	1		Q1010-12	2SD1996	TRANSISTOR	3	
L30026	VLQ0163J100	COIL 10UH	1		Q1017	2SD25440-G	TRANSISTOR	1	
L30027	VLQ0163J5R6	COIL 5.6UH	1		Q1018	2SD1996	TRANSISTOR	1	
L30028.29	VLQ0163J330	COIL 33UH	2		Q1020	2SD601A-R	TRANSISTOR	1	
L30030	ELJPA150KF	COIL 15UH	1		Q1023	2SD802A-R	TRANSISTOR	1	
L30031	VLQ0163J8R2	COIL 8.2UH	1		Q1024	23B710	TRANSISTOR	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Q1025-27	2SB956	TRANSISTOR	3		QR1003	UN221F	TRANSISTOR-RESISTOR	1	
Q1028, 29	2SD1996	TRANSISTOR	2		QR1005	MUN2113	TRANSISTOR-RESISTOR	1	
Q1030	2SD601A-R	TRANSISTOR	1		QR1008	MUN2211	TRANSISTOR-RESISTOR	1	
Q2201-08	2SD601A-R	TRANSISTOR	8		QR1009	MUN2213	TRANSISTOR-RESISTOR	1	
Q2501	2SB1073	TRANSISTOR	1		QR1011	MUN2213	TRANSISTOR-RESISTOR	1	
Q2506, 07	2SB1073	TRANSISTOR	2		QR1012	UN211D	TRANSISTOR-RESISTOR	1	
Q2509	2SB1073	TRANSISTOR	1		QR2001	UN5113	TRANSISTOR-RESISTOR	1	
Q3001	2SD1819	TRANSISTOR	1		QR2002, 03	UN5213	TRANSISTOR-RESISTOR	2	
Q3002	2SB1218	TRANSISTOR	1		QR2201-06	MUN2213	TRANSISTOR-RESISTOR	6	
Q3003	2SD1819A	TRANSISTOR	1		QR2207, 08	MUN2212	TRANSISTOR-RESISTOR	2	
Q3004, ■	2SD1819	TRANSISTOR	2		QR2209-11	MUN2211	TRANSISTOR-RESISTOR	3	
Q3006	2SC3830	TRANSISTOR	1		QR2212	MUN2213	TRANSISTOR-RESISTOR	1	
Q3007, 08	2SD1819	TRANSISTOR	2		QR2213	MUN2211	TRANSISTOR-RESISTOR	1	
Q3201	2SB1218A-R	TRANSISTOR	1		QR2214	MUN2213	TRANSISTOR-RESISTOR	1	
Q3601	2SD601A-R	TRANSISTOR	1		QR2215	MUN2211	TRANSISTOR-RESISTOR	1	
Q3602	MSB709-R	TRANSISTOR	1		QR2216-18	MUN2213	TRANSISTOR-RESISTOR	3	
Q3901	2SD1328	TRANSISTOR	1		QR2220-22	MUN2213	TRANSISTOR-RESISTOR	3	
Q3902	2SB709A	TRANSISTOR	1		QR2503	UN215	TRANSISTOR-RESISTOR	1	
Q3903, 04	2SD601A	TRANSISTOR	2		QR2508	UN2115	TRANSISTOR-RESISTOR	1	
Q3905	2SB709A	TRANSISTOR	1		QR3601-03	MUN2213	TRANSISTOR-RESISTOR	3	
Q3907-09	2SD601A	TRANSISTOR	3		QR3604, 05	UN221L	TRANSISTOR-RESISTOR	2	
Q4001	2SK170BL	TRANSISTOR	1		QR3606	MUN2212	TRANSISTOR-RESISTOR	1	
Q4002	2SB709	TRANSISTOR	1		QR3901	MUN2211	TRANSISTOR-RESISTOR	1	
Q4003	2SD1992	TRANSISTOR	1		QR3902	MUN2111	TRANSISTOR-RESISTOR	1	
Q4004	2SD601A-R	TRANSISTOR	1		QR3903	MUN2211	TRANSISTOR-RESISTOR	1	
Q4005	2SB1320A	TRANSISTOR	1		QR3904	MUN2213	TRANSISTOR-RESISTOR	1	
Q4301	2SD1468T93	TRANSISTOR	1		QR4301	UN2119	TRANSISTOR-RESISTOR	1	
Q4302	MSB709-R	TRANSISTOR	1		QR4302	MUN2212	TRANSISTOR-RESISTOR	1	
Q4303-10	2SD601A	TRANSISTOR	8		QR4303	MUN2213	TRANSISTOR-RESISTOR	1	
Q4311, 12	XN4501	TRANSISTOR-RESISTOR	2		QR4701-03	MUN2213	TRANSISTOR-RESISTOR	3	
Q4313-15	2SD601A	TRANSISTOR	3		QR4704	MUN2211	TRANSISTOR-RESISTOR	1	
Q4701, 02	2SD601A-R	TRANSISTOR	2		QR4706	MUN2112	TRANSISTOR-RESISTOR	1	
Q6001	2SB970X	TRANSISTOR	1		QR6001	UN5213	TRANSISTOR-RESISTOR	1	
Q7601	2SD601A-R	TRANSISTOR	1		QR7601	MUN2213	TRANSISTOR-RESISTOR	1	
Q7604, ■	2SD1328-S	TRANSISTOR	2		QR30001	MUN2213	TRANSISTOR-RESISTOR	1	
Q7606	2SB709A	TRANSISTOR	1		QR30003	UN221L	TRANSISTOR-RESISTOR	1	
Q30001	MSD601-R	TRANSISTOR	1		QR30004	UN5116	TRANSISTOR	1	
Q30002	MSB709-R	TRANSISTOR	1		QR30005	MUN2213	TRANSISTOR-RESISTOR	1	
Q30003, 04	2SB1218	TRANSISTOR	2		QR30006	MUN2111	TRANSISTOR-RESISTOR	1	
Q30005, 06	2SC3930	TRANSISTOR	2						
Q30007, 08	MSB709-R	TRANSISTOR	2		R0703	ERJ3GEY6152	M. RESISTOR CH 1/16W 1.5K	1	
Q30008	2SC3930	TRANSISTOR	1		R0704	ERJ3GEYJ222	M. RESISTOR CH 1/16W 2.2K	1	
Q30010	MSC2295-B	TRANSISTOR	1		R0705	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1	
Q30011	2SB1218	TRANSISTOR	1		R0706, 07	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	2	
Q30012	MSC2295-B	TRANSISTOR	1		R0708	ERJ3GEY6152	M. RESISTOR CH 1/16W 1.5K	1	
Q30013, 14	2SB1218	TRANSISTOR	2		R0709	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1	
Q30015	2SD1819	TRANSISTOR	1		R0710	ERJ6GEY6134	M. RESISTOR CH 1/10W 150K	1	
Q30016	MSB709-R	TRANSISTOR	1		R0713	ERJ3GEY6471	M. RESISTOR CH 1/16W 470	1	
Q30017	2SD1819	TRANSISTOR	1		R0714	ERJ3GEYJ470	M. RESISTOR CH 1/16W 47	1	
Q30018	MSB709-R	TRANSISTOR	1		R0715	ERJ3GEYJ432	M. RESISTOR CH 1/16W 4.3K	1	
Q30019	2SD1819	TRANSISTOR	1		R0716	VRE0040E151	M. RESISTOR CH 1/10W 150	1	
Q30020	2SB1218	TRANSISTOR	1		R0717	ERJ3GEYJ330	M. RESISTOR CH 1/16W 33	1	
Q30021, 22	2SD1819	TRANSISTOR	2		R0718	ERJ3GEY6102	M. RESISTOR CH 1/16W 1K	1	
Q30023	2SB1218	TRANSISTOR	1		R0719	ERJ6GEY6752	M. RESISTOR CH 1/10W 7.5K	1	
Q30024-27	2SD1819	TRANSISTOR	4		R0720	ERJ3GEY6102	M. RESISTOR CH 1/16W 1K	1	
Q30028	MSB709-R	TRANSISTOR	1		R0722	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
Q30030	MSD601-R	TRANSISTOR	1		R0723	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	1	
Q30031, 32	2SB1218	TRANSISTOR	2		R0724	ERJ3GEYJ183	M. RESISTOR ■ 1/16W 18K	1	
Q30033	2SD1819	TRANSISTOR	1		R0725	ERJ3GEYJ182	M. RESISTOR CH 1/16W 1.8K	1	
Q30034, 35	2SB1218	TRANSISTOR	2		R0726	ERJ3GEY6561	M. RESISTOR CH 1/16W 560	1	
Q30036	2SD1819	TRANSISTOR	1		R0727	ERJ3GEY6132	M. RESISTOR CH 1/16W 1.3K	1	
Q30037	MSB709-R	TRANSISTOR	1		R0728	ERJ3GEY6471	M. RESISTOR CH 1/16W 470	1	
Q30038	2SD1819	TRANSISTOR	1		R0729	ERJ3GEY6102	M. RESISTOR ■ 1/16W 1K	1	
Q30039	2SB1218	TRANSISTOR	1		R0732	ERJ3GEY6471	M. RESISTOR ■ 1/16W 470	1	
Q30040	2SD1819	TRANSISTOR	1		R0783	ERJ3GEYJ393	M. RESISTOR ■ 1/16W 39K	1	
Q30042	2SD1819	TRANSISTOR	1		R1001	ERDS2TJ182	C. RESISTOR 1/4W 1.8K	1	
Q30043	2SB1218	TRANSISTOR	1		R1002	ERDS2TJ122	C. RESISTOR 1/4W 1.2K	1	
Q30044	MSD601-R	TRANSISTOR	1		R1004	ERDS2TJ471	C. RESISTOR 1/4W 470	1	
Q30045	2SB1218	TRANSISTOR	1		R1005, 08	ERJ6GEY6882	M. RESISTOR CH 1/10W 6.8K	2	
Q30046	MSD601-R	TRANSISTOR	1		R1007	ERJ6GEY6103	M. RESISTOR CH 1/10W 10K	1	
Q30047	MSB709-R	TRANSISTOR	1		R1008	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
Q30048	2SD1819	TRANSISTOR	1		R1009	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
Q30049	2SB1218	TRANSISTOR	1		R1012	ERJ6GEY6103	M. RESISTOR CH 1/10W 10K	1	
					R1013, 14	ERDS2TJ821	C. RESISTOR 1/4W 820	2	
QR1001	MUN2213	TRANSISTOR-RESISTOR	1		R1015	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R1016	ERDS2TJ272	C. RESISTOR 1/4W 2.7K	1	
R1018	ERDS2TJ821	C. RESISTOR 1/4W 820	1	
R1019	ERDS2TJ272	C. RESISTOR 1/4W 2.7K	1	
R1021	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R1022	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R1023	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R1025	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R1026	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1	
R1027	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R1028	ERJ6GEYF822	M. RESISTOR CH 1/10W 8.2K	1	
R1029	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R1030	ERJ6GEY0332	M. RESISTOR CH 1/10W 3.3K	1	
R1031	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R1032, 33	ERJ6GEY0563	M. RESISTOR CH 1/10W 56K	2	
R1034	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1	
R1038	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1	
R1039	ERDS2TJ562	C. RESISTOR 1/4W 5.6K	1	
R1040	ERDS2TJ821	C. RESISTOR 1/4W 820	1	
R1041	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R1042	ERDS2TJ562	C. RESISTOR 1/4W 5.6K	1	
R1043	ERDS2TJ103	C. RESISTOR 1/4W 10K	1	
R1044	ERDS2TJ332	C. RESISTOR 1/4W 3.3K	1	
R1045, 46	ERDS2TJ472	C. RESISTOR 1/4W 4.7K	2	
R1049	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R1050, 51	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	2	
R1052	ERJ6GEY0562	M. RESISTOR CH 1/10W 5.6K	1	
R2001	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2002, 03	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	2	
R2006-21	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	16	
R2022-27	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	6	
R2028	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2029-31	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	3	
R2032	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2033	ERJ3GEYJ363	M. RESISTOR CH 1/16W 36K	1	
R2034	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1	
R2035	ERJ3GEYJ220	M. RESISTOR CH 1/16W 22	1	
R2036	ERJ3GEYJ478	M. RESISTOR CH 1/16W 47K	1	
R2038	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
R2039	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2040	ERJ3GEY0822	M. RESISTOR CH 1/16W 8.2K	1	
R2042	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2045	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2047	ERJ3GEY0102	M. RESISTOR CH 1/16W 1K	1	
R2048	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2049	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2050	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2052	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2055-60	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	6	
R2061, 62	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	2	
R2063, 64	ERJ6GEY0101	M. RESISTOR CH 1/10W 100	2	
R2065	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2068	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2073	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2074	ERJ3GEY0102	M. RESISTOR CH 1/16W 1K	1	
R2076	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	1	
R2077	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2079	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2080	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1	
R2081	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1	
R2082	ERJ3RBD183	M. RESISTOR CH 1/16W 18K	1	
R2084	ERJ3RBD333	M. RESISTOR CH 3W 33K	1	
R2085, 86	ERJ3GEY0822	M. RESISTOR CH 1/16W 8.2K	2	
R2087, 88	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	2	
R2090	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2092	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R2099-02	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	4	
R2104-06	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	3	
R2111	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2112	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2113	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	1	
R2115	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R2118, 19	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R2201	ERJ6GEY0152	M. RESISTOR CH 1/10W 1.5K	1	
R2202	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2203	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R2204-06	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	3	
R2207	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2209	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R2211	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2213	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2215	ERJ6GEY0221	M. RESISTOR CH 1/10W 220	1	
R2217-19	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	3	
R2220-23	ERJ6GEY0332	M. RESISTOR CH 1/10W 3.3K	4	
R2224-26	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	3	
R2227	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2228	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2229	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2230	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2231	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2232	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2233	ERJ6GEY0105	M. RESISTOR CH 1/10W 1M	1	
R2234	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2235	ERJ6GEY0801	M. RESISTOR CH 1/10W 5.6K	1	
R2236	ERJ6GEYJ106	M. RESISTOR CH 1/10W 10M	1	
R2237	ERJ6GEYJ224	M. RESISTOR CH 1/10W 220K	1	
R2238-40	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	3	
R2241	ERJ6GEY0562	M. RESISTOR CH 1/10W 5.6K	1	
R2242	ERJ6GEYF822	M. RESISTOR CH 1/10W 8.2K	1	
R2243	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	1	
R2244	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2245	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2246	ERJ6GEY0152	M. RESISTOR CH 1/10W 1.5K	1	
R2247	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2248	ERJ6GEY0183	M. RESISTOR CH 1/10W 18K	1	
R2249	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2250, 51	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	2	
R2252-54	ERJ6GEY0332	M. RESISTOR CH 1/10W 3.3K	3	
R2255	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2256, 57	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	2	
R2258	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R2261	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2262	ERJ6GEY0161	M. RESISTOR CH 1/10W 160	1	
R2263	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2264	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2265, 66	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	2	
R2267	ERJ6GEY0223	M. RESISTOR CH 1/10W 22K	1	
R2268	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2269-75	ERJ6GEY0101	M. RESISTOR CH 1/10W 100	7	
R2280-84	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	5	
R2285	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2286	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1	
R2287	ERJ6GEY0152	M. RESISTOR CH 1/10W 1.5K	1	
R2288	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	1	
R2289	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1	
R2290	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	1	
R2291	ERJ6GEY0101	M. RESISTOR CH 1/10W 100	1	
R2292-95	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	4	
R2296, 97	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	2	
R2298, 99	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	2	
R2301	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R2302	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	1	
R2303	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2304	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2305	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R2306-12	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	7	
R2313	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2314	ERJ6GEY0223	M. RESISTOR CH 1/10W 22K	1	
R2315	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2316	ERJ6GEY0272	M. RESISTOR CH 1/10W 2.7K	1	
R2317	ERJ6GEY0223	M. RESISTOR CH 1/10W 22K	1	
R2318	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2319	ERJ6GEY0222	M. RESISTOR CH 1/10W 2.2K	1	
R2320	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2321	ERJ6GEY0223	M. RESISTOR CH 1/10W 22K	1	
R2322	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2323	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2324	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	
R2325	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R2326	ERJ6GEY0223	M. RESISTOR CH 1/10W 22K	1	
R2327	ERJ6GEY0103	M. RESISTOR CH 1/10W 10K	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R2328, 29	ERJ6GEYF473	M. RESISTOR 1/10W 47K	2		R3069, 70	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R2330	ERJ6GEYB103	M. RESISTOR 1/10W 10K	1		R3072	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
R2331	ERJ6GEYOR00	M. RESISTOR 1/10W	1		R3073	ERJ3GEYJ563	M. RESISTOR CH 1/16W 56K	1	
R2504	ERJ6GEYB102	M. RESISTOR CH 1/10W 1K	1		R3074	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1	
R2505	ERDS2TJ681	C. RESISTOR 1/4W 680	1		R3075	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R2513	ERJ6GEYB102	M. RESISTOR CH 1/10W 1K	1		R3077	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1	
R2514	ERDS2TJ681	C. RESISTOR 1/4W 680	1		R3079	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	1	
R2523	ERJ6GEYB331	M. RESISTOR CH 1/10W 330	1		R3080-83	ERJ3GEYOR00	M. RESISTOR CH 1/16W	4	
R2524	ERDS2TJ122	C. RESISTOR 1/4W 1.2K	1		R3084	ERJ3GEYB152	M. RESISTOR CH 1/16W 1.5K	1	
R2525-27	ERJ6GEYJ471	M. RESISTOR CH 1/10W 470	3		R3085	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1	
R2528	ERJ6GEYB103	M. RESISTOR CH 1/10W 10K	1		R3086	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1	
R2534, 35	ERJ6GEYB103	M. RESISTOR CH 1/10W 10K	2		R3088	ERJ3GEYJ103	M. RESISTOR CH 1/16W 100K	1	
R2537	ERJ6GEYB183	M. RESISTOR CH 1/10W 18K	1		R3089, 90	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	2	
R2538, 39	ERJ6GEYB104	M. RESISTOR CH 1/10W 100K	2		R3091	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R2540, 41	ERJ6GEYB103	M. RESISTOR CH 1/10W 10K	2		R3092	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1	
R2543	ERJ6GEYB153	M. RESISTOR CH 1/10W 15K	1		R3094	ERJ3GEYJ103	M. RESISTOR CH 1/16W 100K	1	
R2544	ERJ6GEYB474	M. RESISTOR CH 1/10W 470K	1		R3095	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R2545	ERJ6GEYB104	M. RESISTOR CH 1/10W 100K	1		R3097	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2546	ERJ6GEYB183	M. RESISTOR CH 1/10W 18K	1		R3098, 99	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	2	
R2547	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		R3100	ERJ3GEYJ182	M. RESISTOR CH 1/16W 1.8K	1	
R2548	ERJ6GEYB103	M. RESISTOR CH 1/10W 10K	1		R3101	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R2549	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		R3102	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1	
R2550	ERJ6GEYB104	M. RESISTOR CH 1/10W 100K	1		R3117	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2551	ERJ6GEYB183	M. RESISTOR CH 1/10W 18K	1		R3120-22	ERJ3GEYB152	M. RESISTOR CH 1/16W 1.5K	3	
R2552	ERJ6GEYB474	M. RESISTOR CH 1/10W 470K	1		R3123	ERJ3GEYJ564	M. RESISTOR CH 1/16W 560K	1	
R2553	ERJ6GEYB153	M. RESISTOR CH 1/10W 15K	1		R3128	ERJ3GEYJ881	M. RESISTOR CH 1/16W 880	1	
R2554	ERJ6GEYB331	M. RESISTOR CH 1/10W 330	1		R3129	ERJ3GEYJ561	M. RESISTOR CH 1/16W 560	1	
R2555	ERDS2TJ122	C. RESISTOR 1/4W 1.2K	1		R3130	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1	
R2556	ERJ6GEYJ471	M. RESISTOR CH 1/10W 470	1		R3131	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R3001	ERJ3RBD104	M. RESISTOR CH 3W 100K	1		R3132	ERJ3GEYJ881	M. RESISTOR CH 1/16W 880	1	
R3003	ERJ3GEYB332	M. RESISTOR CH 1/16W 3.3K	1		R3133	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R3004	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1		R3201	ERJ2GEJ102	M. RESISTOR CH 2W 1K	1	
R3005, 06	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2		R3202	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1	
R3009	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1		R3203	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1	
R3010	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1		R3204	ERJ3GEYB471	M. RESISTOR CH 1/16W 470	1	
R3011, 12	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	2		R3205	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1	
R3013	ERJ3GEYB332	M. RESISTOR CH 1/16W 3.3K	1		R3206, 07	ERJ3GEYJ121	M. RESISTOR CH 1/16W 120	2	
R3014	ERJ3GEYB472	M. RESISTOR CH 1/16W 4.7K	1		R3208	ERJ3GEYB822	M. RESISTOR CH 1/16W 2.2K	1	
R3016	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1		R3209	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1	
R3017	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		R3210	ERJ3GEYJ561	M. RESISTOR CH 1/16W 560	1	
R3018	ERJ3GEYB471	M. RESISTOR CH 1/16W 470	1		R3211	ERJ3GEYJ680	M. RESISTOR CH 1/16W	1	
R3019	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R3212	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3020	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	1		R3213	ERJ3GEYB682	M. RESISTOR CH 1/16W 6.8K	1	
R3021	ERJ3GEYB332	M. RESISTOR CH 1/16W 3.3K	1		R3214	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1	
R3022	ERJ3GEYJ121	M. RESISTOR CH 1/16W 120	1		R3215	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	1	
R3023	ERJ3GEYB682	M. RESISTOR CH 1/16W 6.8K	1		R3217	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R3024	ERJ3GEYB332	M. RESISTOR CH 1/16W 3.3K	1		R3218	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1	
R3026	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1		R3219	ERJ3RBD222	M. RESISTOR CH 3W 2.2K	1	
R3027	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1		R3220	ERJ3GEYJ564	M. RESISTOR CH 1/16W 560K	1	
R3028	ERJ3GEYJ183	M. RESISTOR CH 1/16W 18K	1		R3221	ERJ3GEYJ391	M. RESISTOR CH 1/16W 390	1	
R3034	ERJ3GEYB822	M. RESISTOR CH 1/16W 8.2K	1		R3222	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1	
R3035	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1		R3223	ERJ3RBD222	M. RESISTOR CH 3W 2.2K	1	
R3036	ERJ3GEYB822	M. RESISTOR CH 1/16W 8.2K	1		R3224	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R3037	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1		R3225	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1	
R3038	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R3226	ERJ3GEYJ224	M. RESISTOR CH 1/16W 220K	1	
R3039	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1		R3227	ERJ3GEYJ563	M. RESISTOR CH 1/16W 56K	1	
R3041	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	1		R3228	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1	
R3042	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1		R3229	ERJ3GEYJ224	M. RESISTOR CH 1/16W 220K	1	
R3043	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		R3230	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	1	
R3044	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R3232	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R3046	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R3233	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	1	
R3047	ERJ3GEYB471	M. RESISTOR CH 1/16W 470	1		R3234	ERJ3GEYB472	M. RESISTOR CH 1/16W 4.7K	1	
R3048, 49	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	2		R3235-37	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	3	
R3050, 51	ERJ3GEYB471	M. RESISTOR CH 1/16W 470	2		R3238	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
R3052	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1		R3239	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R3053	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R3240, 41	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	2	
R3054	ERJ3GEYJ105	M. RESISTOR CH 1/16W	1		R3242	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3057, 58	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2		R3243	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1	
R3059	ERJ6GEYOR00	M. RESISTOR CH 1/10W	1		R3245	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R3060, 61	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	2		R3249	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3063	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	1		R3249	ERJ3GEYJ683	M. RESISTOR CH 1/16W 68K	1	
R3064	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1		R3256	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3065	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	1		R3257	ERJ3GEYJ124	M. RESISTOR CH 1/16W 120K	1	
R3066	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1		R3258-68	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	9	
R3067, 68	ERJ3GEYB102	M. RESISTOR CH 1/16W 1K	2		R3267	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3288	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1		R3931	ERJ6GEY6222	M. RESISTOR CH 1/10W 2.2K	1	
R3289-72	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	4		R3932, 33	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	2	
R3301-07	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	7		R3934	ERJ6GEY0273	M. RESISTOR CH 1/10W 27K	1	
R3308	ERJ3GEYJ562	M. RESISTOR 1/16W 5.6K	1		R3935	ERJ6GEY6883	M. RESISTOR CH 1/10W 68K	1	
R3309, 10	ERJ3GEYOR00	M. RESISTOR 1/16W 0	2		R3936, 37	ERJ6GEY6183	M. RESISTOR CH 1/10W 18K	2	
R3312	ERJ3GEYOR00	M. RESISTOR 1/16W 0	1		R4001	ERJ6GEY6183	M. RESISTOR CH 1/10W 18K	1	
R3601	ERJ6GEY6103	M. RESISTOR 1/10W 10K	1		R4002-04	ERJ6GEYF333	M. RESISTOR 1/10W 33K	3	
R3602	ERJ6GEY6392	M. RESISTOR CH 1/10W 3.9K	1		R4005	ERJ6GEY6883	M. RESISTOR 1/10W 68K	1	
R3603, 04	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	2		R4008	ERJ6GEY6223	M. RESISTOR 1/10W 22K	1	
R3605	ERJ6GEY6103	M. RESISTOR CH 1/10W 10K	1		R4007	ERJ6GEY6883	M. RESISTOR CH 1/10W 68K	1	
R3606	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1		R4008	ERJ6GEY6223	M. RESISTOR 1/10W 22K	1	
R3607	ERJ6GEYJ224	M. RESISTOR CH 1/10W 220K	1		R4009	ERJ6GEYJ104	M. RESISTOR CH 1/10W 100K	1	
R3608	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1		R4010	ERJ6GEY6223	M. RESISTOR CH 1/10W 22K	1	
R3609	ERJ6GEY6821	M. RESISTOR 1/10W 820	1		R4011	ERJ6GEYJ104	M. RESISTOR CH 1/10W 100K	1	
R3610	ERJ6GEY6881	M. RESISTOR CH 1/10W 680	1		R4012	ERJ6GEY6223	M. RESISTOR CH 1/10W 22K	1	
R3611	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1		R4014	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R3612	ERJ6GEY6474	M. RESISTOR CH 1/10W 470K	1		R4015	ERJ6GEYJ113	M. RESISTOR CH 1/10W 11K	1	
R3613	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		R4016	ERJ6GEY6222	M. RESISTOR CH 1/10W 2.2K	1	
R3614, 15	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	2		R4017	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R3617	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1		R4018	ERJ6GEY6105	M. RESISTOR CH 1/10W 1M	1	
R3618	ERJ6GEYF561	M. RESISTOR CH 1/10W 560	1		R4019	ERJ6RBD471	M. RESISTOR CH 1/10W 470	1	
R3620	ERJ6GEY6332	M. RESISTOR CH 1/10W 3.3K	1		R4020	ERJ6RBD102	M. RESISTOR CH 1/10W 1K	1	
R3621	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		R4021, 22	ERJ6RBD202	M. RESISTOR CH 1/10W 2K	2	
R3622	ERJ6GEY6101	M. RESISTOR 1/10W 100	1		R4023	ERJ6RBD102	M. RESISTOR CH 1/10W 1K	1	
R3623	ERJ6GEY6103	M. RESISTOR CH 1/10W 10K	1		R4024	ERJ6RBD201	M. RESISTOR CH 1/10W 200	1	
R3624	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	1		R4025-27	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	3	
R3625	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		R4203, 04	ERJ3RBD103	M. RESISTOR CH 3W 10K	2	
R3626	ERJ6GEY6101	M. RESISTOR 1/10W 100	1		R4205, 06	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3627	ERJ6GEY6104	M. RESISTOR 1/10W 100K	1		R4207-10	ERJ3RBD103	M. RESISTOR CH 3W 10K	4	
R3628	ERJ6GEY6153	M. RESISTOR 1/10W 15K	1		R4213, 14	ERJ3RBD103	M. RESISTOR 1/10W 3W 10K	2	
R3629, 30	ERJ6GEY6103	M. RESISTOR 1/10W 10K	2		R4215, 16	ERJ3GEYOR00	M. RESISTOR 1/16W 0	2	
R3631	ERJ6GEY6222	M. RESISTOR CH 1/10W 2.2K	1		R4217, 18	ERJ3RBD103	M. RESISTOR CH 3W 10K	2	
R3633	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1		R4219-22	ERJ3RBD472	M. RESISTOR CH 1/10W 4.7K	4	
R3634	ERJ6GEY6883	M. RESISTOR CH 1/10W 68K	1		R4223, 24	ERJ3RBD103	M. RESISTOR CH 3W 10K	2	
R3635	ERJ6GEYJ884	M. RESISTOR CH 1/10W 880K	1		R4225, 26	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R3636	ERJ6GEY6753	M. RESISTOR CH 1/10W 75	1		R4227, 28	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	2	
R3637	ERJ6GEY6331	M. RESISTOR CH 1/10W 330	1		R4229-32	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	4	
R3638	ERJ6GEY6824	M. RESISTOR CH 1/10W 820K	1		R4233	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
R3640	ERJ6GEY6392	M. RESISTOR CH 1/10W 3.9K	1		R4301	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1	
R3641	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1		R4302	ERJ6RBD391	M. RESISTOR CH 1/10W 390	1	
R3643	ERJ6GEY6222	M. RESISTOR CH 1/10W 2.2K	1		R4303	ERJ6RBD472	M. RESISTOR CH 1/10W 4.7K	1	
R3701	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		R4305	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1	
R3702	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R4306, 07	ERJ6RBD183	M. RESISTOR CH 1/10W 18K	2	
R3703	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R4308	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1	
R3709	ERJ3RBD272	M. RESISTOR CH 3W 2.7K	1		R4309	ERJ6GEY6183	M. RESISTOR CH 1/10W 18K	1	
R3710	ERJ3RBD332	M. RESISTOR CH 3W 3.3K	1		R4310	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1	
R3711	ERJ3GEYJ394	M. RESISTOR CH 1/16W 390K	1		R4311	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1	
R3715-18	ERJ3RBD560	M. RESISTOR CH 3W 56	4		R4312	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1	
R3719	ERJ3GEYJ391	M. RESISTOR CH 1/16W 390	1		R4313	ERJ6GEY6183	M. RESISTOR CH 1/10W 18K	1	
R3720	ERJ3GEY6472	M. RESISTOR CH 1/16W 4.7K	1		R4314	ERJ6GEY6102	M. RESISTOR CH 1/10W 1K	1	
R3721-25	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	5		R4315	ERJ6RBD123	M. RESISTOR CH 1/10W 12K	1	
R3728-33	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	6		R4316	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1	
R3735	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R4317	ERJ6RBD123	M. RESISTOR CH 1/10W 12K	1	
R3736	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R4318	ERJ6RBD204	M. RESISTOR CH 1/10W 200K	1	
R3737	ERJ3GEYJ270	M. RESISTOR CH 1/16W 27	1		R4319	ERJ6RBD104	M. RESISTOR CH 1/10W 100K	1	
R3739, 40	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2		R4320	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1	
R3901-09	ERJ6GEY6750	M. RESISTOR CH 1/10W 75	9		R4321	ERJ6RBD104	M. RESISTOR CH 1/10W 100K	1	
R3910	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1		R4322	ERJ6RBD204	M. RESISTOR CH 1/10W 200K	1	
R3911	ERJ6GEY6331	M. RESISTOR CH 1/10W 330	1		R4323	ERJ6RBD273	M. RESISTOR CH 1/10W 27K	1	
R3912	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1		R4324	ERJ6RBD751	M. RESISTOR CH 1/10W 750	1	
R3913	ERJ6GEY6121	M. RESISTOR CH 1/10W 120	1		R4325	ERJ6RBD204	M. RESISTOR CH 1/10W 200K	1	
R3914	ERJ6GEYJ111	M. RESISTOR CH 1/10W 110	1		R4326	ERJ6RBD112	M. RESISTOR CH 1/10W 1.1K	1	
R3915	ERJ6GEY6223	M. RESISTOR CH 1/10W 22K	1		R4327	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1	
R3916	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1		R4328	ERJ6RBD204	M. RESISTOR CH 1/10W 200K	1	
R3917	ERJ6GEY6331	M. RESISTOR CH 1/10W 330	1		R4329	ERJ6GEY6331	M. RESISTOR CH 1/10W 330	1	
R3918	ERJ6GEY6223	M. RESISTOR CH 1/10W 22K	1		R4330	ERJ6GEY6101	M. RESISTOR CH 1/10W 100	1	
R3919	ERJ6GEYJ111	M. RESISTOR CH 1/10W 110	1		R4331	ERJ6GEY6105	M. RESISTOR CH 1/10W 1M	1	
R3920	ERJ6GEY6121	M. RESISTOR CH 1/10W 120	1		R4332	ERJ6RBD223	M. RESISTOR CH 1/10W 22K	1	
R3921-23	ERJ6GEY6750	M. RESISTOR CH 1/10W 75	3		R4333	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R3924	ERDS2TJ561	C. RESISTOR 1/4W 560	1		R4334	ERJ6GEY0102	M. RESISTOR CH 1/10W 1K	1	
R3925	ERJ6GEY6104	M. RESISTOR CH 1/10W 100K	1		R4335	ERJ6RBD223	M. RESISTOR 1/10W 22K	1	
R3926	ERJ6GEY6750	M. RESISTOR CH 1/10W 75	1		R4336	ERJ6GEY0103	M. RESISTOR 1/10W 10K	1	
R3927	ERJ6GEYF822	M. RESISTOR CH 1/10W 8.2K	1		R4337	ERJ6RBD273	M. RESISTOR 1/10W 27K	1	
R3928	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1		R4338	ERJ6GEYOR00	M. RESISTOR CH 1/10W 0	1	
					R4339	ERJ6RBD363	M. RESISTOR CH 1/10W 36K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4340	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6008	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R4342	ERJ6RBD083	M. RESISTOR CH 1/10W 88K	1		R6009	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R4343	ERJ6RBD223	M. RESISTOR CH 1/10W 22K	1		R6010	ERJ3GEYJ560	M. RESISTOR CH 1/16W 56	1	
R4344	ERJ6RBD083	M. RESISTOR CH 1/10W 88K	1		R6011	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1	
R4345	ERJ6RBD223	M. RESISTOR CH 1/10W 22K	1		R6012	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R4347	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R6014	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1	
R4348, 49	ERJ6GEYJ681	M. RESISTOR CH 1/10W 680	2		R6015	ERJ3GEYJ220	M. RESISTOR CH 1/16W 22	1	
R4350	ERJ3GEYJ124	M. RESISTOR CH 1/16W 120K	1		R6016-18	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	3	
R4351	ERJ6RBD392	M. RESISTOR CH 1/10W 3.9K	1		R6018	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4352	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6024	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R4353	ERJ6RBD392	M. RESISTOR CH 1/10W 3.9K	1		R6025-28	ERJ3GEYJ000	M. RESISTOR CH 1/16W	4	
R4354, 55	ERJ6RBD223	M. RESISTOR CH 1/10W 22K	2		R6029	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1	
R4356	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6034, 35	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	2	
R4357	ERJ6RBD363	M. RESISTOR CH 1/10W 36K	1		R6036-38	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	3	
R4358	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6039	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4359	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6042	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	1	
R4360	ERJ6RBD363	M. RESISTOR CH 1/10W 36K	1		R6043	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	1	
R4361	ERDAS3G680	M. RESISTOR 3W 68	1		R6044	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	1	
R4362	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6045	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	1	
R4363	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1		R6046	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R4364	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6047	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1	
R4365	ERDAS3G680	M. RESISTOR 3W 68	1		R6048, 49	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	2	
R4366	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1		R6050	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1	
R4367	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6051	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R4368	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6052	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R4369	ERJ3RBD513	M. RESISTOR CH 3W 51K	1		R6053	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4370	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R6054, 55	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R4371	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6056, 57	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	2	
R4372	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R6058-61	ERJ3GEYJ000	M. RESISTOR CH 1/16W	4	
R4373	ERJ3RBD513	M. RESISTOR CH 3W 51K	1		R6063-65	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	3	
R4374	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	1		R6066	ERJ3GEYJ222	M. RESISTOR CH 1/16W 2.2K	1	
R4375	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6067	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1	
R4376	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	1		R6068, 69	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	2	
R4377	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6070	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	1	
R4378	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1		R6071	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R4380	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6072	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4381	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1		R6073	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R4382	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	1		R6074, 75	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	2	
R4384	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1		R6080	ERJ3GEYJ222	M. RESISTOR CH 1/16W 2.2K	1	
R4385	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	1		R6082	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4386	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6084, 85	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	2	
R4387	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6087	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4388	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1		R6089-91	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	3	
R4389	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6092	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1	
R4390	ERJ6RBD103	M. RESISTOR CH 1/10W 10K	1		R6093	ERJ3GEYJ560	M. RESISTOR CH 1/16W 56	1	
R4391	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1		R6095	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R4392	ERJ6GEYJ000	M. RESISTOR CH 1/10W	1		R6096	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1	
R4393	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1		R6097	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R4394	ERJ3GEYJ561	M. RESISTOR CH 1/16W 560	1		R6098	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4396	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	1		R6099	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R4397	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1		R6100	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1	
R4398	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6101	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R4401-03	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	3		R6102, 103	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	2	
R4405-07	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	3		R6104	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4701, 02	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	2		R6105	ERJ3GEYJ153	M. RESISTOR CH 1/16W 15K	1	
R4703	ERJ6GEYJ222	M. RESISTOR CH 1/10W 2.2K	1		R6107	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4704	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	1		R6108	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
R4705	ERJ6GEYJ222	M. RESISTOR CH 1/10W 2.2K	1		R7302	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R4706-09	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	4		R7305, 106	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2	
R4710	ERJ6GEYJ152	M. RESISTOR CH 1/10W 1.5K	1		R7318	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R4712-18	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	7		R7318	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1	
R4719	ERJ6GEYJ560	M. RESISTOR CH 1/10W	1		R7324	ERJ3GEYJ393	M. RESISTOR CH 1/16W 39K	1	
R4721	ERJ6GEYJ272	M. RESISTOR CH 1/10W 2.7K	1		R7325	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R4722	ERJ6GEYJ222	M. RESISTOR CH 1/10W 2.2K	1		R7326	ERJ3GEYJ393	M. RESISTOR CH 1/16W 39K	1	
R4723	ERJ6GEYJ473	M. RESISTOR CH 1/10W 47K	1		R7327	ERJ3GEYJ822	M. RESISTOR CH 1/16W 8.2K	1	
R4724	ERJ6GEYJ472	M. RESISTOR CH 1/10W 4.7K	1		R7328, 29	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	2	
R4726	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	1		R7601, 02	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2	
R4727	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1		R7603	ERJ6GEYJ102	M. RESISTOR CH 1/10W 1K	1	
R4728, 106	ERJ6GEYJ273	M. RESISTOR CH 1/10W 27K	1		R7604	ERJ6GEYJ000	M. RESISTOR CH 1/10W 0	1	
R4903, 04	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2		R7605, 06	ERQ2SJ331	M. RESISTOR 2W 330	2	
R4907, 08	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2		R7607, 08	ERJ6GEYJ683	M. RESISTOR CH 1/10W 68K	2	
R4911, 12	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2		R7609, 10	ERJ6GEYJ151	M. RESISTOR CH 1/10W 150	2	
R6001	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1		R7611	ERJ6GEYJ103	M. RESISTOR CH 1/10W 10K	1	
R6003	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1		R7612	ERJ6GEYJ561	M. RESISTOR CH 1/10W 560	1	
R6006	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1		R7613, 14	ERJ6GEYJ101	M. RESISTOR CH 1/10W 100	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R7522	ERJ6GEY6104	M.RESISTOR ■ 1/10W 100K	1		R30070-72	ERJ6GEY6101	M.RESISTOR CH 1/10W 100	3	
R7524	ERJ6GEY6182	M.RESISTOR CH 1/10W 1.8K	1		R30073	ERJ3GEYJ103	M.RESISTOR CH 1/10W 10K	1	
R7551	ERJ6GEYF473	M.RESISTOR ■ 1/10W 47K	1		R30074	VLF1315A102	FILTER	1	
R7553	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30075, 76	ERJ3GEYJ222	M.RESISTOR ■ 1/16W 2.2K	2	
R7936	ERJ6GEY6392	M.RESISTOR CH 1/10W 3.9K	1		R30077, 78	ERJ3GEYJ101	M.RESISTOR ■ 1/16W 100	2	
R7937	ERJ6GEYF472	M.RESISTOR CH 1/10W 4.7K	1		R30079	ERJ3GEYJ561	M.RESISTOR CH 1/16W 560	1	
R7938	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30080	ERJ3GEYJ334	M.RESISTOR CH 1/16W 330K	1	
R7939-41	ERJ6GEYJ471	M.RESISTOR CH 1/10W 470	3		R30081	ERJ6GEY6823	M.RESISTOR CH 1/10W 82K	1	
R7942, 43	ERJ6GEY6101	M.RESISTOR CH 1/10W 100	2		R30082	ERJ6RBD104	M.RESISTOR CH 1/10W 100K	1	
R7944	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30083	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1	
R7945	ERJ6GEYF472	M.RESISTOR CH 1/10W 4.7K	1		R30086	ERJ3GEYJ561	M.RESISTOR CH 1/16W 560	1	
R7946	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30087	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1	
R7947	ERJ6GEYF472	M.RESISTOR CH 1/10W 4.7K	1		R30088	ERJ3GEY6471	M.RESISTOR CH 1/16W 470	1	
R7948	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30089	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1	
R7950	ERJ6GEY6103	M.RESISTOR ■ 1/10W 10K	1		R30090	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	1	
R7953	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1		R30091, 92	ERJ3GEY6471	M.RESISTOR CH 1/16W 470	2	
R7954	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1		R30093	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1	
R30001	ERJ6GEY6562	M.RESISTOR ■ 1/10W 5.6K	1		R30094	ERJ6GEY6892	M.RESISTOR CH 1/10W ■ ■	1	
R30002	ERJ6GEY6223	M.RESISTOR ■ 1/10W 22K	1		R30095	ERJ6GEY6332	M.RESISTOR ■ 1/10W 3.3K	1	
R30003	ERJ6GEY6104	M.RESISTOR CH 1/10W 100K	1		R30097	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1	
R30004	ERJ6GEY6272	M.RESISTOR ■ 1/10W 2.7K	1		R30098	ERJ6GEY6221	M.RESISTOR ■ 1/10W 220	1	
R30005	ERJ3GEYJ391	M.RESISTOR CH 1/16W 390	1		R30099	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	1	
R30006	ERJ3GEY6114	M.RESISTOR CH 1/16W 110K	1		R30100	ERJ3GEYJ224	M.RESISTOR CH 1/16W 220K	1	
R30008	ERJ6GEY6223	M.RESISTOR CH 1/10W 22K	1		R30101	ERJ6GEY6104	M.RESISTOR CH 1/10W 100K	1	
R30009	ERJ6GEY6102	M.RESISTOR CH 1/10W 1K	1		R30102	ERJ6GEYJ225	M.RESISTOR CH 1/10W 2.2M	1	
R30010	ERJ6GEY6183	M.RESISTOR CH 1/10W 18K	1		R30103	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1	
R30011	ERJ3GEYJ123	M.RESISTOR CH 1/16W 12K	1		R30104	ERJ3GEY6472	M.RESISTOR CH 1/16W 4.7K	1	
R30012	ERJ6GEY6821	M.RESISTOR CH 1/10W 820	1		R30105-07	ERJ6GEYF472	M.RESISTOR CH 1/10W 4.7K	3	
R30013	ERJ6GEY6132	M.RESISTOR CH 1/10W 1.3K	1		R30108	ERJ6GEY6101	M.RESISTOR CH 1/10W 100	1	
R30014	ERJ6GEY6222	M.RESISTOR CH 1/10W 2.2K	1		R30111	VLF1315A102	FILTER	1	
R30017	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1		R30114, 15	ERJ6GEY6101	M.RESISTOR CH 1/10W 100	2	
R30018	ERJ3GEYJ181	M.RESISTOR CH 1/16W 180	1		R30119	VLF1315A102	FILTER	1	
R30019	ERJ3GEYJ561	M.RESISTOR CH 1/16W 560	1		R30120	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1	
R30020	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	1		R30123, 24	ERJ6GEY6332	M.RESISTOR CH 1/10W 3.3K	2	
R30021	ERJ3GEYJ271	M.RESISTOR CH 1/16W 270	1		R30126	ERJ6GEYOR00	M.RESISTOR CH 1/10W ■	1	
R30022	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1		R30127, 28	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	2	
R30023	ERJ3GEYJ112	M.RESISTOR CH 1/16W 1.1K	1		R30131-34	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	4	
R30024	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1		R30135, 36	VLP0147	COIL	2	
R30025	ERJ3GEYJ821	M.RESISTOR CH 1/16W 820	1		R30139, 40	VLP0147	COIL	2	
R30026	ERJ6GEY6102	M.RESISTOR CH 1/10W 1K	1		R30141	ERJ3GEY6682	M.RESISTOR CH 1/16W 6.8K	1	
R30027	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R30142	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R30028	ERJ6GEYF561	M.RESISTOR ■ 1/10W 560	1		R30143, 44	VLF1315A102	FILTER	2	
R30029	ERJ6GEYF333	M.RESISTOR CH 1/10W 33K	1		R30145	ERJ6GEY6104	M.RESISTOR CH 1/10W 100K	1	
R30030	ERJ3GEYJ241	M.RESISTOR ■ 1/16W 240	1		R30146	VLP0147	COIL	1	
R30031	ERJ6GEY6223	M.RESISTOR ■ 1/10W 22K	1		R30148	VLF1315A102	FILTER	1	
R30032	ERJ3GEYJ112	M.RESISTOR ■ 1/16W 1.1K	1		R30149	ERJ3GEYJ821	M.RESISTOR CH 1/16W 820	1	
R30033	ERJ6GEY6102	M.RESISTOR ■ 1/10W 1K	1		R30150, 51	ERJ6GEY6682	M.RESISTOR CH 1/10W 6.8K	2	
R30034	ERJ6GEY6821	M.RESISTOR ■ 1/10W 820	1		R30152	ERJ6GEY6103	M.RESISTOR ■ 1/10W 10K	1	
R30035, 36	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	■		R30153	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1	
R30037	ERJ3GEYJ112	M.RESISTOR CH 1/16W 1.1K	1		R30154	ERJ3GEYJ103	M.RESISTOR ■ 1/16W 10K	1	
R30038	ERJ3GEYJ333	M.RESISTOR ■ 1/16W 33K	1		R30155	ERJ6GEY6103	M.RESISTOR CH 1/10W 10K	1	
R30039	ERJ3GEYJ561	M.RESISTOR ■ 1/16W 560	1		R30156	ERJ6GEYF473	M.RESISTOR CH 1/10W 47K	1	
R30040	ERJ3GEYJ273	M.RESISTOR ■ 1/16W 27K	1		R30157	ERJ6GEYF472	M.RESISTOR CH 1/10W 4.7K	1	
R30041	ERJ6GEY6121	M.RESISTOR ■ 1/10W 120	1		R30158	ERJ6GEY6331	M.RESISTOR CH 1/10W 330	1	
R30042	ERJ3GEYJ101	M.RESISTOR ■ 1/16W 100	1		R30159	ERJ3GEYJ182	M.RESISTOR CH 1/16W 1.8K	1	
R30043	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1		R30160, 61	ERJ6GEY6101	M.RESISTOR CH 1/10W 100	2	
R30044	ERJ3GEY6822	M.RESISTOR CH 1/16W 8.2K	1		R30166	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1	
R30045	ERJ6GEYF123	M.RESISTOR CH 1/10W 12K	1		R30167	ERJ3GEY6472	M.RESISTOR CH 1/16W 4.7K	1	
R30046, 47	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	2		R30168	ERJ3GEYJ563	M.RESISTOR CH 1/16W 56K	1	
R30048	ERJ3GEYJ821	M.RESISTOR CH 1/16W 820	1		R30169	ERJ6GEY6331	M.RESISTOR CH 1/10W 330	1	
R30049	ERJ6GEYF473	M.RESISTOR CH 1/10W 47K	1		R30170	ERJ6GEY6821	M.RESISTOR CH 1/10W 820	1	
R30051	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1		R30171	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1	
R30052	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	1		R30172	ERJ6GEY6911	M.RESISTOR CH 1/10W 910	1	
R30053	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1		R30173	ERJ6GEYF333	M.RESISTOR CH 1/10W 33K	1	
R30054	ERJ3GEYJ391	M.RESISTOR ■ 1/16W 390	1		R30174	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	1	
R30055	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1		R30175	ERJ6GEY6223	M.RESISTOR CH 1/10W 22K	1	
R30056	ERJ3RBD153	M.RESISTOR CH 3W 15K	1		R30176	ERJ3GEYJ111	M.RESISTOR CH 1/16W 30K	1	
R30057	ERJ3GEYJ391	M.RESISTOR CH 1/16W 390	1		R30177	ERJ3GEYJ121	M.RESISTOR CH 1/16W 120	1	
R30058	ERJ6GEY6102	M.RESISTOR CH 1/10W 1K	1		R30178	ERJ3GEY6102	M.RESISTOR CH 1/16W 1K	1	
R30061	ERJ6GEY6102	M.RESISTOR CH 1/10W 1K	1		R30179	ERJ6GEY6104	M.RESISTOR CH 1/10W 100K	1	
R30064	ERJ6GEY6432	M.RESISTOR ■ 1/10W 4.3K	1		R30180	ERJ6GEY6153	M.RESISTOR CH 1/10W 15K	1	
R30065	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R30181	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	1	
R30066, 67	ERJ6GEY6102	M.RESISTOR CH 1/10W 1K	2		R30182, 83	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	2	
R30068	ERJ3GEYJ103	M.RESISTOR ■ 1/16W 10K	1		R30184	ERJ3GEYJ153	M.RESISTOR CH 1/16W 15K	1	
R30069	ERJ6GEYF561	M.RESISTOR CH 1/10W 560	1		R30185	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R30186	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		VR0701	EVNGBAA00B24	V. RESISTOR 20K	1	
R30187	ERJ6GEYG821	M. RESISTOR CH 1/10W 820	1		VR30001	EVN7JGA00B15	V. RESISTOR 100K	1	
R30188, 89	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	2		VR30002	EVMEGSA00B24	V. RESISTOR 20K	1	
R30190	VLF1315A102	FILTER	1		VR30003	EVN7JGA00B54	V. RESISTOR 50K	2	
R30195	ERJ6GEYG103	M. RESISTOR CH 1/10W 10K	1		W101, 02	ERJ3GEYOR00	M. RESISTOR 1/16W	0 2	
R30198	ERJ6GEYG101	M. RESISTOR CH 1/10W 100	1		W102	ERJ6GMZOR00	M. RESISTOR CH 1/10W	0 1	
R30197	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		W103	ERJ6GEYOR00	M. RESISTOR CH 1/10W	0 1	
R30198	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		W103	ERJ6GEYOR00	M. RESISTOR CH 1/8W	1 1	
R30199	ERJ3GEYJ154	M. RESISTOR CH 1/16W 150K	1		W104	ERJ6GEYOR00	M. RESISTOR CH 1/10W	1 1	
R30200	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		W104	ERJ6GEYOR00	M. RESISTOR CH 1/8W	1 1	
R30201	ERJ3GEYJ561	M. RESISTOR CH 1/16W 560	1		W105	ERJ6GEYOR00	M. RESISTOR CH 1/10W	1 1	
R30202	ERJ3GEYG102	M. RESISTOR 1/16W 1K	1		W105, 06	ERJ6GMZOR00	M. RESISTOR CH 1/10W	0 2	
R30203	ERJ6GEYG104	M. RESISTOR CH 1/10W 100K	1		W107	ERJ3GEYOR00	M. RESISTOR CH 1/16W	0 1	
R30204	ERJ6GEYG154	M. RESISTOR CH 1/10W 150K	1		W108	ERJ6GMZOR00	M. RESISTOR CH 1/10W	0 1	
R30205	ERJ6GEYJ471	M. RESISTOR CH 1/10W 470	1		W109	ERJ6GEYOR00	M. RESISTOR CH 1/8W	0 1	
R30206	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		W111	ERJ6GMZOR00	M. RESISTOR 1/10W	0 1	
R30207	ERJ3GEYJ154	M. RESISTOR CH 1/16W 150K	1		W112	ERJ6GEYOR00	M. RESISTOR CH 1/8W	0 1	
R30208	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		W113	ERJ3GEYOR00	M. RESISTOR CH 1/16W	0 1	
R30211	ERJ3GEYJ391	M. RESISTOR CH 1/16W 390	1		W114	ERJ6GEYOR00	M. RESISTOR CH 1/8W	1 1	
R30212	ERJ3GEYG471	M. RESISTOR CH 1/16W 470	1		W115, 16	ERJ3GEYOR00	M. RESISTOR CH 1/16W	1 2	
R30213	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1		X0701	VLF1418	FILTER	1	
R30216	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	1		X0702	VLF1290	FILTER	1	
R30217, 18	ERJ3GEYG471	M. RESISTOR CH 1/16W 470	2		X0703	EFC5SR5MW5	FILTER	1	
R30219	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1		X0704	VLF1313	FILTER	1	AG-DV2700B
R30220	ERJ6GEYG101	M. RESISTOR CH 1/10W 100	1		X0704	VLF1388	FILTER	1	AG-DV2700E
R30222	ERJ6GEYF561	M. RESISTOR CH 1/10W 560	1		X2001	VSX0847	CRYSTAL OSCILLATOR	1	
R30223	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		X2002	VSX0872	CRYSTAL OSCILLATOR	1	
R30224	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		X2201	VSX0830	CRYSTAL OSCILLATOR	1	
R30225	ERJ3GEYJ154	M. RESISTOR CH 1/16W 150K	1		X2202	VSX0860	CRYSTAL OSCILLATOR	1	
R30226	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		X2203	EFOEG7374A4	CRYSTAL OSCILLATOR	1	
R30227	ERJ3GEYJ473	M. RESISTOR 1/16W 47K	1		X3001	VSX0848	CRYSTAL OSCILLATOR	1	
R30228	ERJ6GEYG821	M. RESISTOR 1/10W 820	1		X3003	VSX0846	CRYSTAL OSCILLATOR	1	
R30229	ERJ3GEYJ474	M. RESISTOR CH 1/16W 470K	1		X3004	VSX0832	CRYSTAL OSCILLATOR	1	
R30230	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		X4701	VSX0834	CRYSTAL OSCILLATOR	1	
R30231	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1		X6001	VSX0847	CRYSTAL OSCILLATOR	1	
R30232	ERJ6GEYF333	M. RESISTOR CH 1/10W 33K	1		X7902	VSX0953	CRYSTAL OSCILLATOR	1	
R30233	ERJ6GEYG223	M. RESISTOR CH 1/10W 22K	1		X7902	EFOEC4004A4	CRYSTAL OSCILLATOR	1	
R30234	ERJ6GEYG331	M. RESISTOR CH 1/10W 330	1		X30001	VSX1030	CRYSTAL OSCILLATOR	1	
R30235	ERJ6GEYG101	M. RESISTOR CH 1/10W 100	1		X30002	VSX0574	CRYSTAL OSCILLATOR	1	
R30236	ERJ6GEYG121	M. RESISTOR CH 1/10W 120	1		X30003	VSX0830	CRYSTAL OSCILLATOR	1	
R30237	ERJ3GEYG472	M. RESISTOR CH 1/16W 4.7K	1		X30004	VSX0866	CRYSTAL OSCILLATOR	1	
R30238	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1		X30005	VSX0842	CRYSTAL OSCILLATOR	1	
R30239, 40	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	2		ZA3001-03	XTV3+6J	SCREW	3	
R30241, 42	VLF1315A102	FILTER	2		ZA3004	VSC4689	SHIELD CASE (B)	1	
R30243	ERJ6GEYG183	M. RESISTOR CH 1/10W 18K	1		ZA3005	VSC4690	SHIELD CASE (T)	1	
R30244	ERJ3GEYJ103	M. RESISTOR 1/16W 10K	1		ZA3901	VEJ1819	IN/OUT JACK	1	
R30245	ERJ3GEYOR00	M. RESISTOR CH 1/10W 0	1		ZA3902-05	XTV3+80FZ	SCREW	4	
R30246	ERJ6GEYF472	M. RESISTOR 1/10W 4.7K	1		ZA30001-0	XTV3+6J	SCREW	3	
R30247	VLF1315A102	FILTER	1		ZA30004	VSC4689	SHIELD CASE (B)	1	
R30248, 49	VLP0147	ODIL	2		ZA30005	VSC4690	SHIELD CASE (T)	1	
R30250	ERJ3GEYB471	M. RESISTOR 1/16W 470	1		ZB0801	VJH1041	REAR JACK BOARD	1	
R30251	ERJ6GEYB332	M. RESISTOR 1/10W 3.3K	1		ZB2501	VJF0442	MINI CLAMPER	1	
R30252	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1		ZB4001, 02	VMP4985	GARD CORNER HOLDER	2	
R30253	ERJ6GEYJ112	M. RESISTOR 1/10W 1.1K	1		ZB6701, 02	VMP4985	GARD CORNER HOLDER	2	
R30254	ERJ6GEYB102	M. RESISTOR CH 1/10W 1K	1				MISCELLANEOUS		
S3801	VSS0513	SWITCH	1			VEEC098	CABLE	1	P1102-P1101
T0703	EQV5EC071A	TRANSFORMER	1			VSC4753	SHIELD CASE (LOWER)	1	
T0704	EQV5EC072A	TRANSFORMER	1			VSC4752	SHIELD CASE (MIDDLE)	1	
T0711	EQS5EC032A	TRANSFORMER	1			VWJ1195	FLAT CARD CABLE	1	P7502-P7901
TP2201	VJR0098	TEST POINT	1			VWJ1196	FLAT CARD CABLE	1	P7501-P7902
TP3002	VJR0098	TEST POINT	1			VWJ1197	FLAT CARD CABLE	1	PS4851-P6081
TP3021	VJR0098	TEST POINT	1			VWJ1248	FLAT CARD CABLE	1	P4801-P4001
TP3030-32	VJR0098	TEST POINT	3						
TP3701, 02	VJR0098	TEST POINT	2						
TP3901	VJR0098	TEST POINT	1						
TP30001-0	VJR0108	TEST POINT	5						
TP30007-1	VJR0108	TEST POINT	8						
TU7801	VEK8433	RF BOARD	1						
VC30001	ECRJA020E11	TRIMMER 20P	1						
VC30002	ECRJA050W11	E. CAPACITOR 10U	2						

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
	VEP05351A	HEAD AMP C.B.A.	1	(RTL)	C2704	EEVHB1H2R2	E. CAPACITOR 50V 2.2U	1	
C5001-04	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	4		C2705	ECUX1C473KBV	C. CAPACITOR CH 18V 0.047U	1	
C5007	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2708	ECUX1C474KBN	C. CAPACITOR CH 18V 0.47U	1	
C5010	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2707	ECUX1A104KBV	C. CAPACITOR CH 10V 0.1U	1	
C5013	ECUX1H152KBV	C. CAPACITOR CH 50V 1500P	1		C2708	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
C5014	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C2709	EEVHB1C100	E. CAPACITOR 16V 10U	1	
C5015	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2710, 11	EEVHB1H2R2	E. CAPACITOR 50V 2.2U	2	
C5018	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1		C2712, 13	ECUX1C473KBV	C. CAPACITOR CH 18V 0.047U	2	
C5017	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2714, 15	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	2	
C5018	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1		C2718-18	ECUX1C333KBV	C. CAPACITOR CH 18V 0.033U	3	
C5019	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2719	ECUX1C104KBV	C. CAPACITOR CH 18V 0.1U	1	
C5020, 21	ECST1AY106Z	T. CAPACITOR CH 10V 10U	2		C2720-22	ECUX1H472KBV	C. CAPACITOR CH 50V 4700P	3	
C5022	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1		C2723	EEVHB1A330	E. CAPACITOR 10V 33U	1	
C5023, 24	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	2		C2724	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1	
C5025	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1		C2725	EEVHB1H2R2	E. CAPACITOR 50V 2.2U	1	
C5026	ECUX1H152KBV	C. CAPACITOR CH 50V 1500P	1		C2726	ECUX1C473KBV	C. CAPACITOR CH 18V 0.047U	1	
C5027	ECUX1H330JCV	C. CAPACITOR CH 50V 33P	1		C2727	ECUX1C474KBN	C. CAPACITOR CH 18V 0.47U	1	
C5028	ECUX1H122KBV	C. CAPACITOR CH 50V 1200P	1		C2728	ECUX1A104KBV	C. CAPACITOR CH 10V 0.1U	1	
C5028	ECUX1A105ZV	C. CAPACITOR CH 10V 1U	1		C2729	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
C5030	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		C2730	EEVHB1C100	E. CAPACITOR 16V 10U	1	
C5031	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2731, 32	EEVHB1H2R2	E. CAPACITOR 50V 2.2U	2	
C5032	ECUX1H470JCV	C. CAPACITOR CH 50V 47P	1		C2733, 34	ECUX1C473KBV	C. CAPACITOR CH 18V 0.047U	2	
C5033	ECUX1H881JCV	C. CAPACITOR CH 50V 880P	1		C2735, 36	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	2	
C5034	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2737-39	ECUX1C333KBV	C. CAPACITOR CH 18V 0.033U	3	
C5035	ECST1AY106Z	T. CAPACITOR CH 10V 10U	1		C2740	ECUX1C104KBV	C. CAPACITOR CH 18V 0.1U	1	
C5036, 37	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	2		C2741-43	ECUX1H472KBV	C. CAPACITOR CH 50V 4700P	3	
C5038	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2745	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
C5047	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1		C2747	ECUX1C474ZFN	C. CAPACITOR CH 18V 0.47U	1	
C5051	ECUX1H103ZV	C. CAPACITOR 50V 0.01U	1		C2748	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
					C2749	ECUX1H332KBV	C. CAPACITOR CH 50V 3300P	1	
FP5001	VJS3319B008	CONNECTOR (FEMALE)	1		C2751	ECUX1C474ZFN	C. CAPACITOR CH 18V 0.47U	1	
FP5002	VJS3251	CONNECTOR (FEMALE)	1		C2752	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
IC5001	AN3731FH0	IC	1		C2753	EEVHB1C100	E. CAPACITOR 16V 10U	1	
L5002, 03	VL00163K220	COIL 22UH	2		C2754	ECUX1H471JCV	C. CAPACITOR CH 50V 470P	1	
L5005-07	ELJPA100KF	COIL 10UH	3		C2755	EEVHB1C100	E. CAPACITOR 16V 10U	1	
					C2757	ECUX1C105ZFN	C. CAPACITOR CH 18V 1U	1	
Q5002, 03	2SC3937	TRANSISTOR	2		C2758, 59	ECUX1H103ZV	C. CAPACITOR 50V 0.01U	2	
Q5005, 06	2SD1938F	TRANSISTOR	2		C2760	EEVHB1C100	E. CAPACITOR 16V 10U	1	
					C2762	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
R5002	ERJ3GEY6471	M. RESISTOR CH 1/16W 470	1		C2763	ECUX1C105ZFN	C. CAPACITOR CH 18V 1U	1	
R5003	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		C2764	ECUX0J225KBN	C. CAPACITOR CH6.3V 2.2U	1	
R5004	ERJ3GEY6152	M. RESISTOR CH 1/16W 1.5K	1		C2766	ECUX1E223KBV	C. CAPACITOR CH 25V 0.023U	1	
R5005	ERJ3GEY6102	M. RESISTOR CH 1/16W 1K	1		C2767	ECUX1C473KBV	C. CAPACITOR CH 18V 0.047U	1	
R5010	ERJ3GEYJ680	M. RESISTOR CH 1/16W 68	1		C2768	EEVHB1E4R7	E. CAPACITOR 25V 4.7U	1	
R5012	ERJ3GEY6152	M. RESISTOR CH 1/16W 1.5K	1		C2769-71	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	3	
R5013	ERJ3GEYJ123	M. RESISTOR CH 1/16W 12K	1		C2772-77	ECUX1C104KBV	C. CAPACITOR CH 18V 0.1U	6	
R5014, 15	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	2		C2778-80	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	3	
R5016, 17	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	2		C2781, 82	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	2	
R5018	ERJ3GEYJ680	M. RESISTOR CH 1/16W 68	1		C2783	EEVHB1C100	E. CAPACITOR 16V 10U	1	
R5019	ERJ3GEYJ123	M. RESISTOR CH 1/16W 12K	1		C2784-87	ECUX1H103KBV	C. CAPACITOR CH 50V 0.01U	4	
R5020	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1		C2788	EEVHB1C470	E. CAPACITOR 16V 47U	1	
R5021	ERJ3GEYJ100	M. RESISTOR CH 1/16W 10	1		C2789, 90	ECUX1H562KBV	C. CAPACITOR CH 50V 5600P	2	
R5024	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		C2791	EEVHB1C470	E. CAPACITOR 16V 47U	1	
R5025	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	1		C2792	EEVHB1C100	E. CAPACITOR 16V 10U	1	
R5026	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		C2793	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
R5028	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1		C2794	ECUX0J225KBN	C. CAPACITOR CH6.3V 2.2U	1	
R5029-32	ERJ3GEYOR00	M. RESISTOR CH 1/16W	4		C2795	ECUX1H332KBV	C. CAPACITOR CH 50V 3300P	1	
R5040, 41	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	2		C2796	ECUX1H562KBV	C. CAPACITOR CH 50V 5600P	1	
					C2797	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
					C2798	ECUX1H562KBV	C. CAPACITOR CH 50V 5600P	1	
					C2799, 00	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	2	
					C2801, 02	EEVNP1HR47	E. CAPACITOR 50V 47U	2	
					C2803	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	1	
					C2807, 08	EEVHB1C100	E. CAPACITOR 16V 10U	2	
					C2809	EEVHB0J330	E. CAPACITOR 6.3V 33U	1	
					C2810	ECUX1C104KBV	C. CAPACITOR CH 18V 0.1U	1	
					C2811	EEVHB0J330	E. CAPACITOR 6.3V 33U	1	
					C8301-08	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	8	
					C8307	EEVHB1C470	E. CAPACITOR 16V 47U	1	
					C8308-13	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	6	
					C8314-16	ECUX1C104KBV	C. CAPACITOR CH 18V 0.1U	3	
					C8317	EEVHB1C470	E. CAPACITOR 16V 47U	1	
					C8318-27	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	10	
					C8328	EEVHB1C470	E. CAPACITOR 16V 47U	1	
					C8501	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1	
C2701, 02	ECUX1H103ZV	C. CAPACITOR CH 50V 0.01U	2						
C2703	ECUM1C104ZFN	C. CAPACITOR CH 18V 0.1U	1						

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C6502	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		IC6514	ON1114.VT	IC	1	
C6504	EEVHB1C470	E. CAPACITOR 16V 47U	1						
C6505	ECUX1C224ZFV	C. CAPACITOR CH 16V 0.22U	1		K2701.02	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2	
C6506	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1						
C6507	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		L2701.02	VLQ0589J880	COIL 68UH	2	
C6509	EEVHB1C470	E. CAPACITOR 16V 47U	1						
C6510	ECUX1C224ZFV	C. CAPACITOR CH 16V 0.22U	1		LB2702	VLP0145	COIL	1	
C6511, 12	EEVHB1H3R3	E. CAPACITOR 50V 3.3U	2						
C6513	EEVHB1C100	E. CAPACITOR 16V 10U	1		P2701.02	VJS3813B017	CONNECTOR (FEMALE)	2	
C6515	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	1		P2703	VJS3319B009	CONNECTOR (FEMALE)	1	
C6516-18	ECUX1H103ZFV	C. CAPACITOR 50V 0.01U	3		P2704	VJS3408B019	CONNECTOR (FEMALE)	1	
C6519	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		P2705	VJP1929T	CONNECTOR (MALE)	1	
C6520	EEVHB1H3R3	E. CAPACITOR 50V 3.3U	1		P8301.02	VJP3518B002	CONNECTOR (MALE)	2	
C6522	EEVHB1C100	E. CAPACITOR 16V 10U	1		P8303	VJP3518B003	CONNECTOR (MALE)	1	
C6523-26	ECUM1C104ZFN	C. CAPACITOR 16V 0.1U	4		P6501	VJP3518B002	CONNECTOR (MALE)	1	
C6527	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1		P6502	VJP4044A002	CONNECTOR (MALE)	1	
C6529	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		P6503	VJP31720002	CONNECTOR (MALE)	1	
C6530	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		P6504	VJS3537B026	CONNECTOR (FEMALE)	1	
C6531	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		P6505	VJS3537B032	CONNECTOR (FEMALE)	1	
C6532	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1		P6506	VJP31258002	CONNECTOR (MALE)	1	
C6534	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1		P6507	VJP31720002	CONNECTOR (MALE)	1	
C6536	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		P6508	VJP31720004	CONNECTOR (MALE)	1	
C6537	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		P6509	VJS2958B008	CONNECTOR (FEMALE)	1	
C6538	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1		P6510	VJP31720002	CONNECTOR (MALE)	1	
C6539	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1		P6514	VJP31720004	CONNECTOR (MALE)	1	
C6541	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		P6520	VJP31720003	CONNECTOR (MALE)	1	
C6542, 43	EEVHB1H3R3	E. CAPACITOR 50V 3.3U	2						
C6544-47	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4		Q2701	2SD1328	TRANSISTOR	1	
C6552-55	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	4		Q2703.04	MSD601-R	TRANSISTOR	2	
C6556, 57	EEVHB1C470	E. CAPACITOR 16V 47U	2		Q6301	MSD601-R	TRANSISTOR	1	
C6558	ECUM1C104ZFN	C. CAPACITOR CH 16V 0.1U	1		Q6302	2SB1073	TRANSISTOR	1	
C6559	EEVHB1C100	E. CAPACITOR 16V 10U	1		Q6303	MSD601-R	TRANSISTOR	1	
C6565, ■	EEVHB0J220	E. CAPACITOR 0.3V 22U	2		Q6304	2SB1073	TRANSISTOR	1	
					Q6305	MSD601-R	TRANSISTOR	1	
D2713-16	MA856	DIODE	4		Q6306	2SB1073	TRANSISTOR	1	
D2717	MA8056-M	DIODE	1		Q6307	2SB1073-R	TRANSISTOR	1	
D6301	MA4051-L	DIODE	1		Q6308	MSD601-R	TRANSISTOR	1	
D8302-09	AK04	DIODE	■		Q6502	2SB709A	TRANSISTOR	1	
D8310	MA142HK	DIODE	1		Q6503	2SB1073	TRANSISTOR	1	
D8311	MA4043L	DIODE	1		Q6504	2SB710	TRANSISTOR	1	
D8312-15	AK04	DIODE	4		Q6505	2SB1073	TRANSISTOR	1	
D8316	MA142HK	DIODE	1						
D8317	MA4043L	DIODE	1		QR8301-03	XN1112	TRANSISTOR-RESISTOR	3	
D8318-34	MA142HK	DIODE	17		QR8304.05	MUN2213	TRANSISTOR-RESISTOR	2	
D6501	AK04	DIODE	1		QR8306-08	XN1213	TRANSISTOR-RESISTOR	4	
D6502, 03	MA721	DIODE	2		QR8314-16	MUN2213	TRANSISTOR-RESISTOR	3	
D6511	MA721HK	DIODE	1		QR6317	UN221D	TRANSISTOR	1	
D6512	MA8082-H	DIODE	1		QR8318	XN4213	TRANSISTOR-RESISTOR	1	
D6513	MA8039-H	DIODE	1		QR6502	MUN2213	TRANSISTOR-RESISTOR	1	
					QR6503	MUN2212	TRANSISTOR-RESISTOR	1	
IC2701	NJM2903M	IC	1		QR6504	UN2211	TRANSISTOR-RESISTOR	1	
IC2702	UPC4558G2	IC	1		QR6508	XN1212	TRANSISTOR-RESISTOR	1	
IC2703.04	AN3834K	IC	2		QR6511	MUN2113	TRANSISTOR-RESISTOR	1	
IC2705	UPC4558G2	IC	1		QR6514	MUN2113	TRANSISTOR-RESISTOR	1	
IC2706	NJM2903M	IC	1		QR6515	MUN2213	TRANSISTOR-RESISTOR	1	
IC2707	NJM2904M	IC	1		QR6517	MUN2213	TRANSISTOR-RESISTOR	1	
IC2708	TB6519F	IC	1						
IC2709	PU3210	TRANSISTOR	1		R2701	ERJ3RBD273	M. RESISTOR CH 3W 27K	1	
IC2710	PU3110	TRANSISTOR	1		R2703.04	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	2	
IC2711	PU3210	TRANSISTOR	1		R2705	ERJ3GEY6152	M. RESISTOR CH 1/16W 1.5K	1	
IC2712	PU3110	TRANSISTOR	1		R2706	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1	
IC2714	NJM2903M	IC	1		R2707	ERJ3GEYJ331	M. RESISTOR CH 1/10W 330	1	
IC2715	NJM2904M	IC	1		R2710	ERJ3RBD473	M. RESISTOR CH 3W 47K	1	
IC8301-03	BA6219BFP-Y	IC	3		R2711	ERJ3RBD823	M. RESISTOR CH 3W 82K	1	
IC8304	UPD4538B6	IC	1		R2712	ERJ3RBD153	M. RESISTOR CH 3W 15K	1	
IC8305	NJM2903M	IC	1		R2713	ERJ3GEYJ330	M. RESISTOR 1/16W 33	1	
IC8306	UPD4538B6	IC	1		R2714.15	ERJ3GEYJ271	M. RESISTOR CH 1/16W 270	2	
IC6501.02	BA6887-V3	IC	2		R2716	ERJ14YJ330	M. RESISTOR 1/4W 33	1	
IC6503	NJM2904M	IC	1		R2717	ERJ14YK2R2	M. RESISTOR CH 1/4W 2.2	1	
IC6504.05	UPC4558G2	IC	2		R2718	ERJ3GEY6472	M. RESISTOR CH 1/16W 4.7K	1	
IC6506-08	NJM2903M	IC	3		R2719	ERJ3GEY6393	M. RESISTOR 1/16W 39K	1	
IC6509, 10	NJM2904M	IC	2		R2720-22	ERJ14YJ330	M. RESISTOR CH 1/4W 33	3	
IC6511	UPC4558G2	IC	1		R2723	ERJ14YK2R2	M. RESISTOR CH 1/4W 2.2	1	
IC6512	MA8010GP	IC	1		R2724	ERJ3GEY6472	M. RESISTOR CH 1/16W 4.7K	1	
IC6513	UPC4558G2	IC	1		R2725	ERJ3GEY6393	M. RESISTOR CH 1/16W 39K	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R2726, 27	ERJ14YJ330	M. RESISTOR CH 1/4W 33	2		R6311	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2728, 29	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2		R6312, 13	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R2730	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6314	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2731	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1		R6315	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2732	ERJ3GEYJ153	M. RESISTOR CH 1/16W 15K	1		R6318, 17	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	2	
R2733	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6318	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2734	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1		R6319	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2735	ERJ3GEYJ153	M. RESISTOR CH 1/16W 15K	1		R6320	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R2736	ERJ3GEYJ122	M. RESISTOR CH 1/16W 1.2K	1		R6321	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2737	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1		R6322, 23	ERJ3GEYJ394	M. RESISTOR CH 1/16W 390K	2	
R2738	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1		R6324-29	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	6	
R2739	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6330	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2740	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1		R6331, 32	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	2	
R2741	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1		R6333	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2742	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1		R6334	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R2743	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1		R6335	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2744	ERJ3GEYJ222	M. RESISTOR CH 1/16W 2.2K	1		R6336	ERJ3GEYJ222	M. RESISTOR CH 1/16W 2.2K	1	
R2745	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6337	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2747	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6338	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1	
R2748	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1		R6339	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R2749	ERJ3GEYJ562	M. RESISTOR CH 1/16W 5.6K	1		R6340	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2750	ERJ3GEYJ561	M. RESISTOR CH 1/16W 560	1		R6341	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R2751	ERJ3GEYJ333	M. RESISTOR CH 1/16W 0.33	1		R6342	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1	
R2752	ERJ3GEYJ47	M. RESISTOR CH 1/16W 0.47	1		R6343	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	1	
R2753	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6344	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2754-58	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	3		R6345	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R2757	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6346	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R2758	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6347-49	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	3	
R2760	ERJ3GEYJ471	M. RESISTOR CH 1/16W 470	1		R6501	ERJ3RBD123	M. RESISTOR CH 3W 12K	1	
R2761	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6502	ERJ3GEYJ332	M. RESISTOR CH 1/16W 3.3K	1	
R2762	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	1		R6503	ERJ3GEYJ154	M. RESISTOR CH 1/16W 150K	1	
R2763	ERJ3GEYJ823	M. RESISTOR CH 1/16W 82K	1		R6504	ERJ3GEYJ393	M. RESISTOR CH 1/16W 39K	1	
R2764	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	1		R6505	ERJ14YJ101	M. RESISTOR CH 1/4W 100	1	
R2765	ERJ3GEYJ471	M. RESISTOR CH 1/16W 470	1		R6506	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R2766	ERJ3GEYJ382	M. RESISTOR CH 1/16W 3.8K	1		R6507	ERJ3GEYJ334	M. RESISTOR CH 1/16W 330K	1	
R2768	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R6508	ERJ3GEYJ122	M. RESISTOR CH 1/16W 1.2K	1	
R2769	ERJ3RBD153	M. RESISTOR CH 3W 15K	1		R6509	ERJ3RBD332	M. RESISTOR CH 3W 3.3K	1	
R2770	ERJ3RBD823	M. RESISTOR CH 3W 82K	1		R6510	ERJ3RBD153	M. RESISTOR CH 3W 15K	1	
R2771	ERJ3RBD473	M. RESISTOR CH 3W 47K	1		R6511	ERJ3GEYJ181	M. RESISTOR CH 1/16W 180	1	
R2772	ERJ3RBD102	M. RESISTOR CH 3W 1K	1		R6512	ERJ3RBD153	M. RESISTOR CH 3W 15K	1	
R2773, 74	ERJ14YK2R2	M. RESISTOR CH 1/4W 2.2	2		R6513	ERJ3RBD113	M. RESISTOR CH 3W 11K	1	
R2775	ERJ3RBD273	M. RESISTOR CH 3W 27K	1		R6514	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2777	ERJ3GEYJ823	M. RESISTOR CH 1/16W 82K	1		R6515	ERJ14YK3R9	M. RESISTOR CH 1/4W 3.9	1	
R2778	ERJ3GEYJ6912	M. RESISTOR CH 1/16W 9.1K	1		R6518-18	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	3	
R2779	ERJ3GEYJ334	M. RESISTOR CH 1/16W 330K	1		R6519	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	1	
R2780, 81	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2		R6520	ERJ3GEYJ823	M. RESISTOR CH 1/16W 82K	1	
R2782	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6521	ERJ3GEYJ272	M. RESISTOR CH 1/16W 2.7K	1	
R2783	ERJ3GEYJ6883	M. RESISTOR CH 1/16W 68K	1		R6524	ERJ14YK5R8	M. RESISTOR CH 1/4W 5.8	1	
R2784	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6525-27	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	3	
R2786	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1		R6529	ERJ3GEYJ000	M. RESISTOR CH 1/16W 0	1	
R2787	ERJ3GEYJ393	M. RESISTOR CH 1/16W 39K	1		R6530	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2788	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R6532	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2789	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R6533, 34	ERJ3RBD184	M. RESISTOR CH 3W 180K	2	
R2790	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6535	ERJ3GEYJ123	M. RESISTOR CH 1/16W 12K	1	
R2791	ERJ3GEYJ152	M. RESISTOR CH 1/16W 1.5K	1		R6536	ERJ3GEYJ363	M. RESISTOR CH 3W 36K	1	
R2792	ERJ3GEYJ393	M. RESISTOR CH 1/16W 39K	1		R6537, 38	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	2	
R2793	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1		R6541	ERJ3GEYJ682	M. RESISTOR CH 1/16W 6.8K	1	
R2794	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1		R6542	ERJ3RBD103	M. RESISTOR CH 3W 10K	1	
R2795	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6543	ERJ3RBD392	M. RESISTOR CH 3W 3.9K	1	
R2796	ERJ3RBD823	M. RESISTOR CH 3W 82K	1		R6544	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1	
R2798	ERJ3RBD102	M. RESISTOR CH 3W 1K	1		R6545	ERJ3RBD104	M. RESISTOR CH 3W 100K	1	
R2799	ERJ3GEYJ154	M. RESISTOR CH 1/16W 150K	1		R6546	ERJ3RBD103	M. RESISTOR CH 3W 10K	1	
R2800	ERJ3RQJR27	M. RESISTOR CH 1/8W 0.27	1		R6547	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2801, 02	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	2		R6548	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1	
R2803	ERJ3GEYJ102	M. RESISTOR CH 1/16W 1K	1		R6549	ERJ3GEYJ122	M. RESISTOR CH 1/16W 1.2K	1	
R2804	ERJ3GEYJ122	M. RESISTOR CH 1/16W 1.2K	1		R6550	ERJ3GEYJ682	M. RESISTOR CH 1/16W 6.8K	1	
R2805	ERJ3GEYJ000	M. RESISTOR CH 1/16W	1		R6551	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R2808	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	1		R6552	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1	
R2807	ERJ3GEYJ563	M. RESISTOR CH 1/16W 56K	1		R6553, 54	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R2808	ERJ3GEYJ472	M. RESISTOR CH 1/16W 4.7K	1		R6555	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1	
R6301	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1		R6558, 57	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R6302	ERJ14YJ561	M. RESISTOR CH 1/4W 560	1		R6558	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1	
R6303-07	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	5		R6559, 60	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	
R6308	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1		R6561	ERJ3GEYJ184	M. RESISTOR CH 1/16W 180K	1	
R6309, 10	ERJ3GEYJ224	M. RESISTOR CH 1/16W 220K	2		R6562, 61	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R6584	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1	
R6585	ERJ3GEYR000	M.RESISTOR CH 1/16W 0	1	
R6586	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1K	1	
R6587	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6588	ERJ3GEYR000	M.RESISTOR CH 1/16W 0	1	
R6589	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6590	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1	
R6591	ERJ3GEYR000	M.RESISTOR CH 1/16W 0	1	
R6592	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1	
R6593	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6594	ERJ3GEYR000	M.RESISTOR CH 1/16W 0	1	
R6595	ERJ3RB01B2	M.RESISTOR CH 3W 1.8K	1	
R6596-77	ERJ3RB0223	M.RESISTOR CH 3W 22K	2	
R6597-80	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	3	
R6598-86	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	6	
R6599-89	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	3	
R6600	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6601	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6602	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6603-94	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	2	
R6604	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6605	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6606	ERJ3GEYJ122	M.RESISTOR CH 1/16W 1.2K	1	
R6607	ERJ3GEYJ6332	M.RESISTOR CH 1/16W 3.3K	1	
R6608	ERJ3GEYJ6682	M.RESISTOR CH 1/16W 8.8K	1	
R6609	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1	
R6610	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1	
R6611	ERJ14YK3R3	M.RESISTOR CH 1/4W 3.3	1	
R6612-04	ERJ14YK5R0	M.RESISTOR CH 1/4W 5.6	2	
R6613	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1	
R6614-13	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	3	
R6615	ERJ3GEYR000	M.RESISTOR CH 1/16W 0	1	
R6616-17	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	3	
R6618	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1	
S6501	VSP1054	SWITCH	1	
S6502	VSP1055	SWITCH	1	
S6503	VSP1054	SWITCH	1	
S6504	VSS0512	SWITCH	1	
TP2701-04	VJR0008	TEST POINT	4	
TP6501-05	VJR0008	TEST POINT	5	
VR2701, 02	EVMCSA00B12	V.RESISTOR	100	2
VR6501	EVMCSA00B24	V.RESISTOR	20K	1
VR6502	EVMCSA00B54	V.RESISTOR	50K	1
		MISCELLANEOUS		
	VRJ28HW080MM	FLAT CARD CABLE	1	
	VRJ32HW080MM	FLAT CARD CABLE	1	
■ VEPO7977A	TIMER C.B.A.		1 (RTL)	
G7501	ECUM1H103ZFV	C.CAPACITOR ■ 50V 0.01U	1	
G7502	ECEAIHKSI00	E.CAPACITOR 50V 10U	1	
G7503-09	ECUM1H101JCN	C.CAPACITOR CH 50V 100P	2	
G7510	ECUM1H220JCN	C.CAPACITOR CH 50V 22P	1	
G7512	ECEAIHKSI2R2	E.CAPACITOR 50V 2.2U	1	
G7513, 14	ECUM1H104ZFN	C.CAPACITOR ■ 50V 0.1U	2	
G7515	ECEAOJKS101	E.CAPACITOR 6.3V 100U	1	
G7516, 17	ECUM1H103ZFV	C.CAPACITOR CH 50V 0.01U	2	
G7518, 19	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	2	
G7520, 21	ECUMIE473ZFV	C.CAPACITOR ■ 25V 0.047U	2	
G7522	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	1	
G7523	ECEAOJKS220	E.CAPACITOR 8.3V 22U	1	
G7524	ECUX1H223KBN	C.CAPACITOR CH 50V 0.22U	1	
G7525, 28	ECEAIKES4R7	■ CAPACITOR 25V 4.7U	2	
G7527	ECEAIKSI00	E.CAPACITOR 16V 10U	1	
G7528	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	1	
D7501	MA4220	DIODE	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
D7502	MA165	DIODE	1	
D7503-08	LN28RCPPU	DIODE	8	
D7509, 10	LN316CPHLMU	LED	2	
D7511, 12	LN376GCPXUY	DIODE	2	
D7513, 14	LN48YCPL	DIODE	2	
D7515, 16	LN28RCPPU	DIODE	2	
D7517	MA165	DIODE	1	
D7518	MA4056-H	DIODE	1	
DP7501	VSL0512	DISPLAY	1	
IC7501	M35500AFP	IC	1	
IC7502	S80743AL	IC	1	
IC7503	M68010GP	IC	1	
IC7504	BA6810F	IC	1	
IC7505	RN5RZ38BA	IC	1	
L7501	VLQ0589J220	COIL 22UH	1	
LB7501-04	VLP0147	COIL	4	
P7501	VJS3537B017	CONNECTOR (FEMALE)	1	
P7502	VJS3537B019	CONNECTOR (FEMALE)	1	
P7503	VJP1231T	CONNECTOR (MALE) 4P	1	
P7503	VJS1231T	CONNECTOR (FEMALE)	1	
P7504	VJS2183	CONNECTOR (FEMALE)	1	
P7601	VJS1231T	CONNECTOR (FEMALE)	1	
QR7501-16	MUN2112	TRANSISTOR-RESISTOR	16	
QR7517-18	MUN2111	TRANSISTOR-RESISTOR	3	
QR7520-23	UM211F	TRANSISTOR-RESISTOR	4	
R7501, 02	ERDS2T0	O.RESISTOR 1/4W 0	2	
R7503, 04	ERDS2TJ132	O.RESISTOR 1/4W 1.3K	2	
R7505	ERJ8GEYG101	M.RESISTOR CH 1/10W 100	1	
R7506	ERJ8GEYR000	M.RESISTOR CH 1/10W 0	1	
R7507	ERJ8GEYG104	M.RESISTOR CH 1/10W 100K	1	
R7510	ERJ8GEYG432	M.RESISTOR CH 1/10W 4.3K	1	
R7511-16	ERJ8GEYG303	M.RESISTOR CH 1/10W 30K	6	
R7520-24	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	5	
R7526	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	1	
R7528	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	1	
R7539-41	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	3	
R7542	ERJ8GEYR000	M.RESISTOR CH 1/10W	1	
R7543-46	ERJ8GEYG103	M.RESISTOR CH 1/10W 10K	4	
R7555-62	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	8	
R7583	ERJ8GEYG272	M.RESISTOR CH 1/10W 2.7K	1	
R7584, 65	ERJ8GEYF473	M.RESISTOR CH 1/10W 47K	2	
R7586	ERJ8GEYG102	M.RESISTOR CH 1/10W 1K	1	
R7587	ERJ8GEYG223	M.RESISTOR CH 1/10W 22K	1	
R7589-72	ERJ8GEYG221	M.RESISTOR CH 1/10W 220	4	
R7573	ERJ8GEYG103	M.RESISTOR CH 1/10W 10K	1	
R7574	ERJ8GEYG102	M.RESISTOR CH 1/10W 1K	1	
RX7501, 02	EXBF6E104J	COMBI. R-R 100K	2	
RX7503	EXBF8E104J	COMBI. R-R 100K	1	
S7501	VSP1053	SWITCH	1	
VR4004	EVNCA003853	V.RESISTOR 5K	1	
ZB7501	VJF1331	FIP HOLDER	1	
ZB7503-05	VMD0504	LED HOLDER	6	
ZB7509, 10	VMD1932	LED SPACER	2	
ZB7511-16	VMD0504	LED HOLDER	6	
		MISCELLANEOUS		
	VEE0027	CABLE	1	P7601-P7503
■ VEPO48B5A	FRONT (L) C.B.A.		1 (RTL)	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C4851	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4852.53	ECUMIH471JCN	C. CAPACITOR CH 50V 470P	2	
C4854.55	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	2	
C4856	ECEA0JKA470	E. CAPACITOR 8.3V 47U	1	
C4857	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	1	
D4851.52	MA165	DIODE	2	
IR4851	RPM8937-V11	REMOTE CONTROL RECEIVER	1	
JK4851	VEJ1B01	JACK	1	
K4851	VWJD119	JUMPER	1	
LB4851.52	VLP0145	COIL	2	
P4851	VJS3537B0226	CONNECTOR (FEMALE)	1	
R4851-53	ERJ6GEY8750	M. RESISTOR CH 1/10W 75	3	
R4854.55	ERJ6GEY8101	M. RESISTOR CH 1/10W 100	2	
R4856	ERDS2TJ470	C. RESISTOR 1/4W 47	1	
R4857	ERJ6GEYF473	M. RESISTOR CH 1/10W 47K	1	
R4858	ERJ6GEY8332	M. RESISTOR CH 1/10W 3.3K	1	
S4851	EV011407K	SWITCH	1	
S4852	ESD170308	SWITCH	1	
S4853	VSR0221	SWITCH	1	
ZB4851	VMD2247	INFRA HOLDER	1	
ZB4852	VGU7654	SLIDE KNOB	1	
ZB4853	VGU7652	MIC KNOB	1	
ZB4854	VGF0740	VC SHEET	1	
■ VEP04898D		FRONT (R) C.B.A.	1 (RTL)	
G4801.02	ECUMIH103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C4803.04	ECUX1H223KBN	C. CAPACITOR CH 50V 0.22U	2	
C4805	ECEA1CKA330	E. CAPACITOR 18V 33U	1	
C4806	ECEA1EKS3R3	E. CAPACITOR 25V 3.3U	1	
C4807	ECUMIH472KBN	C. CAPACITOR CH 50V 4700P	1	
C4808	ECEA1AKA330	E. CAPACITOR 10V 33U	1	
C4809-11	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	3	
C4812	ECUMIH103ZFN	C. CAPACITOR CH 50V 0.01U	1	
C4813	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	1	
C4814.15	ECUMIH103ZFN	C. CAPACITOR CH 50V 0.01U	2	
C4816	ECUMIH104ZFN	C. CAPACITOR CH 50V 0.1U	1	
D4801	LN478YCPX4	DIODE	1	
LC4801	VCR0172	IC	1	
JA1	VEEOE94	FRONT (R) CABLE	1	
JK4801	VJJ0264	HEADPHONE JACK	1	
JK4802	VJJ0263	MIC JACK	1	
L4801.02	VL00599J221	COIL 220UH	2	
L4803.04	VL00599J471	COIL 470UH	2	
LB4801	VLP0145	COIL	1	
P4801	VJS3537B0209	CONNECTOR (FEMALE)	1	
QR4801	UN211F	TRANSISTOR-RESISTOR	1	
R4801	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
R4802	ERJ6GEY6882	M. RESISTOR CH 1/10W 6.8K	1	
R4803.04	ERJ6GEY6432	M. RESISTOR CH 1/10W 4.3K	2	
R4805	ERJ6GEY6221	M. RESISTOR CH 1/10W 220	1	
R4806	ERJ6BD471	M. RESISTOR CH 1/10W 470	1	
R4807	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	1	
R4808	ERJ6BD162	M. RESISTOR CH 1/10W 1.6K	1	
R4809.10	ERJ6BD101	M. RESISTOR CH 1/10W 100	2	
R4811	ERJ6BD162	M. RESISTOR CH 1/10W 1.6K	1	
R4812	ERJ6BD471	M. RESISTOR CH 1/10W 470	1	
R4813	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	1	
R4814	ERJ6BD162	M. RESISTOR CH 1/10W 1.6K	1	
R4815	ERJ6BD471	M. RESISTOR CH 1/10W 470	1	
R4816	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	1	
R4817	ERJ6BD101	M. RESISTOR CH 1/10W 100	1	
S4801-08	EV011407K	SWITCH	8	
VR4801	EVJYM0F15023	V. RESISTOR 2K	1	
VR4802	EWANYJX1054J	V. RESISTOR 1.05M	1	
VR4803	EVJ021F1554J	V. RESISTOR 1.55M	1	
ZB4801	VGU7650	VOLUME KNOB	1	
ZB4802.03	VGU7653	REC LEVEL KNOB	2	
ZB4804	VGU7652	MIC KNOB	1	
ZB4805	VMD2326	REFLECTOR	1	
ZB4806	VKM3673	REC VOL PLATE	1	
ZB4807	VGF0208	REC VR SHEET	1	
ZB4808	VGF0740	VC SHEET	1	
■ VEP07968A		MODULAR C.B.A.	1 (RTL)	
JK7801	VJJ0587	4P MODULAR JACK	1	
P7801	VJP1231T	CONNECTOR (MALE)	4P 1	
		MISCELLANEOUS		
VMX1021		LOCKING SPACER	1	
■ VEP07965A		FRONT LED C.B.A.	1 (RTL)	
D7751	LN01301C	DIODE	1	
D7752.53	LN01801C	DIODE	2	
D7754	LN01301C	DIODE	1	
P7751	VJP1244T	CONNECTOR (MALE)	4P 1	
P7752	VJS3537B0096	CONNECTOR (FEMALE)	1	
■ VEP07968B		IR C.B.A.	1 (RTL)	
C7701.02	ECKF1H103ZF	C. CAPACITOR 50V 0.01U	2	
D7701.02	MA4056-H	DIODE	2	
LB7701	VLP0196	COIL	1	
P7701	VJR1044	CONNECTOR	1	
P7751	VJS1231T	CONNECTOR (FEMALE)	1	
		MISCELLANEOUS		
VEEOC28		CABLE	1	IR-P7751

[illegible]

Memo

Panasonic